

DECEMBER 1, 2023



U.S. Department of Transportation  
**Federal Highway Administration**

# USER'S GUIDE

## TRAFFIC NOISE MODEL 3.2

FHWA-HEP-24-014  
FEDERAL HIGHWAY ADMINISTRATION  
Office of Natural Environment

## **Notice**

This document is disseminated under the sponsorship of the Department of Transportation in the interest of information exchange. The United States Government assumes no liability for the contents or use thereof.

The United States Government does not endorse products or manufacturers. Trade or manufacturers' names appear herein solely because they are considered essential to the objective of this report.

<b>REPORT DOCUMENTATION PAGE</b>			<i>Form Approved</i> <i>OMB No. 0704-0188</i>	
Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.				
1. AGENCY USE ONLY (Leave blank)		2. REPORT DATE September 2023		3. REPORT TYPE AND DATES COVERED Final Report
4. TITLE AND SUBTITLE Traffic Noise Model 3.2 User's Guide and Help Menu				5a. FUNDING NUMBERS HW58P123 WQ258
6. AUTHOR(S) Sophie Son and Aaron Hastings				5b. CONTRACT NUMBER HW58P123
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) U.S. Department of Transportation John A. Volpe National Transportation Systems Center 55 Broadway Cambridge, MA 02142-1093				8. PERFORMING ORGANIZATION REPORT NUMBER
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES) U.S. Department of Transportation Federal Highway Administration 1200 New Jersey Avenue, SE Washington, DC 20590				10. SPONSORING/MONITORING AGENCY REPORT NUMBER  FHWA-HEP-24-014
11. SUPPLEMENTARY NOTES FHWA Program Manager: Cecilia Ho				
12a. DISTRIBUTION/AVAILABILITY STATEMENT This document is available to the public on the FHWA website at <a href="http://www.fhwa.dot.gov">http://www.fhwa.dot.gov</a>				12b. DISTRIBUTION CODE
13. ABSTRACT (Maximum 200 words) The Federal Highway Administration (FHWA) with the assistance of the Volpe Center Acoustics Facility finalized the Traffic Noise Model (TNM) version 3.2. This document is the information found in the Help Menu inside TNM 3.2. It is being provided as a separate report, in addition to being embedded inside TNM 3.2, to assist users prior to using the model for the first time.				
14. SUBJECT TERMS Traffic Noise Model 3.2, TNM 3.2, Help Menu, User Guide, User Manual				15. NUMBER OF PAGES 73
				16. PRICE CODE
17. SECURITY CLASSIFICATION OF REPORT Unclassified	18. SECURITY CLASSIFICATION OF THIS PAGE Unclassified	19. SECURITY CLASSIFICATION OF ABSTRACT Unclassified	20. LIMITATION OF ABSTRACT	

NSN 7540-01-280-5500

Standard Form 298 (Rev. 2-89)  
Prescribed by ANSI Std. Z39-18  
298-102

SI* (MODERN METRIC) CONVERSION FACTORS				
APPROXIMATE CONVERSIONS TO SI UNITS				
Symbol	When You Know	Multiply By	To Find	Symbol
<b>LENGTH</b>				
in	inches	25.4	millimeters	mm
ft	feet	0.305	meters	m
yd	yards	0.914	meters	m
mi	miles	1.61	kilometers	km
<b>AREA</b>				
in <sup>2</sup>	square inches	645.2	square millimeters	mm <sup>2</sup>
ft <sup>2</sup>	square feet	0.093	square meters	m <sup>2</sup>
yd <sup>2</sup>	square yard	0.836	square meters	m <sup>2</sup>
ac	acres	0.405	hectares	ha
mi <sup>2</sup>	square miles	2.59	square kilometers	km <sup>2</sup>
<b>VOLUME</b>				
fl oz	fluid ounces	29.57	milliliters	mL
gal	gallons	3.785	liters	L
ft <sup>3</sup>	cubic feet	0.028	cubic meters	m <sup>3</sup>
yd <sup>3</sup>	cubic yards	0.765	cubic meters	m <sup>3</sup>
<b>NOTE: volumes greater than 1000 L shall be shown in m<sup>3</sup></b>				
<b>MASS</b>				
oz	ounces	28.35	grams	g
lb	pounds	0.454	kilograms	kg
T	short tons (2000 lb)	0.907	megagrams (or "metric ton")	Mg (or "t")
oz	ounces	28.35	grams	g
<b>TEMPERATURE (exact degrees)</b>				
°F	Fahrenheit	(F-32)/1.8	Celsius	°C
<b>ILLUMINATION</b>				
fc	foot-candles	10.76	lux	lx
fl	foot-Lamberts	3.426	candela/m <sup>2</sup>	cd/m <sup>2</sup>
<b>FORCE and PRESSURE or STRESS</b>				
lbf	poundforce	4.45	newtons	N
lbf/in <sup>2</sup>	poundforce per square inch	6.89	kilopascals	kPa

<b>SI* (MODERN METRIC) CONVERSION FACTORS</b>				
<b>APPROXIMATE CONVERSIONS FROM SI UNITS</b>				
<b>Symbol</b>	<b>When You Know</b>	<b>Multiply By</b>	<b>To Find</b>	<b>Symbol</b>
<b>LENGTH</b>				
<b>mm</b>	millimeters	0.039	inches	in
<b>m</b>	meters	3.28	feet	ft
<b>m</b>	meters	1.09	yards	yd
<b>km</b>	kilometers	0.621	miles	mi
<b>AREA</b>				
<b>mm<sup>2</sup></b>	square millimeters	0.0016	square inches	in <sup>2</sup>
<b>m<sup>2</sup></b>	square meters	10.764	square feet	ft <sup>2</sup>
<b>m<sup>2</sup></b>	square meters	1.195	square yards	yd <sup>2</sup>
<b>ha</b>	hectares	2.47	acres	ac
<b>km<sup>2</sup></b>	square kilometers	0.386	square miles	mi <sup>2</sup>
<b>VOLUME</b>				
<b>mL</b>	milliliters	0.034	fluid ounces	fl oz
<b>L</b>	liters	0.264	gallons	gal
<b>m<sup>3</sup></b>	cubic meters	35.314	cubic feet	ft <sup>3</sup>
<b>m<sup>3</sup></b>	cubic meters	1.307	cubic yards	yd <sup>3</sup>
<b>mL</b>	milliliters	0.034	fluid ounces	fl oz
<b>MASS</b>				
<b>g</b>	grams	0.035	ounces	oz
<b>kg</b>	kilograms	2.202	pounds	lb
<b>Mg (or "t")</b>	megagrams (or "metric ton")	1.103	short tons (2000 lb)	T
<b>g</b>	grams	0.035	ounces	oz
<b>TEMPERATURE (exact degrees)</b>				
<b>°C</b>	Celsius	1.8C+32	Fahrenheit	°F
<b>ILLUMINATION</b>				
<b>lx</b>	lux	0.0929	foot-candles	fc
<b>cd/m<sup>2</sup></b>	candela/m <sup>2</sup>	0.2919	foot-Lamberts	fl
<b>FORCE and PRESSURE or STRESS</b>				
<b>N</b>	newtons	0.225	poundforce per square	lbf lbf/in <sup>2</sup>
<b>kPa</b>	Kilopascals	0.145	inch	

*\*SI is the symbol for the International System of Units. Appropriate rounding should be made to comply with Section 4 of ASTM E380. (Revised March 2003)*

# TABLE OF CONTENTS

<b>TABLE OF CONTENTS.....</b>	<b>4</b>
<b>LIST OF FIGURES .....</b>	<b>7</b>
<b>1. INTRODUCTION .....</b>	<b>1</b>
1.1 TECHNICAL SUPPORT.....	1
<b>2. DEFAULT INTERFACE LAYOUT .....</b>	<b>2</b>
2.1 WINDOW MANIPULATION .....	4
<b>3. TOOLBAR.....</b>	<b>5</b>
3.1 FILE TAB .....	5
3.1.1 <i>Creating a New Project</i> .....	5
3.1.2 <i>Opening a Project</i> .....	8
3.1.3 <i>Saving a Project</i> .....	9
3.1.4 <i>Printing a Project</i> .....	9
3.1.5 <i>Closing a Project</i> .....	9
3.1.6 <i>Importing a Project</i> .....	9
3.1.7 <i>Exiting</i> .....	9
3.2 EDIT/MODIFY TAB .....	10
3.2.1 <i>Shared Tools Function</i> .....	10
3.2.2 <i>General Select Function</i> .....	11
3.2.3 <i>Receivers, Barriers, Roadways, Equipment, Terrain Lines, Building Rows, Tree Zones, Ground Zones, or Contour Zones Select Function</i> .....	11
3.3 VIEW TAB .....	12
3.3.1 <i>Sync 3D Geometry Function</i> .....	12
3.3.2 <i>Sync 3D View Function</i> .....	12
3.3.3 <i>Exaggerate Heights Function</i> .....	12
3.3.4 <i>Zoom Extent Function</i> .....	12
3.3.5 <i>Start Section Function</i> .....	12
3.3.6 <i>Toggle Point Labels Function</i> .....	13
3.3.7 <i>Toggle Object Labels Function</i> .....	13
3.4 SETTINGS TAB.....	13
3.4.1 <i>Application Settings Function</i> .....	13
3.4.2 <i>Project Settings Function</i> .....	15
3.5 CALCULATE TAB .....	18
3.5.1 <i>Receivers Function</i> .....	18
3.5.2 <i>For Roadways Function</i> .....	18
3.5.3 <i>For Equipment Function</i> .....	19
3.5.4 <i>Parallel Barrier (Calculate Section) Function</i> .....	19
3.6 BARRIER ANALYSIS TAB .....	20
3.6.1 <i>Mode Function</i> .....	20
3.6.2 <i>Current Analysis Function</i> .....	22
3.6.3 <i>Existing Analysis Function</i> .....	23
3.7 CONTOURS TAB .....	24
3.7.1 <i>Contour Levels Function</i> .....	24

3.7.2	<i>Calculate Contour Function</i> .....	25
3.7.3	<i>Grid File Function</i> .....	27
3.8	REPORTS TAB .....	27
3.8.1	<i>Input Reports Function</i> .....	27
3.8.2	<i>Results Reports Function</i> .....	28
3.9	TOOLS TAB .....	28
3.9.1	<i>Navigation History Function</i> .....	28
3.9.2	<i>Measure Function</i> .....	28
3.10	HELP TAB .....	29
<b>4.</b>	<b>LEGEND PANE</b> .....	<b>30</b>
<b>5.</b>	<b>VIEW PANE</b> .....	<b>31</b>
5.1	PLAN BUILDER .....	31
5.2	3D VIEW .....	32
5.3	SECTION VIEW .....	33
5.4	REPORT VIEW .....	33
<b>6.</b>	<b>EDIT PANE: EDIT TAB</b> .....	<b>35</b>
6.1	EDITING RECEIVER DEFAULTS.....	35
6.1.1	<i>To Edit the Basic Features of Receivers</i> .....	36
6.1.2	<i>To Edit the levels/Criteria Features of Receivers</i> .....	36
6.2	EDITING BARRIER DEFAULTS .....	37
6.2.1	<i>To Edit the Basic Features of Barriers</i> .....	37
6.2.2	<i>To Edit the Wall Reflection Features of Barriers</i> .....	38
6.2.3	<i>To Edit the Segment Features of Barriers</i> .....	38
6.2.4	<i>To Edit the Wall Unit Cost Features of Barriers</i> .....	38
6.3	EDITING ROADWAY DEFAULTS .....	38
6.3.1	<i>To Edit the Basic Features of Roadways</i> .....	39
6.3.2	<i>To Edit the Multi-Lane Settings of Roadways</i> .....	39
6.4	EDITING EQUIPMENT DEFAULTS .....	40
6.4.1	<i>To Edit the Basic Features of Equipment objects</i> .....	41
6.4.2	<i>To Edit the Equipment Settings</i> .....	41
6.5	EDITING TERRAIN LINE DEFAULTS .....	41
6.5.1	<i>To Edit the Basic Features of Terrain lines</i> .....	41
6.6	EDITING BUILDING ROW DEFAULTS.....	42
6.6.1	<i>To Edit the Basic Features of Building Rows</i> .....	42
6.6.2	<i>To Edit the Measurements Features of Building Rows</i> .....	42
6.7	EDITING TREE ZONE DEFAULTS .....	42
6.7.1	<i>To Edit the Basic Features of Tree Zones</i> .....	43
6.7.2	<i>To Edit the Ground Info Features of Tree Zones</i> .....	43
6.7.3	<i>To Edit the Measurements Feature of Tree Zones</i> .....	43
6.8	EDITING GROUND ZONE DEFAULTS .....	43
6.8.1	<i>To Edit the Basic Features of Ground Zones</i> .....	44
6.8.2	<i>To Edit the Ground Info of Ground Zones</i> .....	44
6.9	EDITING CONTOUR ZONE DEFAULTS .....	44
6.9.1	<i>To Edit the Basic Features of Contour Zones</i> .....	45
6.9.2	<i>To Edit the Measurements Features of Contour Zones</i> .....	45
<b>7.</b>	<b>EDIT PANE: SEARCH AND GEOCODE TABS</b> .....	<b>46</b>

7.1	SEARCH TAB .....	46
7.1.1	<i>To Search for an Item</i> .....	46
7.2	GEOCODE TAB .....	46
7.2.1	<i>To Locate Points on the Map</i> .....	47
7.2.2	<i>To Obtain a Geocoded Address</i> .....	47
<b>8.</b>	<b>OBJECT DETAILS PANE .....</b>	<b>48</b>
8.1	DATA ENTRY TIPS .....	48
8.2	DATA EXPORT TIP .....	49
8.3	RECEIVERS DETAIL SUB-PANE .....	50
8.4	BARRIERS DETAIL SUB-PANE .....	50
8.5	ROADWAYS DETAIL SUB-PANE .....	50
8.6	EQUIPMENT DETAIL SUB-PANE .....	50
8.7	TERRAIN LINES DETAIL SUB-PANE .....	50
8.8	BUILDING ROWS DETAIL SUB-PANE .....	51
8.9	TREE ZONES DETAIL SUB-PANE .....	51
8.10	GROUND ZONES DETAIL SUB-PANE .....	51
8.11	CONTOUR ZONES DETAIL SUB-PANE .....	51
8.12	USER-DEFINED VEHICLES DETAIL SUB-PANE .....	51
8.13	OUTPUT DETAIL SUB-PANE .....	51
8.14	PROJECT INFORMATION DETAIL SUB-PANE .....	51
8.15	ROADWAY RESULTS DETAIL SUB-PANE .....	51
8.16	EQUIPMENT RESULTS DETAIL SUB-PANE .....	52
8.17	VALIDATION RESULTS DETAIL SUB-PANE .....	52
<b>9.</b>	<b>DRAWING IN THE PLAN BUILDER .....</b>	<b>53</b>
9.1	ADDING RECEIVERS TO THE PROJECT .....	53
9.1.1	<i>To add a Receiver</i> .....	53
9.2	ADDING BARRIERS TO THE PROJECT .....	54
9.2.1	<i>To add a Barrier</i> .....	54
9.3	ADDING ROADWAYS TO THE PROJECT .....	55
9.3.1	<i>To add a Roadway</i> .....	55
9.4	ADDING EQUIPMENT TO THE PROJECT .....	56
9.4.1	<i>To add a Stationary Equipment Object</i> .....	56
9.4.2	<i>To add a Non-Stationary Equipment Object</i> .....	57
9.5	ADDING TERRAIN LINES TO THE PROJECT .....	58
9.5.1	<i>To add a Terrain Line</i> .....	59
9.6	ADDING BUILDING ROWS TO THE PROJECT .....	59
9.6.1	<i>To add a Building Row</i> .....	60
9.7	ADDING TREE ZONES TO THE PROJECT .....	60
9.7.1	<i>To add a Tree Zone</i> .....	60
9.8	ADDING GROUND ZONES TO THE PROJECT .....	61
9.8.1	<i>To add a Ground Zone</i> .....	61
9.9	ADDING CONTOUR ZONES TO THE PROJECT .....	62
9.9.1	<i>To add a Contour Zone</i> .....	62



# LIST OF FIGURES

<b>FIGURE 1</b> TNM DEFAULT INTERFACE LAYOUT .....	3
<b>FIGURE 2</b> TNM WINDOW MANIPULATION .....	4
<b>FIGURE 3</b> TNM TOOLBAR .....	5
<b>FIGURE 4</b> FILE TAB AND MENU .....	5
<b>FIGURE 5</b> NEW PROJECT DIALOG BOX .....	6
<b>FIGURE 6</b> SHARED TOOLS FUNCTION .....	10
<b>FIGURE 7</b> SEGMENTS BUTTON AND SUB-MENU .....	10
<b>FIGURE 8</b> GENERAL SELECT FUNCTION.....	11
<b>FIGURE 9</b> AVAILABLE OBJECT SELECT BUTTONS WITH ICONS.....	12
<b>FIGURE 10</b> VIEW TAB .....	12
<b>FIGURE 11</b> SETTINGS TAB.....	13
<b>FIGURE 12</b> APPLICATION SETTINGS DIALOG BOX.....	14
<b>FIGURE 13</b> PROJECT SETTINGS DIALOG BOX .....	16
<b>FIGURE 14</b> CALCULATE TAB .....	18
<b>FIGURE 15</b> BARRIER ANALYSIS TAB .....	20
<b>FIGURE 16</b> BARRIER ANALYSIS MODULE LAYOUT .....	22
<b>FIGURE 17</b> SAVE CURRENT BARRIER ANALYSIS DIALOG BOX.....	22
<b>FIGURE 18</b> BARRIER ANALYSIS MODULE LINE OF SIGHT CHECK.....	23
<b>FIGURE 19</b> LOAD BARRIER ANALYSIS DIALOG BOX.....	24
<b>FIGURE 20</b> CONTOURS TAB .....	24
<b>FIGURE 21</b> CONTOUR LEVELS DIALOG BOX.....	25
<b>FIGURE 22</b> SOUND LEVEL CONTOUR DIALOG BOX .....	26
<b>FIGURE 23</b> NOISE REDUCTION CONTOUR DIALOG BOX .....	26
<b>FIGURE 24</b> LEVEL DIFFERENCE CONTOUR DIALOG BOX.....	26
<b>FIGURE 25</b> TOOLS TAB.....	28
<b>FIGURE 26</b> HELP TAB.....	29
<b>FIGURE 27</b> VIEW PANE TABS .....	31
<b>FIGURE 28</b> PLAN BUILDER .....	32
<b>FIGURE 29</b> 3D VIEW .....	32
<b>FIGURE 30</b> SECTION VIEW .....	33
<b>FIGURE 31</b> REPORT VIEW .....	34
<b>FIGURE 32</b> EDIT RECEIVER DEFAULTS PANE .....	36
<b>FIGURE 33</b> EDIT BARRIER DEFAULTS PANE .....	37
<b>FIGURE 34</b> EDIT ROADWAY DEFAULTS PANE .....	39
<b>FIGURE 35</b> EDIT EQUIPMENT DEFAULTS PANE .....	40
<b>FIGURE 36</b> EDIT TERRAIN LINE DEFAULTS PANE .....	41
<b>FIGURE 37</b> EDIT BUILDING ROW DEFAULTS PANE.....	42
<b>FIGURE 38</b> EDIT TREE ZONE DEFAULTS PANE.....	43
<b>FIGURE 39</b> EDIT GROUND ZONE DEFAULTS PANE .....	44
<b>FIGURE 40</b> EDIT CONTOUR ZONE DEFAULTS PANE .....	45
<b>FIGURE 41</b> SEARCH SUB-PANE .....	46

<b>FIGURE 42</b> GEOCODE SUB-PANE .....	46
<b>FIGURE 43</b> OBJECT DETAILS PANE MENU .....	48
<b>FIGURE 44</b> ADDED RECEIVERS IN THE PLAN BUILDER .....	54
<b>FIGURE 45</b> AN ADDED BARRIER IN THE PLAN BUILDER .....	55
<b>FIGURE 46</b> ADDED ROADWAYS IN THE PLAN BUILDER .....	56
<b>FIGURE 47</b> AN ADDED STATIONARY EQUIPMENT OBJECT IN THE PLAN BUILDER .....	57
<b>FIGURE 48</b> AN ADDED NON-STATIONARY EQUIPMENT OBJECT IN THE PLAN BUILDER .....	58
<b>FIGURE 49</b> AN ADDED TERRAIN LINE IN THE PLAN BUILDER .....	59
<b>FIGURE 50</b> AN ADDED BUILDING ROW IN THE PLAN BUILDER.....	60
<b>FIGURE 51</b> AN ADDED TREE ZONE IN THE PLAN BUILDER.....	61
<b>FIGURE 52</b> AN ADDED GROUND ZONE IN THE PLAN BUILDER.....	62
<b>FIGURE 53</b> AN ADDED CONTOUR ZONE IN THE PLAN BUILDER.....	63

# I. INTRODUCTION

The Federal Highway Administration (FHWA) Traffic Noise Model (TNM) version 3.2 is a computer program that is used to analyze highway traffic noise to assist in the design and development of highway noise barriers. Roadway construction noise can also be analyzed in TNM 3.2. TNM computes the effect of intervening ground (defined by its type, or optionally by its flow resistivity) with theory-based acoustics that have been calibrated against field measurements. In addition, TNM allows sound to propagate underneath elevated, on-structure, intervening roadways and barriers, rather than being shielded by them. During calculation, TNM perturbs intervening barriers up and down from their input height to calculate for multiple heights. Then, during acoustical design of selected barriers and receivers, TNM displays sound-level results for any combination of barrier height perturbations. TNM also contains a check to determine if noise barriers break the lines-of-sight between sources and receivers. In addition, TNM provides summary cost and benefit information for each barrier design, from user-supplied unit barrier costs and land-use information. For selected cross sections, TNM also computes the effect of multiple reflections between parallel barriers or retaining walls that flank a roadway. The TNM user can then enter the computed parallel barrier performance degradations as adjustment factors for individual receivers in TNM's calculation of receiver sound levels.

TNM is provided by FHWA as a standalone application and includes a batch processing tool as well. This User Guide specifically covers the functionality provided by the TNM standalone application.

Detailed instructions on how to operate the TNM standalone application are comprised of the following topics:

- [DEFAULT INTERFACE LAYOUT](#)
- [TOOLBAR](#)
- [LEGEND PANE](#)
- [VIEW PANE](#)
- [EDIT PANE: EDIT TAB](#)
- [EDIT PANE: SEARCH AND GEOCODE TABS](#)
- [OBJECT DETAILS PANE](#)
- [DRAWING IN THE PLAN BUILDER](#)

## I.1 TECHNICAL SUPPORT

Please contact [TNMHelp@dot.gov](mailto:TNMHelp@dot.gov) for assistance with TNM. The FHWA also provides short **HOW-TO VIDEOS** that demonstrate how to accomplish basic tasks in TNM 3.0 and 3.1 on the FHWA YouTube channel under the 'TNM' playlist at:

[https://www.youtube.com/playlist?list=PL5\\_sm9g9d4T3naH9knm5E6SZUpml\\_QD3y](https://www.youtube.com/playlist?list=PL5_sm9g9d4T3naH9knm5E6SZUpml_QD3y). These tasks are performed similarly in TNM 3.2. New videos for TNM 3.2 will be added periodically.

## 2. DEFAULT INTERFACE LAYOUT

The TNM default layout of the user interface consists of the toolbar and individual function panes, annotated in **FIGURE 1**. The mouse and keyboard are used to navigate, draw, and execute TNM noise modeling. The main areas in the TNM application are as follows:

### TOOLBAR

The toolbar, located at the top of the user interface by default (Section 1 annotated in **FIGURE 1**), contains File, Edit/Modify, View, Settings, Calculate, Barrier Analysis, Contours, Reports, Tools, and Help tabs.

### LEGEND PANE

The Legend Pane, located at the left of the user interface by default (Section 2 annotated in **FIGURE 1**), shows layers and/or features that have been added to the project.

### VIEW PANE

The View Pane, located at in the center of the user interface by default (Section 3 annotated in **FIGURE 1**), includes the Plan Builder, 3D View, Section View, and Report View sub-panes.

### EDIT PANE: EDIT TAB

The Edit Pane, located at the right of the user interface by default (Section 4 annotated in **FIGURE 1**), contains the sub-panes of default settings for each input object including receivers, barriers, roadways, equipment, terrain lines, building rows, tree zones, ground zones, and contour zones.

### EDIT PANE: SEARCH AND GEOCODE TABS

The Search and Geocode functions are located within the Edit Pane in their respective tabs after the Edit tab. The Edit Pane is located at the right of the user interface by default (Section 4 annotated in **FIGURE 1**).

### OBJECT DETAILS PANE

The Object Details Pane, located at the bottom of the user interface by default (Section 5 annotated in **FIGURE 1**), allows the user to review the individual attributes of each object in the open TNM project.




Figure 1 TNM default interface layout

## 2.1 WINDOW MANIPULATION

The size and shape of all functional areas except the Toolbar can be changed by hovering the mouse over the borders between each section until the directional symbol replaces the cursor, clicking, and dragging in the direction indicated by the symbol.


The entire Legend Pane, as well as each tab of the Edit Pane and Object Details Pane can be minimized using the pin icon in the top right corner of each respective pane. Once minimized, they can be re-accessed by hovering over the tab title. Clicking and dragging the entire Legend Pane, as well as each tab of the View Pane, Edit Pane, and Object Details Pane pops it out of TNM into a separate floating window that can be resized and/or dragged to a desired location. The floating window can be redocked in a new location within the TNM window by dragging it to the desired location and releasing the mouse once the desired TNM homepage area turns yellow, as shown in **FIGURE 2**.



**Figure 2** TNM Window Manipulation

## 3. TOOLBAR

The Toolbar, shown in **FIGURE 3**, is used to perform various functions in TNM. Minimize or maximize the toolbar by right clicking and selecting Minimize the Ribbon.




**Figure 3** TNM Toolbar

The toolbar consists of the following tabs:

- [FILE TAB](#)
- [EDIT/MODIFY TAB](#)
- [VIEW TAB](#)
- [SETTINGS TAB](#)
- [CALCULATE TAB](#)
- [BARRIER ANALYSIS TAB](#)
- [CONTOURS TAB](#)
- [REPORTS TAB](#)
- [TOOLS TAB](#)
- [HELP TAB](#)

### 3.1 FILE TAB

The File Tab, shown in **FIGURE 4**, is used for [CREATING A NEW PROJECT](#), [OPENING A PROJECT](#), [SAVING A PROJECT](#), [PRINTING A PROJECT](#), [CLOSING A PROJECT](#), [IMPORTING A PROJECT](#) (or combining project files by adding objects from another file to the open project), and [EXITING](#) the TNM software.




**Figure 4** File Tab and Menu

#### 3.1.1 CREATING A NEW PROJECT

To create a new project:

1. Click the File Tab.
2. Click New Project. The New Project dialog box appears, shown in **FIGURE 5** with all possible inputs filled out.



The 'New Project' dialog box is shown with the 'Basic' tab selected. It contains the following fields and options:

- Organization:** Volpe
- Contract:** 51HW58P123
- Analysis By:** User Name
- Type:** ☐ Cartesian ☐ Geographic ☒ Projected
- Projection Settings:**
  - Category:** StatePlaneNad1983Feet
  - System:** NAD1983StatePlaneMassachusettsMainlandFIPS2001f
  - Units:** Foot\_US
- Units Of Measure:** English (Applies to length, distance, and speed.)
- Traffic:** LAeq1h: Volumes, Speeds
- Roadway Report Metric:** LA Avg
- RCNM Report Metric:** LAsmax
- RCNM Analysis Period (hrs):** 8
- Relative Humidity (%):** 50
- Temperature (°F):** 68
- Ground Type:** Pavement
- LOS Distance Limit [ft]:** 500.00
- ☐ Enable state plane adjustment
- Type:** ☒ Scale ☐ Offset
- State plane adjustment:**
  - X:** 0.0000000000
  - Y:** 0.0000000000
- ☒ Maintain aspect ratio
- Name:** My Project
- Description:** This project analyzes...
- Buttons:** Cancel, Create

Figure 5 New Project Dialog Box

3. Enter the Organization for the New Project to define optional metadata.  
**Note:** This value may be prepopulated from the [APPLICATION SETTINGS FUNCTION](#).
4. Enter the Contract for the New Project to define optional metadata.  
**Note:** This value may be prepopulated from the [APPLICATION SETTINGS FUNCTION](#).
5. Enter the user information for the New Project in Analysis By to define optional metadata.  
**Note:** This value may be prepopulated from the [APPLICATION SETTINGS FUNCTION](#).
6. Define the Projection Type for the New Project by selecting one of the Cartesian, Geographic, or Projected radio buttons. See Step Z for more details on the three options. The Projection Type, Category, System, and Units Project Settings define the format for input object coordinates, as well as the relationship between the input objects and the basemap shown in the Plan Builder.
7. Select the desired Category and System Projection Settings from the dropdown lists, as follows:
  - **Cartesian** defines spatial position using a pair of coordinates indicating that position's



relationship to a fixed origin where (0,0) corresponds to the intersection of the equator and prime meridian on a 2-dimensional plane of infinite distance. This system is most often utilized in Computer Aided Design (CAD) software and may or may not have a direct relationship with known coordinates on the Earth. Cartesian coordinates correspond to the Orthographic system used in TNM 2.5. Select 'Cartesian' from the Category dropdown list and either 'Cartesian 2D (Meters)' or 'Cartesian 2D (Feet)' from the System dropdown list, depending on the desired units for the New Project. The Units value will be populated according to the System selection.

- **Geographic** defines spatial position on a 3-dimensional spherical model of the Earth. Coordinates are described in terms of longitude, latitude, and elevation. Latitude and longitude are designated using decimal degrees or in degrees, minutes, and seconds. The recommended Geographic Category and System selections from their respective dropdown lists for New Projects located in North America are Category = 'World' and System = 'WGS1984'. These settings leverage the WGS84 (EPSG: 4326) in decimal degrees, which is a standard in cartography and navigation/global positioning systems. The Units value will be populated according to the System selection.
  - **Projected** defines spatial position on a model of the surface of the Earth where the Earth's surface is rendered as a flat, 2-dimensional surface. Different projected systems preserve or alter distance, shape/areas, and North directionality, among other factors that should be taken into consideration when selecting a projected coordinate system. In the absence of project-specific projection information, the recommended Projected Category and System selections from their respective dropdown lists for New Projects located in North America are Category = 'World' and System = 'WebMercator'. These settings leverage the WGS84 Web Mercator (EPSG: 3857) in meters, which is the de facto standard for web mapping applications. The Units value will be populated according to the System selection. See the FAQ document for more information.
8. Select the roadway noise analysis metric and roadway traffic input format for the New Project from the Traffic dropdown list.
- Note:** This value may be prepopulated from the [APPLICATION SETTINGS FUNCTION](#). Choose from:
- LAeq1h: Volumes, Speeds
  - LAeq1h: Percent Volumes, Speeds
  - Ldn: Day Night
  - Lden: Day Evening Night
9. Select the Roadway Report Metric for the New Project using the dropdown list.
- Note:** This value may be prepopulated from the [APPLICATION SETTINGS FUNCTION](#). Also note, this dropdown will be disabled if LAeq1h is not selected from the Traffic dropdown list in step 8. If LAeq1h is selected, choose from the following options:
- LA Avg (the average noise level across the hour)
  - LA10 (the noise level exceeded 10% of the hour)
  - LA50 (the noise level exceeded 50% of the hour)
10. Select the construction noise analysis metric for the New Project using the RCNM Report Metric dropdown list.

**Note:** This value may be prepopulated from the [APPLICATION SETTINGS FUNCTION](#).

Choose from:

- LAeq
- LAsmax

11. Enter the construction noise Analysis Period value for the New Project in the RCNM Analysis Period field.

**Note:** This value may be prepopulated from the [APPLICATION SETTINGS FUNCTION](#). Also note, this field will be disabled if LAsmax is selected from the RCNM Report Metric dropdown list in step 10, as shown in [FIGURE 5](#).

12. Enter the Relative Humidity value for the New Project.

**Note:** This value may be prepopulated from the [APPLICATION SETTINGS FUNCTION](#).

**Recommendation:** maintain default values, except for extreme weather conditions.

13. Enter the Temperature value for the New Project.

**Note:** This value may be prepopulated from the [APPLICATION SETTINGS FUNCTION](#).

**Recommendation:** maintain default values, except for extreme weather conditions.

14. Select a Ground Type for the New Project to define the default ground material applied throughout the Project extent, apart from areas covered by objects with unique acoustic ground impedance, namely roadways, ground zones, and tree zones. See [SECTIONS 6.8.2](#) and [9.8](#) for more details on how ground impedance is quantified.

**Note:** This value may be prepopulated from the [APPLICATION SETTINGS FUNCTION](#).

Choose from the following options in the dropdown list:

- Pavement
- Water
- Hard Soil
- Loose Soil
- Lawn
- Field Grass
- Granular Snow
- Powder Snow

15. Enter the LOS Distance Limit to define the range of the line of sight checking tool for the New Project.
16. Check or uncheck the “Enable state plane adjustment” checkbox to toggle the option for the New Project. Once enabled, the Scale and Offset radio buttons can be selected, and X/Y coordinates can be entered. Check or uncheck the checkbox to maintain the aspect ratio for the New Project coordinate system.
17. Enter the Name of the New Project.
18. Enter the Description of the New Project to define optional metadata.
19. Click Create to create the New Project.
20. Click Cancel at any time to cancel the creation of the New Project.

### 3.1.2 OPENING A PROJECT

To open an existing project:

1. Click the File Tab.
2. Click Open Project. A file explorer window opens.

**Note:** This option will be disabled if a project is currently open. Click Close Project in the File Tab to enable project opening.

3. Navigate to the desired file.
4. Select your project and click the Open button in the file explorer to open the project in TNM.
5. Click Cancel in the file explorer at any time to cancel opening a project.

### 3.1.3 SAVING A PROJECT

To save a project or save a project as:

1. Click the File Tab.
2. Click Save Project. A window stating 'Project Saved' will appear when complete.  
**Note:** This option will be disabled if no project is currently open.
3. Click OK.
4. Click Save Project As. A file explorer window opens.
5. Enter a Project Name in the file explorer and click Save. A window stating 'Project Saved' will appear when complete. Click OK.
6. Click Cancel in the file explorer at any time to cancel saving a project.

### 3.1.4 PRINTING A PROJECT

To print a project:

1. Click the File Tab.
2. Click Print Project. A window opens containing printing options.
3. Select the desired printing options in the window and click Print when done.
4. Click Cancel in the Print window at any time to cancel printing the project.

### 3.1.5 CLOSING A PROJECT

To close a project:

1. Click the File Tab.
2. Click Close Project. The project data will disappear from all function panes, but the TNM application will remain open.

### 3.1.6 IMPORTING A PROJECT

To import a project (or combine project files by adding objects from another file to the open project):

1. Click the File Tab.
2. Click Import From XML. A file explorer window opens.
3. Navigate to the desired file.
4. Select your project in the file explorer and click the Open button to import the project.
5. Click Cancel in the file explorer at any time to cancel importing a project.

### 3.1.7 EXITING

To exit the TNM software:

1. Click the File Tab.
2. Click Exit. The TNM application will close.

**Note:** If a project is currently open when Exit is clicked, a window will display prompting a save of the current project. After responding to that window, the TNM application will close.

## 3.2 EDIT/MODIFY TAB

The Edit/Modify tab contains the [SHARED TOOLS FUNCTION](#), the [GENERAL SELECT FUNCTION](#), and the [RECEIVERS, BARRIERS, ROADWAYS, EQUIPMENT, TERRAIN LINES, BUILDING ROWS, TREE ZONES, GROUND ZONES, OR CONTOUR ZONES SELECT FUNCTION](#). When editing an object, it must first be selected. An object can be selected by clicking on it in the [PLAN BUILDER](#) or [OBJECT DETAILS PANE](#) or by using the Edit/Modify tab to easily access multiple object selection options.

### 3.2.1 SHARED TOOLS FUNCTION

The Shared Tools Function, shown in [FIGURE 6](#), includes Delete, Edit, and Segments buttons to modify selected objects. The Enable Object Add button toggles whether the mouse is used in the Plan Builder for editing existing objects or creating new objects.




Figure 6 Shared Tools Function

To delete an entire object that has been selected, click the Delete button.

Click the Edit button to enable graphical movement of entire objects or individual object points in the Plan Builder. See the [EDIT PANE: EDIT TAB](#) for more information on editing an object's attributes.

The Segments button contains a dropdown list of actions (shown in [FIGURE 7](#)) to apply to the selected feature(s). This button will be disabled, as shown in [FIGURE 6](#), if no segmented objects are currently selected.




Figure 7 Segments button and sub-menu

- Enter a Divide (Length) to divide a feature by length.
- Enter a Divide (Number) to divide a feature by a numerical amount (e.g., divide into 4 sections).
- Click Combine Two Objects to combine selected objects on the map.<sup>1</sup>
- Click Divide Object in Two to split to an object into two separate objects.

<sup>1</sup> Note that if users are attempting to combine equipment objects, only non-stationary equipment objects of the same equipment ID can be combined. Once combined, users will need to re-enter the 'Time Active' input for the new object.

Verify that object attributes (e.g., traffic, flow control, structural pairings, etc.) are correct for all segments after applying one of the actions within the Segments button.

The Shared Tools function also includes the Enable Object Add button that allows or disallows drawing of objects in the Plan Builder. This button can be toggled via mouse click or the “D” key on the keyboard. TNM can only perform either the Edit or the Enable Object Add functions at a time, such that toggling the Enable Object Add function on will automatically disable the Edit function and vice versa.

### 3.2.2 GENERAL SELECT FUNCTION

To graphically move or delete objects, they must first be selected. See the [EDIT PANE: EDIT TAB](#) for more information on editing an object's attributes.

1. To select objects of multiple types at once in the Plan Builder, click the General Select button, shown in [FIGURE 8](#).
2. Choose Inside or Outside from the dropdown menu to define the rules for the desired area of selection.
3. If Inside is chosen, highlight the desired objects by clicking and dragging in the Plan Builder to draw a rectangular area of selection over the objects of interest. Upon release of the mouse, all objects contained within the area of selection will be highlighted to indicate their selection.
4. If Outside is chosen, highlight the desired objects by clicking and dragging in the Plan Builder to draw a rectangular area of selection that does not include any of the desired objects. Upon release of the mouse, all objects NOT contained within the area of selection will be highlighted to indicate their selection.

**Note:** Objects and/or segments can also be selected by single click in the [PLAN BUILDER](#) or [OBJECT DETAILS PANE](#). Multiple objects can be selected at once by holding the ‘Ctrl’ key while clicking.




Figure 8 General Select Function

### 3.2.3 RECEIVERS, BARRIERS, ROADWAYS, EQUIPMENT, TERRAIN LINES, BUILDING ROWS, TREE ZONES, GROUND ZONES, OR CONTOUR ZONES SELECT FUNCTION

To graphically move or delete receivers, barriers, roadways, equipment, terrain lines, building rows, tree zones, ground zones, or contour zones, they must first be selected. See the [EDIT PANE: EDIT TAB](#) for more information on editing an object's attributes.

1. To select objects of a particular type, click the Selection button for that object type. All options are shown in [FIGURE 9](#).
2. Choose Select, Select All, or Deselect All from the dropdown menu to highlight the desired objects.
3. If Select is chosen, highlight the desired objects by clicking and dragging in the Plan Builder to draw a rectangular area of selection over the objects of interest. Upon release of the mouse, all objects of the respective object type contained within the area of selection will be highlighted to indicate their selection.



Figure 9 Available Object Select buttons with Icons

### 3.3 VIEW TAB

The View tab, shown in **FIGURE 10**, contains the [SYNC 3D GEOMETRY FUNCTION](#), [SYNC 3D VIEW FUNCTION](#), [EXAGGERATE HEIGHTS FUNCTION](#), [ZOOM EXTENT FUNCTION](#), [START SECTION FUNCTION](#), [TOGGLE POINT LABELS FUNCTION](#), and [TOGGLE OBJECT LABELS FUNCTION](#).




Figure 10 View Tab

#### 3.3.1 SYNC 3D GEOMETRY FUNCTION

To sync the 3D geometry with the Plan Builder:

1. Click the Sync 3D Geometry button.
2. The Plan Builder and 3D View will refresh and display identical data in their respective formats.

#### 3.3.2 SYNC 3D VIEW FUNCTION

To sync the 3D View with the Plan Builder:

1. Click the Sync 3D View button.
2. The 3D View will refresh to match the view extent of the Plan Builder.

#### 3.3.3 EXAGGERATE HEIGHTS FUNCTION

To exaggerate the height of objects in the 3D View:

1. Click the Exaggerate Heights button.
2. Objects that have height above the ground will appear farther off the ground in the 3D View.

#### 3.3.4 ZOOM EXTENT FUNCTION

To see all objects in the Plan Builder and 3D View:

1. Click the Zoom Extent button
2. The Plan Builder and 3D View will refresh to include all input objects in their extent.

#### 3.3.5 START SECTION FUNCTION

The Start Section Function replaces the Skew View from TNM 2.5. It allows drawing of a section line in the Plan Builder to open the Section View containing a cross section of the input objects that intersect the section line.

To draw a section line:

1. Click the Start Section button.
2. Click in the Plan Builder to begin drawing the section line. A blue line will appear as drawing of

the section line continues.

3. Double click to terminate the section line in the Plan Builder such that the line crosses through all objects desired to be seen in the Section View.
4. The View Pane will switch from the Plan Builder to the Section View, which will display a cross section of the input objects included in the section line.
5. The Legend Pane will now include a 'SectionLine' item that can be toggled on and off in the Plan Builder. Section lines appear in the Plan Builder as dotted blue lines.

### 3.3.6 TOGGLE POINT LABELS FUNCTION

- To toggle object name labels for a specific object type, check or uncheck the checkbox next to the name of the desired object type.
- To toggle object name labels for all objects, click the Toggle All Object Labels Button.

### 3.3.7 TOGGLE OBJECT LABELS FUNCTION

- To toggle point name labels for a specific object type, check or uncheck the checkbox next to the name of the desired object type.
- To toggle point name labels for all objects, click the Toggle All Point Labels Button.

## 3.4 SETTINGS TAB

The Settings Tab, shown in [FIGURE 11](#), contains the [APPLICATION SETTINGS FUNCTION](#) and [PROJECT SETTINGS FUNCTION](#).



*Figure 11 Settings Tab*

### 3.4.1 APPLICATION SETTINGS FUNCTION

Prior to creating a new project, specific input settings can be tailored by preferences. These settings will apply to all new projects by appearing in the New Project dialog box ([FIGURE 5](#)) when [CREATING A NEW PROJECT](#).

The Application Settings function is enabled when there is no open project in TNM. To adjust the Application Settings, click the Application Settings button. The Application Settings dialog box appears, shown in [FIGURE 12](#) with all possible inputs filled out.

The screenshot shows the 'Application Settings' dialog box with the 'Project Defaults' tab selected. The settings are as follows:

Field	Value
Organization:	Volpe
Contract:	51HW58P123
Analysis By:	User Name
Units Of Measure:	English
Traffic:	LAeq1h: Volumes, Speeds
Roadway Report Metric:	LA Avg
RCNM Report Metric:	LAeq
RCNM Analysis Period (hrs):	8
Relative Humidity (%):	50
Temperature (°F):	68
Ground Type:	Pavement

Buttons: Cancel, Save Settings

**Figure 12** Application Settings Dialog Box

1. Enter a default Organization Name to define optional metadata.
2. Enter a default Contract Name to define optional metadata.
3. Enter default user information in Analysis By to define optional metadata.
4. Select a default Unit of Measure from the dropdown list. Choose English or Metric.
5. Select a default roadway noise analysis metric and roadway traffic input format from the Traffic dropdown list. Choose from:
  - LAeq1h: Volumes, Speeds
  - LAeq1h: Percent Volumes, Speeds
  - Ldn: Day Night
  - Lden: Day Evening Night
6. Select the default Report Metric using the dropdown list.
 

**Note:** This dropdown will be disabled if LAeq1h is not selected from the Traffic dropdown list in step 5.

If LAeq1h is selected, choose from the following options:

  - LA Avg (the average noise level across the hour)
  - LA10 (the noise level exceeded 10% of the hour)
  - LA50 (the noise level exceeded 50% of the hour)
7. Select the default construction noise analysis metric using the RCNM Report Metric dropdown list. Choose from:
  - LAeq
  - LAsmax
8. Enter the default construction noise Analysis Period value in the RCNM Analysis Period field.
 

**Note:** This field will be disabled if LAsmax is selected from the RCNM Report Metric dropdown list



in step [Z](#).

9. Enter a default Relative Humidity value.
10. Enter a default Temperature value.
11. Select a default Ground Type to define the ground material applied throughout the project extent, apart from areas covered by objects with unique acoustic ground impedance, namely roadways, ground zones, and tree zones. See [SECTIONS 6.8.2](#) and [9.8](#) for more details on how ground impedance is quantified. Choose from the following options in the dropdown list:
  - Pavement
  - Water
  - Hard Soil
  - Loose Soil
  - Lawn
  - Field Grass
  - Granular Snow
  - Powder Snow
12. Click Save Settings to save the Application Settings.
13. Click Cancel to abandon the changes.

### 3.4.2 PROJECT SETTINGS FUNCTION

The Project Settings function is enabled when there is an open project in TNM. Some Settings for the open project can be changed using this function, and all other Settings can be viewed. **Saving any changes to the Project Settings will reset any saved results within the project.**

To view or adjust the Project Settings, click the Project Settings button. The Project Settings dialog box appears, shown in [FIGURE 13](#) with all possible inputs filled out.

**Project Settings**

**Basic**

Organization: Volpe

Contract: 51HW58P123

Analysis By: User Name

Type: ☒ Cartesian ☐ Geographic ☐ Projected

Category: Cartesian

Projection Settings: System: Cartesian 2D (Feet)

Units: Feet

Units Of Measure: English (Applies to length, distance, and speed.)

Traffic: LAeq1h: Volumes, Speeds

Roadway Report Metric: LA Avg

RCNM Report Metric: LAeq

RCNM Analysis Period (hrs): 8

Relative Humidity (%): 50

Temperature (°F): 68

Ground Type: Pavement

LOS Distance Limit [ft]: 500.00

☐ Enable state plane adjustment

Type: ☒ Scale ☐ Offset

State plane adjustment: X: 0.0000000000

Y: 0.0000000000

☒ Maintain aspect ratio

Name: My Project

Description: This project file includes analysis of...

Cancel Save

**Figure 13** Project Settings Dialog Box

1. Enter or change the Organization Name for the open Project to define optional metadata.
2. Enter or change the Contract for the open Project to define optional metadata.
3. Enter or change the user information for the open Project in the Analysis By field to define optional metadata.
4. The Projection Type, Category, System, and Units settings are disabled as they cannot be changed once a project is created. This is known in [FIGURE 13](#).
5. Change the roadway noise analysis metric and roadway traffic input format for the open Project

from the Traffic dropdown list.

**Note:** Changing the Traffic will reset any saved roadway or construction noise results in the open project.

Choose from:

- LAeq1h: Volumes, Speeds
- LAeq1h: Percent Volumes, Speeds
- Ldn: Day Night
- Lden: Day Evening Night

6. Change the Roadway Report Metric for the open Project using the dropdown list.

**Note:** Changing the Roadway Report Metric will reset any saved roadway or construction noise results in the open project. Also note: this dropdown will be disabled if LAeq1h is not selected from the Traffic dropdown list in step [5](#).

If LAeq1h is selected, choose from the following options:

- LA Avg (the average noise level across the hour)
- LA10 (the noise level exceeded 10% of the hour)
- LA50 (the noise level exceeded 50% of the hour)

7. Change the construction noise analysis metric for the open project using the RCNM Report Metric dropdown list.

**Note:** Changing the RCNM Report Metric will reset any saved roadway or construction noise results in the open project.

Choose from:

- LAeq
- LAsmax

8. Change the construction noise Analysis Period value for the open project in the RCNM Analysis Period field.

**Note:** Changing the RCNM Analysis Period will reset any saved roadway or construction noise results in the open project. Also note, this field will be disabled if LAsmax is selected from the RCNM Report Metric dropdown list in step [7](#).

9. Change the Relative Humidity value for the open Project.

**Note:** Changing the Relative Humidity will reset any saved roadway or construction noise results in the open project.

10. Change the Temperature value for the open Project.

**Note:** Changing the Temperature will reset any saved roadway or construction noise results in the open project.

11. Change the Ground Type for the open Project to define the default ground material applied throughout the Project extent, apart from areas covered by objects with unique acoustic ground impedance, namely roadways, ground zones, and tree zones. See [SECTIONS 6.8.2](#) and [9.8](#) for more details on how ground impedance is quantified.

**Note:** Changing the Ground Type will reset any saved roadway or construction noise results in the open project.

Choose from the following options in the dropdown list:

- Pavement
- Water
- Hard Soil

- Loose Soil
  - Lawn
  - Field Grass
  - Granular Snow
  - Powder Snow
12. Change the LOS Distance Limit to define the range of the line of sight checking tool for the open Project.
  13. Check or uncheck the “Enable state plane adjustment” checkbox to toggle the option for the open Project. Once enabled, the Scale and Offset radio buttons can be selected, and X/Y coordinates can be entered. Check or uncheck the checkbox to maintain the aspect ratio for the Project coordinate system.  
**Note:** *Changing the state plane adjustment will reset any saved roadway or construction noise results in the open project.*
  14. Change the Name of the open Project.
  15. Enter or change the Description of the open Project to define optional metadata.
  16. Click Save Settings to save any changes to the Project Settings.
  17. Click Cancel to abandon any changes.

## 3.5 CALCULATE TAB

The Calculate tab, shown in [FIGURE 14](#), contains the [RECEIVERS FUNCTION](#), [FOR ROADWAYS FUNCTION](#), [FOR EQUIPMENT FUNCTION](#), and [PARALLEL BARRIER \(CALCULATE SECTION\) FUNCTION](#).

After setting up a project and adding all the needed input objects to the Plan Builder, users can calculate the noise level of roadway traffic or roadway construction activity at receivers that have been strategically placed in the area of interest. The results of these calculations are used to assist in the design of noise barriers.




Figure 14 Calculate Tab

### 3.5.1 RECEIVERS FUNCTION

The Receivers Function contains the Set Active button. The Set Active options allows toggling of the activation of receivers to be used for the calculate functions.

### 3.5.2 FOR ROADWAYS FUNCTION

The For Roadways Function contains All Receivers and Active Receivers buttons.

**Note:** *Performing one of the following steps is required in order to enable the [BARRIER ANALYSIS TAB](#).*

- To calculate all active and inactive receivers for roadway noise using a single thread, click the top half of the All Receivers button. Open the dropdown menu and select “All Roadways in parallel (beta)” to enable multi-threaded computation for roadway noise. A Calculation window appears displaying the computation progress. Users will be prompted to click OK when the

calculation is complete. The spectral data file called `thirdoct_roadways_<Roadway Noise Metric>.csv` (where the Roadway Noise Metric is established via the Traffic input in the Project Settings dialog box, see [FIGURE 13](#)) will automatically be saved in the following directory: `Documents\TNM\Temp\<Project Name>`. The [ROADWAY RESULTS DETAIL SUB-PANE](#) of the [OBJECT DETAILS PANE](#) opens.

- To calculate only the active receivers for roadway noise using a single thread, click the top half of the Active Receivers button. Open the dropdown menu and select “Active Receivers in parallel (beta)” to enable multi-threaded computation for roadway noise. A Calculation window appears displaying the computation progress. Users will be prompted to click OK when the calculation is complete. The spectral data file called `thirdoct_roadways_<Roadway Noise Metric>.csv` (where the Roadway Noise Metric is established via the Traffic input in the Project Settings dialog box, see [FIGURE 13](#)) will automatically be saved in the following directory: `Documents\TNM\Temp\<Project Name>`. The [ROADWAY RESULTS DETAIL SUB-PANE](#) of the [OBJECT DETAILS PANE](#) opens.
- To identify non-permitted input data for roadway noise analyses, click the Check Inputs button.

**Note:** *Parallel processing is currently a beta feature in TNM 3.2 to reduce computation time in early modeling stages. It should not be used to compute final noise levels reported for regulatory analyses.*

### 3.5.3 FOR EQUIPMENT FUNCTION

The For Equipment Function contains All Receivers and Active Receivers buttons.

- To calculate all active and inactive receivers for equipment noise using a single thread, click the All Receivers button. A Calculation window appears displaying the computation progress. Users will be prompted to click OK when the calculation is complete. The spectral data file called `thirdoct_equipment_<RCNM Report Metric>_<Analysis Period>hr.csv` (where the RCNM Report Metric and Analysis Period are established via the Project Settings dialog box, see [FIGURE 13](#)) will automatically be saved in the following directory: `Documents\TNM\Temp\<Project Name>`. The [EQUIPMENT RESULTS DETAIL SUB-PANE](#) of the [OBJECT DETAILS PANE](#) opens.
- To calculate only the active receivers for equipment noise using a single thread, click the top half of the Active Receivers button. Open the dropdown menu and select “Active Receivers in parallel (beta)” to enable multi-threaded computation for equipment noise. A Calculation window appears displaying the computation progress. Users will be prompted to click OK when the calculation is complete. The spectral data file called `thirdoct_equipment_<RCNM Report Metric>_<Analysis Period>hr.csv` (where the RCNM Report Metric and Analysis Period are established via the Project Settings dialog box, see [FIGURE 13](#)) will automatically be saved in the following directory: `Documents\TNM\Temp\<Project Name>`. The [EQUIPMENT RESULTS DETAIL SUB-PANE](#) of the [OBJECT DETAILS PANE](#) opens.
- To identify non-permitted input data for construction noise analyses, click the Check Inputs button.

**Note:** *Parallel processing is currently a beta feature in TNM 3.2 to reduce computation time in early modeling stages.*

### 3.5.4 PARALLEL BARRIER (CALCULATE SECTION) FUNCTION

The Parallel Barrier Function allows the user to define a section line between two parallel barriers and

calculate the degradation of barrier performance as the sound waves from the noise sources bounce between the barriers.

To compute the noise level increase due to parallel barriers:

1. Click the Calculate Section button.
2. Click in the Plan Builder to begin drawing a line through at least one receiver, at least one roadway or equipment source, and the parallel barriers. A red line will appear as drawing continues.
3. Double click to terminate the line, drawn as perpendicular as possible to the parallel barriers.
4. The Roadway or Equipment Results tab will open in the [OBJECT DETAILS PANE](#) based on which source type was included in the section line. The respective tab will display the noise level increase due to the parallel barriers in the Parallel Increase column.

**Note:** The computed barrier performance degradation should be applied to the pertinent receiver(s) outside of TNM because the parallel barrier analysis only accounts for the given barrier heights. Thus, the results only pertain to that barrier design (i.e., not the “No Barrier” levels or noise levels for any other barrier design), whereas the Adjustment Factors in TNM 3.2 (See [SECTION 8.3](#)) apply to all computed results throughout the model regardless of barrier segment height.

## 3.6 BARRIER ANALYSIS TAB

The Barrier Analysis tab is used when determining the optimal heights for each barrier segment when barrier perturbations have been included in the calculations. The Barrier Analysis tab contains the [MODE FUNCTION](#),

[CURRENT ANALYSIS FUNCTION](#), and [EXISTING ANALYSIS FUNCTION](#). The Barrier Analysis Tab tools will be disabled, as shown in [FIGURE 15](#), until the project includes a completed roadway noise receiver calculation using the [FOR ROADWAYS FUNCTION](#). The [MODE FUNCTION](#) and [EXISTING ANALYSIS FUNCTION](#) can then be used to analyze the results from that calculation.




Figure 15 Barrier Analysis Tab

### 3.6.1 MODE FUNCTION

The Mode Function contains the Start Analysis button.

To begin analyzing the For Noise Abatement barriers in the open project:

1. Click the Start Analysis button. The TNM workspace layout will shift to the Barrier Analysis Module, as shown in [FIGURE 16](#). The Start Analysis button in the Mode Function will be replaced with the End Analysis button. The Load button in the [EXISTING ANALYSIS FUNCTION](#) will become disabled. All [TOOLBAR](#) functions within the [EDIT/MODIFY TAB](#), [SETTINGS TAB](#), [CALCULATE TAB](#), [CONTOURS TAB](#), and [REPORTS TAB](#) will become disabled or non-functional.

**Note:** Only the active receivers and For Noise Abatement barriers will be shown in the Barrier

*Analysis Module workspace elements.*

The Barrier Analysis Module workspace elements on the top include a Plan Builder, 3D View, and the Barrier Analysis Tool pane.

**Note:** *The objects in the Barrier Analysis Module Plan Builder cannot be edited, but the view in the Barrier Analysis Module Plan Builder and 3D View can be tailored using the same controls enumerated in [SECTIONS 3.3, 5.1, and 5.2](#).*

The Barrier Analysis Tool pane includes a dropdown list of all For Noise Abatement barriers. The Barrier Analysis Module workspace elements on the bottom include the Receivers (Active) Table and two Barrier Design Tables that can be selected with tabs at the bottom right of the application. The data in these tables can be exported to .csv files at any time by clicking the Excel symbol in the bottom right corner of the desired table. A file explorer opens to designate the output file name and directory.

**Note:** *Once saved, these files will not update to reflect any future changes made in the Barrier Analysis Module.*

2. Select a Barrier using the dropdown list in the Barrier Analysis Tool Pane. Each segment of the selected barrier will be displayed along with the current heights.
3. Click the Up and Down buttons to perturb the corresponding barrier segment. Perturbing the barrier using these controls will update the barrier segment height in the 3D view and the resulting data in all three tables will reflect the newly established barrier design.
4. Click the Perturb Barrier Up and Perturb Barrier Down buttons in the bottom of the Barrier Analysis Tool Pane to perturb all segments at once for the selected barrier. Perturbing the barrier using these controls will update the barrier segment height in the 3D view and the resulting data in all three tables will reflect the newly established barrier design.
5. When all barrier segment height perturbations have been selected for all Noise Abatement barriers in order to achieve the desired results in the Barrier Analysis tables, click the End Analysis button in the Mode Function of the Barrier Analysis toolbar. A window appears prompting a save of the current project. Simultaneously, the TNM interface layout will revert to the configuration as it was before clicking the Start Analysis button.

See the [TNM 3.2 FAQs](#) (FHWA-HEP-24-013) for more information.




Figure 16 Barrier Analysis Module Layout

### 3.6.2 CURRENT ANALYSIS FUNCTION

The Current Analysis Function contains the Save and LOS Check buttons. These buttons are enabled when in the Start Analysis mode (i.e., a barrier design is open - see [SECTION 3.6.1](#)).

To save the current barrier design:

1. Click the Save button. The Save Current Analysis dialog box appears. The default barrier designs of All Barriers at Zero Height, All Abatement Barrier Segments at Zero Height, and Input Heights are displayed in the list of Other Saved Analyses, as shown in [FIGURE 17](#).
2. Enter a name for the current barrier design in the New Name field.
3. Click Save in the Save Current Analysis dialog box. A window stating 'Project Saved' will appear when complete. Click OK in the Project Saved window.
4. Click Cancel in the Save Current Analysis dialog box at any time to abandon saving the current barrier design.





Figure 17 Save Current Barrier Analysis Dialog Box



The LOS Check function enables the user to determine the degree to which selected barrier segments in the current barrier design break the line of sight between selected receivers and all roadways.

To check line of sight:

1. Select at least one receiver and one barrier segment for the tool to evaluate by holding the 'Ctrl' key while clicking in the Plan Builder.
2. Click the LOS Check button. Graphic lines in the 3D View connecting the chosen receivers with all roadway segments appear for all selected barrier segments, as shown in **FIGURE 18**. Green graphic rays indicate complete line of sight blockage for all vehicle sources. Yellow graphic rays indicate a line-of-sight blockage for some vehicle sources, while red graphic rays indicate a direct line of sight from source to receiver (i.e., no blockage of any vehicle source).
3. Perturb the selected barrier segments using the Barrier Analysis Tool pane. The graphic ray colors will update to reflect the current barrier design heights.
4. Click the LOS Check button to clear the graphic rays from the 3D View.



**Figure 18** Barrier Analysis Module Line of Sight Check

### 3.6.3 EXISTING ANALYSIS FUNCTION

The Existing Analysis function contains the Load button. This button will be disabled if in Start Analysis mode (i.e., a barrier design is open - see **SECTION 3.6.1**).

To open an existing barrier design:


1. Click the Load button in the Existing Analysis Function. The Load Barrier Analysis dialog box appears, as shown in **FIGURE 19**.
2. Click the Load button in the Open Analysis column of the Load Barrier Analysis dialog box.
3. Click the Close button at any time to cancel opening an existing barrier design.

To delete an existing barrier design:

1. Click the Load button in the Existing Analysis Function. The Load Barrier Analysis dialog box

appears, as shown in **FIGURE 19**.


2. Click the Delete button in the Delete Analysis column of the Load Barrier Analysis dialog box. A window appears prompting confirmation of the decision to delete the existing barrier design.
3. Click Yes. A window stating 'Project Saved' will appear when complete.
4. Click the Close button in the Load Barrier Analysis dialog box when finished.



**Figure 19** Load Barrier Analysis Dialog Box

## 3.7 CONTOURS TAB

The Contours tab, shown in **FIGURE 20**, is used when conducting a calculation for a selected contour zone. The Contours tab contains the [CONTOUR LEVELS FUNCTION](#), [CALCULATE CONTOUR FUNCTION](#), and the [GRID FILE FUNCTION](#). See the [TNM 3.2 FAQs](#) (FHWA-HEP-24-013) for information not found below.




**Figure 20** Contours Tab

### 3.7.1 CONTOUR LEVELS FUNCTION

The Contour Levels Function allows the user to establish the noise level range and step size between grid cells for contour zone calculations.

To establish the contour parameters for future calculations:

1. Click the Contour Levels button. The Contour Levels dialog box appears, as shown in **FIGURE 21**.
2. Enter the range minimum, maximum, and step inside range values for the desired contour type.
3. Click OK to save the input values.
4. Click Cancel to abandon the input values.



The dialog box is titled "Contour Levels" and contains two main sections: "Absolute Contour Levels" and "Relative Contour Levels".

**Absolute Contour Levels**  
*Used for: Sound Level Contours*

- Range Minimum [dBA]: 0
- Range Maximum [dBA]: 150
- Step Inside Range [dBA]: 5

**Relative Contour Levels**  
*Used for: Noise Reduction or Level Difference Contours*

- Range Minimum [dB]: -30
- Range Maximum [dB]: 30
- Step Inside Range [dB]: 1

At the bottom right are "OK" and "Cancel" buttons.

**Figure 21** Contour Levels Dialog Box

### 3.7.2 CALCULATE CONTOUR FUNCTION


The Calculate Contour Function contains the Sound Level, Noise Reduction, Level Difference, and Clear Contour buttons.

To conduct a contour calculation:

1. Select a single contour.
2. Click the Sound Level, Noise Reduction, or Level Difference buttons to initiate the desired contour type. A dialog box appears according to the selected contour type, shown in [FIGURE 22](#), [FIGURE 23](#), and [FIGURE 24](#). All saved barrier designs, including the three default options, are shown.
3. Select the desired barrier design to apply to the contour calculation.
4. Click OK to initiate calculation. The [ROADWAY RESULTS DETAIL SUB-PANE](#) of the [OBJECT DETAILS PANE](#) opens. A Calculation window appears displaying the computation progress. Users will be prompted to click OK when the calculation is complete.
5. The computed contour grid will appear on the Plan Builder. The contour grid file will automatically be saved in the following directory:  
*Documents\TNM\Temp\<Project Name>*. The file name is auto-generated with the following three components separated by an underscore: two-letter code for contour type (i.e., SL = Sound Level, NR = Noise Reduction, and LD = Level Difference), TNM contour object name, and name of the barrier design selected by the user when prompting a contour calculation. See Table 12 in the [TNM 3.2 Technical Manual](#) (FHWA-HEP-24-015) for details on the file format.

To remove a displayed contour:

1. Select the desired contour for removal.
2. Click the Clear Contour dropdown menu.
3. Click the Clear Selected Contour option in the dropdown menu.



Calculate Sound Level Contour


Contour Zone Name: **Contour Zone-2**

Design Name

All Barriers at Zero Height  
All Abatement Barrier Segments at Zero Height  
Input Heights

Contour Range: [0 to 150] dBA Step: 5 dBA

OK Cancel

**Figure 22** Sound Level Contour Dialog Box


Calculate Noise Reduction Contour


Contour Zone Name: **Contour Zone-2**

Design Name

All Barriers at Zero Height  
All Abatement Barrier Segments at Zero Height  
Input Heights

Contour Range: [-30 to 30] dB Step: 1 dB

OK Cancel

**Figure 23** Noise Reduction Contour Dialog Box


Calculate Level Difference Contour

Contour Zone Name: **Contour Zone-2**

Primary Design Name

All Barriers at Zero Height  
All Abatement Barrier Segments at Zero Height  
Input Heights

Design Name

All Barriers at Zero Height  
All Abatement Barrier Segments at Zero Height  
Input Heights

Contour Range: [-30 to 30] dB Step: 1 dB

OK Cancel

**Figure 24** Level Difference Contour Dialog Box

### 3.7.3 GRID FILE FUNCTION

The Grid File Function contains the Load Grid File and Delete Grid File buttons.

To redisplay a previously computed contour<sup>2</sup> in future TNM sessions:

1. Click the Load Grid File button. A file explorer window opens.
2. Navigate to the desired grid file.
3. Select the grid file and click the Open button in the file explorer to open the contour in TNM.
4. Click Cancel in the file explorer at any time to cancel loading a grid file.

To delete a grid file:

1. Click the Delete Grid File button. A file explorer window opens.
2. Navigate to the desired grid file.
3. Select the grid file and click the Open button in the file explorer to delete the grid file.
4. Click Cancel in the file explorer at any time to cancel deleting a grid file.

## 3.8 REPORTS TAB

The Reports Tab contains the [INPUT REPORTS FUNCTION](#) and [RESULTS REPORTS FUNCTION](#). Each Reports function contains links to reports that are visible in the [REPORT VIEW](#).

### 3.8.1 INPUT REPORTS FUNCTION

The Input Reports Function contains links to the Input Reports. Click any report link to view the report in the [REPORT VIEW](#).

The following Input Reports are listed:

- Receivers
- Barriers
- Tree Zones
- Traffic for TNM Vehicles
- Receiver Adjustment Factors
- On-Structure Barriers
- Contour Zones
- Traffic for User Defined Vehicles
- Terrain Lines
- Reflecting Barriers
- Roadways
- Building Rows
- Ground Zones
- Equipment

---

<sup>2</sup> Note that the loaded grid file will reflect the Contour Levels settings saved at the time of computation and will not be impacted by the current Contour Levels settings.

### 3.8.2 RESULTS REPORTS FUNCTION


The Result Reports Function contains links to the Result Reports. Click any report link to view the report in the [REPORT VIEW](#).

The following Result Reports are listed:

- Sound Levels - No Barrier Objects
- Sound Levels Diagnosis by Road Segment
- Sound Levels - Input Heights
- Sound Levels Diagnosis By Barrier Segment
- Barrier Descriptions
- Sound Levels Diagnosis by Vehicle Type - Input Heights
- Barrier - Segment Descriptions

## 3.9 TOOLS TAB

The Tools tab, shown in [FIGURE 25](#), contains the [NAVIGATION HISTORY FUNCTION](#) and [MEASURE FUNCTION](#).



*Figure 25 Tools Tab*

### 3.9.1 NAVIGATION HISTORY FUNCTION

Navigation allows users to revert to recent map locations in the [VIEW PANE](#).

- To revert to a prior map location, click the Previous button.
- To advance to the next prior map location, click the Next button.

### 3.9.2 MEASURE FUNCTION


The Measure Function allows distances to be approximated in the Plan Builder using the default unit of measure for the project. To approximate a distance:

1. Click the Measure Distance button.
2. Click in the Plan Builder to begin drawing at the desired location. A red line with a tooltip displaying the segment distance will display as drawing of the measurement line continues.
3. Click as many vertices as desired to measure the total distance.
4. Double click the end point location of the measurement line. The total distance of the measurement line will display on the Plan Builder.
5. To remove every measurement line on the Plan Builder, click the Remove All Measures button.

## 3.10 HELP TAB

The Help Tab, shown in **FIGURE 26**, contains the Getting Started, Help and About buttons.

- To open a PDF of the Getting Started Guide, click the Getting Started button.
- To open a PDF of the User's Guide (i.e., this document), click the Help button.
- To view version information for TNM, click the About button.



**Figure 26** Help Tab

## 4. LEGEND PANE


The Legend Pane displays the layers and/or features that have been added to the project, such as a roadway or Section Line, the object type will be listed in the Legend Pane. Once a feature is listed in the Legend Pane, users can choose whether the object type is visible in the Plan Builder and users can adjust the transparency of the object type in the Plan Builder.

- To toggle feature visibility in the Plan Builder, check or uncheck the checkbox next to the feature type in the Legend Pane.
- To adjust the transparency in the Plan Builder, move the slider along the bar next to the feature type in the Legend Pane.



## 5. VIEW PANE

The View Pane displays the map and associated map data using different visualization methods, shown in **FIGURE 27**. The View Pane contains the following four sub-panes: [PLAN BUILDER](#), [3D VIEW](#), [SECTION VIEW](#), and [REPORT VIEW](#).



**Figure 27** View Pane Tabs

### 5.1 PLAN BUILDER

The Plan Builder sub-pane displays the map in a top-down 2D format, as shown in **FIGURE 28**. The majority of input object creation is conducted in the Plan Builder. Object edits or selections made using the [OBJECT DETAILS PANE](#) will be reflected in the Plan Builder. See also: [DRAWING IN THE PLAN BUILDER](#).

To interact with the map in the Plan Builder:

- Click and drag the mouse to pan the map.
- Scroll the mouse wheel to zoom.
- Right click to open a list of the following functions:
  - Zoom to Best View
  - Clear Selection
  - Select All
  - Select All of Type: Receiver, Barrier, Roadway, Equipment, Terrain Line, Building Row, Tree Zone, Ground Zone, or Contour Zone
- Click the Eye icon at the bottom of the View Pane to open the following list of basemap options:
  - Aerial View
  - Physical View
  - Shaded Relief View
  - Road View (**Note: this is the default**)
  - Terrain Base View
  - Topographical View
- Click the arrow in the upper right corner of the Plan Builder to view a zoomed out version of the map showing the extent of the input objects in a wider geographical context.
- Toggle the visibility and transparency of features in the Plan Builder using the [LEGEND PANE](#)
- Select objects via manual click or the features within the Toolbar [EDIT/MODIFY TAB](#)
- Graphically edit the location of input objects using the Edit button in the [SHARED TOOLS FUNCTION](#)
- Add new objects using the Enable Object Add button in the [SHARED TOOLS FUNCTION](#)
- Modify the view using the Basic Tools and label toggles in the Toolbar [VIEW TAB](#)




Figure 28 Plan Builder

## 5.2 3D VIEW

The 3D View sub-pane displays the map and all input objects in a three-dimensional format, as shown in **FIGURE 29**. The 3D view is a three-dimensional representation of the 2D view in the Plan Builder such that the default perspective is top-down. Manipulating the 3D view perspective using the technique in the third bullet below allows users to see object elevation above the flat basemap.

To interact with the map in the 3D view:

- Click and drag the mouse to pan the map.
- Scroll the mouse wheel to zoom.
- Hold the middle mouse wheel and drag the mouse to rotate the map on an axis.
- Use the 3D Settings functions in the Toolbar [VIEW TAB](#) to manipulate the 3D View.





Figure 29 3D View

## 5.3 SECTION VIEW

The Section View sub-pane is used to visualize distance between selected objects, selected object heights, and elevation changes, as shown in **FIGURE 30**. The Section View displays a cross section of the input objects where a section line has been drawn in the Plan Builder using the [START SECTION FUNCTION](#). When switching between tabs in the [VIEW PANE](#), the Section View will always display the objects from the most recently drawn section line.

To interact with the Section View:

- Scroll the mouse wheel to zoom both axes at once.
- To zoom one axis independently, hover the mouse over the scroll bar for the axis of interest until the directional symbol replaces the cursor, click, and drag in the direction indicated by the symbol.
- Click the Reset Zoom button to restore the Section View to the default dimensions.
- Click the Toggle Labels button to enable/disable the object names displayed in the Section View.
- Click the Save View button to capture a .png of the current view including zoom and label settings. A file explorer window opens.



**Figure 30** Section View

## 5.4 REPORT VIEW

The Report View sub-pane is used to display and export selected reports for the open project. An excerpt of the Report View is shown in **FIGURE 31**. Reports are selected using the Toolbar [REPORTS TAB](#). When switching between tabs in the [VIEW PANE](#), the Report View will always display the data from the most recently selected report. Some of the header information above the data tables for each report is generated from the metadata inputs in the [PROJECT SETTINGS FUNCTION](#).

To interact with the Report View:

- Use the arrows or text box in the top left corner as well as the mouse scroll wheel to navigate through multiple pages.

- Click the Refresh icon to update a stale report.
- Click the Page Setup icon. A window opens containing layout settings.
- Click the Print Layout icon. The Report View will refresh to reflect the selected layout settings.
- Once satisfied with the layout, click the Print icon. A window opens containing print settings.
- Click the export icon. A dropdown list opens with the following output format options:
  - Excel
  - PDF
  - Word
- Select the desired report output format. A file explorer opens to designate the output file name and directory.
- Use the dropdown menu to adjust the report zoom.

PLAN BUILDER3D VIEWSECTION VIEWREPORT VIEW

1 of 2100%Find | Next

REPORT: INPUT ROADWAYS

TNM VERSION: 3.2.8741.34338

REPORT DATE: 6 December 2023

CALCULATED WITH: TNM v3.2.8741.95

CALCULATION DATE: 12/6/2023 10:57:06 AM

CASE: Getting Started

ORGANIZATION: Volpe

ANALYSIS BY: User Name

PROJECT/CONTRACT: 51HW58P123

Roadway Name	Roadway Notes	Road Segment		Coordinates (pavement)			Width	Point Notes	Road Segment		
		Start Point		X	Y	Z			Road Category	Pavement Type	On Structure
		Name	Number								
Roadway-1		Point-27	16	518878.30	612283.10	0.00	24.00		Mainline	Average	No
		Point-28	17	519064.50	612463.90	0.00	24.00		Mainline	Average	No
		Point-30	18	519257.50	612646.80	0.00	24.00		Mainline	Average	No
		Point-32	19	519444.40	612824.60	0.00	24.00		Mainline	Average	No
		Point-34	20	519892.20	613244.70	0.00	24.00		Mainline	Average	No
		Point-50	20	520440.00	613484.20	0.00	24.00		Mainline	Average	No

Figure 31 Report View


## 6. EDIT PANE: *EDIT TAB*

The Edit Tab within the Edit Pane contains the functions for editing TNM object default values. The following default editing functions are included:

-  [EDITING RECEIVER DEFAULTS](#)
-  [EDITING BARRIER DEFAULTS](#)
-  [EDITING ROADWAY DEFAULTS](#)
-  [EDITING EQUIPMENT DEFAULTS](#)
-  [EDITING TERRAIN LINE DEFAULTS](#)
-  [EDITING BUILDING ROW DEFAULTS](#)
-  [EDITING TREE ZONE DEFAULTS](#)
-  [EDITING GROUND ZONE DEFAULTS](#)
-  [EDITING CONTOUR ZONE DEFAULTS](#)

### 6.1 EDITING RECEIVER DEFAULTS

The Edit Receiver Defaults Pane, shown in [FIGURE 32](#), provides functions to edit defaults for all receivers that **have not** yet been added to the project. Default changes will not apply to receivers that have already been added to the project.

To edit receiver defaults, click the Receiver icon  .

**Receiver Defaults**



Basic		
Active	<input checked="" type="checkbox"/>	
Dwelling units	1	
Height [ft]	5	
Name	Receiver	
Notes		

Levels/Criteria		
Existing Level	<input type="checkbox"/>	0
Impact Increase	10	
Impact Level	<input type="checkbox"/>	0
Noise Reduction Goal	8	





Edit Search Geocode

*Figure 32 Edit Receiver Defaults Pane*

### 6.1.1 TO EDIT THE BASIC FEATURES OF RECEIVERS


- Check or un-check the Active checkbox to toggle the Active Receiver designation.
- Enter or use the up/down arrows  in the fill box to change the number of Dwelling units represented by each receiver.
- Enter or use the up/down arrows  in the fill box to change the Height of the receivers above the local ground.
- Enter text in the fill box to change the Name of the receivers.
- Enter text in the fill box to change any Notes about the receivers.


### 6.1.2 TO EDIT THE LEVELS/CRITERIA FEATURES OF RECEIVERS

- Enter or use the up/down arrows  in the fill box to change the Existing Level (ambient noise level).
- Enter or use the up/down arrows  in the fill box to change the Impact Increase (relative to the Existing Level).
- Enter or use the up/down arrows  in the fill box to change the Impact Level (absolute roadway noise level).
- Enter or use the up/down arrows  in the fill box to change the Noise Reduction Goal for barrier design.

## 6.2 EDITING BARRIER DEFAULTS

The Edit Barrier Defaults Pane, shown in **FIGURE 33**, provides functions to edit defaults for all barriers that **have not** yet been added to the project. Default changes will not apply to barriers that have already been added to the project.



To edit barrier defaults, click the Barrier icon .






Barrier Defaults	
<b>Basic</b>	
Barrier Type	<input type="checkbox"/> Wall
Max Height [ft]	<input type="text" value="300"/>
Min Height [ft]	<input type="text" value="0"/>
Name	<input type="text" value="Barrier"/>
Notes	<input type="text"/>
<b>Reflection</b>	
NRC Left-Side	<input type="checkbox"/> 0
NRC PBA	<input type="checkbox"/> 0
NRC Right-Side	<input type="checkbox"/> 0
<b>Segment</b>	
For Noise Abatement	<input checked="" type="checkbox"/>
Height [ft]	<input type="text" value="10"/>
Increment Size [ft]	<input type="text" value="0"/>
Increments Down	<input type="text" value="0"/>
Increments Up	<input type="text" value="0"/>
<b>Wall Unit Cost</b>	
Area [\$ /ft <sup>2</sup> ]	<input type="text" value="0"/>
Lineal [\$ /ft]	<input type="text" value="0"/>

**Figure 33** Edit Barrier Defaults Pane





### 6.2.1 TO EDIT THE BASIC FEATURES OF BARRIERS

- Use the dropdown list to change the Barrier Type. Choose from Wall or Berm.
- Enter or use the up/down arrows  in the fill box to change the Maximum Height to define the upper bound for input checking.
- Enter or use the up/down arrows  in the fill box to change the Minimum Height to define the lower bound for input checking.
- Enter text in the fill box to change the Name of the barriers.
- Enter text in the fill box to change any Notes about the barriers.



### 6.2.2 TO EDIT THE WALL REFLECTION FEATURES OF BARRIERS

- Enter or use the up/down arrows  in the fill box to change the Noise Reduction Coefficient for the barrier Left-Side.
- Enter or use the up/down arrows  in the fill box to change the Noise Reduction Coefficient for Parallel Barrier Analysis.
- Enter or use the up/down arrows  in the fill box to change the Noise Reduction Coefficient for the barrier Right-Side.

### 6.2.3 TO EDIT THE SEGMENT FEATURES OF BARRIERS


- Check or un-check the checkbox to toggle the For Noise Abatement barrier designation.  
**Note:** This will impact the noise level results within and outside of the Barrier Analysis module.
- Enter or use the up/down arrows  in the fill box to change the barrier segment Height.
- Enter or use the up/down arrows  in the fill box to change the perturbation IncrementSize.
- Enter or use the up/down arrows  in the fill box to change the number of possible perturbations Down.
- Enter or use the up/down arrows  in the fill box to change the number of possible perturbations Up.

### 6.2.4 TO EDIT THE WALL UNIT COST FEATURES OF BARRIERS

- Enter or use the up/down arrows  in the fill box to change the Area dollar amount per square unit.
- Enter or use the up/down arrows  in the fill box to change the Lineal dollar amount per linear unit.

## 6.3 EDITING ROADWAY DEFAULTS

The Edit Roadway Defaults pane, shown in [FIGURE 34](#), provides functions to edit defaults for all roadways that **have not** yet been added to the project. Default changes will not apply to roadways that have already been added to the project.

To edit roadway defaults, click the Roadway icon .



**Edit**

**Roadway Defaults**

**Basic**

Category	<input type="checkbox"/>	Mainline
Name	<input type="text"/>	Roadway
Notes	<input type="text"/>	
On Structure	<input type="checkbox"/>	
Pavement	<input type="checkbox"/>	Average
Width [ft]	<input type="text"/>	12

**Multi-Lane Settings**

Enable Multi-Lane	<input type="checkbox"/>	
Inside Shoulder	<input type="checkbox"/>	
Inside Shoulder Width...	<input type="text"/>	4
Number of Lanes	<input type="text"/>	2
Outside Shoulder	<input type="checkbox"/>	
Outside Shoulder Widt...	<input type="text"/>	4


**Edit Search Geocode**

Figure 34 Edit Roadway Defaults Pane


### 6.3.1 TO EDIT THE BASIC FEATURES OF ROADWAYS

- Use the dropdown list to change the Category label. Choose from Mainline, Ramp, or Shoulder.
- Enter text in the fill box to change the Name of the roadways.
- Enter text in the fill box to change any Notes about the roadways.
- Check or un-check the checkbox to toggle the On Structure designation for roadways.
- Use the dropdown list to change the roadway surface. Choose from the following Pavement types: Average, Dense Graded Asphalt, Open Graded Asphalt, or Portland Concrete.



**Note:** Average pavement is the only roadway surface type permitted for FHWA regulatory analyses.

- Enter or use the up/down arrows  in the fill box to change the roadway Width to define the pavement ground zone extending perpendicularly from either side of the roadway object centerline.

### 6.3.2 TO EDIT THE MULTI-LANE SETTINGS OF ROADWAYS


- Check/un-check the checkbox to enable/disable the Multi-Lane tool for digitizing many lanes and shoulders simultaneously.
- Check/un-check the checkbox to enable/disable the creation of an Inside Shoulder within the Multi-Lane tool.
- Enter or use the up/down arrows  in the fill box to change the Inside Shoulder Width to


define the pavement ground zone extending perpendicularly from either side of the roadway object centerline.

- Enter or use the up/down arrows  in the fill box to change the Number of Lanes digitized by the Multi-Lane tool.
- Check/un-check the checkbox to enable/disable the creation of an Outside Shoulder within the Multi-Lane tool.
- Enter or use the up/down arrows  in the fill box to change the Outside Shoulder Width to define the pavement ground zone extending perpendicularly from either side of the roadway object centerline.

## 6.4 EDITING EQUIPMENT DEFAULTS

The Edit Equipment Defaults pane, shown in [FIGURE 35](#), provides functions to edit defaults for all equipment that **have not** yet been added to the project. Default changes will not apply to equipment that have already been added to the project.

To edit equipment defaults, click the Equipment icon .



Equipment Defaults	
<b>Basic</b>	
Name	Equipment
Notes	
On Structure	<input type="checkbox"/>
<b>Equipment</b>	
Draw Type	Point
Equipment Height [ft]	7
Equipment Operation	Driving steel posts
Equipment Type	Air-Operated Post Driver
is Stationary	True
Is User Defined	<input type="checkbox"/> False
Time Active (Hours)	2

Edit Search Geocode

*Figure 35 Edit Equipment Defaults Pane*


### 6.4.1 TO EDIT THE BASIC FEATURES OF EQUIPMENT OBJECTS

- Enter text in the fill box to change the Name of the equipment.
- Enter text in the fill box to change any Notes about the equipment.
- Check or un-check the checkbox to toggle the On Structure designation for equipment.

### 6.4.2 TO EDIT THE EQUIPMENT SETTINGS


- Use the dropdown list to change the Equipment Type. Choose from a list of 70 default equipment objects as well as any user defined equipment objects that have been added to the UserDefinedEquipment.csv file. See Section 2.4.1 of the [TNM 3.2 Technical Manual \(FHWA-HEP-24-015\)](#) for more details on the default equipment. See Section 2.4.2 of the [TNM 3.2 Technical Manual](#) for instructions on inputting User Defined Equipment data.

**Note:** Selection of an Equipment Type in the Edit Equipment Defaults pane will change the non-editable Draw Type, Equipment Height, Equipment Operation, is Stationary, and is User Defined displays to reflect the equipment settings for the chosen object.

- Enter or use the up/down arrows  in the fill box to change the Time Active (Hours) to establish the duration of noise generating activity for equipment.

## 6.5 EDITING TERRAIN LINE DEFAULTS

The Edit Terrain Line Defaults pane, shown in [FIGURE 36](#), provides functions to edit defaults for all terrain lines that **have not** yet been added to the project. Default changes will not apply to terrain lines that have already been added to the project.

To edit terrain line defaults, click the Terrain Line icon .





Figure 36 Edit Terrain Line Defaults Pane


### 6.5.1 TO EDIT THE BASIC FEATURES OF TERRAIN LINES

- Enter text in the fill box to change the Name of the terrain lines.
- Enter text in the fill box to change any Notes about the terrain lines.

## 6.6 EDITING BUILDING ROW DEFAULTS

The Edit Building Row Defaults pane, shown in [FIGURE 37](#), provides functions to edit defaults for all building rows that **have not** yet been added to the project. Default changes will not apply to building rows that have already been added to the project.

To edit building row defaults, click the Building Row icon .





*Figure 37 Edit Building Row Defaults Pane*

### 6.6.1 TO EDIT THE BASIC FEATURES OF BUILDING ROWS


- Enter text in the fill box to change the Name of the building rows.
- Enter text in the fill box to change any Notes about the building rows.

### 6.6.2 TO EDIT THE MEASUREMENTS FEATURES OF BUILDING ROWS

- Enter or use the up/down arrows  in the fill box to change the Average building Height.
- Enter or use the up/down arrows  in the fill box to change the Gap Percentage to designate the space between the buildings as a percent of the spatial extent of the building row.

## 6.7 EDITING TREE ZONE DEFAULTS

The Edit Tree Zone Defaults pane, shown in [FIGURE 38](#), provides functions to edit defaults for all tree zones that **have not** yet been added to the project. Default changes will not apply to tree zones that have already been added to the project.

To edit tree zone defaults, click the Tree Zone icon .





Figure 38 Edit Tree Zone Defaults Pane


### 6.7.1 TO EDIT THE BASIC FEATURES OF TREE ZONES

- Enter text in the fill box to change the Name of the tree zones.
- Enter text in the fill box to change any Notes about the tree zones.

### 6.7.2 TO EDIT THE GROUND INFO FEATURES OF TREE ZONES

- Use the dropdown list to select or change the Ground Type beneath the trees. Choose from: Pavement, Water Hard Soil, Loose Soil, Lawn, Field Grass, Granular Snow, Powder Snow, or Custom.
- If Custom Ground Type is selected, enter or use the up/down arrows  in the fill box to select the Flow Resistivity of the Ground Type. Otherwise, the value in this field will reset to the corresponding Flow Resistivity for the Ground Type selected. See Section 4.3.1 in the [TNM 3.2 Technical Manual](#) (FHWA-HEP-24-015) for more details.

### 6.7.3 TO EDIT THE MEASUREMENTS FEATURE OF TREE ZONES

- Enter or use the up/down arrows  in the fill box to change the Average tree Height above the local ground.

## 6.8 EDITING GROUND ZONE DEFAULTS

The Edit Ground Zone Defaults pane, shown in [FIGURE 39](#), provides functions to edit defaults for all ground zones that **have not** yet been added to the project. Default changes will not apply to ground zones that have already been added to the project.

To edit ground zone defaults, click the Ground Zone icon .





Figure 39 Edit Ground Zone Defaults Pane

### 6.8.1 TO EDIT THE BASIC FEATURES OF GROUND ZONES


- Enter text in the fill box to change the Name of the ground zones.
- Enter text in the fill box to change any Notes about the ground zones.


### 6.8.2 TO EDIT THE GROUND INFO OF GROUND ZONES

- Use the dropdown list to select or change the Ground Type of the ground zones. Choose from: Pavement, Water Hard Soil, Loose Soil, Lawn, Field Grass, Granular Snow, Powder Snow, or Custom.
- If Custom Ground Type is selected, enter or use the up/down arrows  in the fill box to select the Flow Resistivity of the Ground Type. Otherwise, the value in this field will reset to the corresponding Flow Resistivity for the Ground Type selected. See Section 4.3.1 in the [TNM 3.2 Technical Manual](#) (FHWA-HEP-24-015) for more details.

## 6.9 EDITING CONTOUR ZONE DEFAULTS

The Edit Contour Zone Defaults pane, shown in [FIGURE 40](#), provides functions to edit defaults for all contour zones that **have not** yet been added to the project. Default changes will not apply to contour zones that have already been added to the project.

To edit contour zone defaults, click the Contour Zones icon .






*Figure 40 Edit Contour Zone Defaults Pane*

### 6.9.1 TO EDIT THE BASIC FEATURES OF CONTOUR ZONES

- Enter text in the fill box to change the Name of the contour zones.
- Enter text in the fill box to change any Notes about the contour zones.

### 6.9.2 TO EDIT THE MEASUREMENTS FEATURES OF CONTOUR ZONES

- Enter or use the up/down arrows  in the fill box to change the Height of the receiver Grid within the contour zones.
- Enter or use the up/down arrows  in the fill box to change the Minimum Spacing between the receiver Grid within the contour zones.
- Enter or use the up/down arrows  in the fill box to change the Tolerance value (the level difference between adjacent contour receiver levels required to split a grid cell).


## 7. EDIT PANE: SEARCH AND GEOCODE TABS


The Edit Pane also contains the [SEARCH TAB](#) and [GEOCODE TAB](#) functions.

### 7.1 SEARCH TAB

The Search tab is used to find objects that currently exist within the open project.

#### 7.1.1 TO SEARCH FOR AN ITEM


1. Enter the name of the desired object in the search bar. Suggestions populate as text is entered, as shown in [FIGURE 41](#).
2. Click the magnifying glass icon  or hit Enter on the keyboard to submit the search criteria. Results matching your search criteria display below the search bar.
3. Click a result. The Plan Builder will refresh to center around the selected object.



*Figure 41 Search Sub-pane*

### 7.2 GEOCODE TAB

The Geocode tab, shown in [FIGURE 42](#) is used to locate points on the map by address and vice versa, to obtain addresses from points on the map.



*Figure 42 Geocode Sub-Pane*



### 7.2.1 TO LOCATE POINTS ON THE MAP

1. Enter an address into the text field shown in [FIGURE 42](#) Geocode Sub-Pane.
2. Click the Geocode Address button or hit Enter on the keyboard to submit the address. Results matching your search criteria display below the Geocode Address and Clear buttons.
3. Click to select an option from the results list. A geocode symbol appears in the Plan Builder.
4. Click the Clear button to remove the geocode symbol from the Plan Builder.

### 7.2.2 TO OBTAIN A GEOCODED ADDRESS

1. Check the Pick from Map checkbox. The Enter Address field and Geocode Address button become disabled.
2. Click in the Plan Builder. The geocode symbol appears in the Plan Builder and the address for that location displays in the Geocode tab.
3. Click the Clear button in the Geocode tab to remove the geocode symbol from the Plan Builder.

## 8. OBJECT DETAILS PANE

The Object Details Pane lists the data for each object that currently exists within the open project, as well as overall noise level results and informational messages. The data in the tabs for each object type will update to reflect changes made in the [PLAN BUILDER](#). Vice versa, edits made in the Object Details Pane data grids will be reflected in the [VIEW PANE](#). The tab menu for each type of information is shown in **FIGURE 43**.

Receivers	Barriers	Roadways	Equipment	Terrain Lines	Building Rows	Tree Zones	Ground Zones	Contour Zones	User Defined Vehicles	Output	Project Information	Roadway Results	Equipment Results	Validation Results
-----------	----------	----------	-----------	---------------	---------------	------------	--------------	---------------	-----------------------	--------	---------------------	-----------------	-------------------	--------------------

**Figure 43** Object Details Pane Menu

The Detail pane consists of the following sub-panes:

- [RECEIVERS DETAIL SUB-PANE](#)
- [BARRIERS DETAIL SUB-PANE](#)
- [ROADWAYS DETAIL SUB-PANE](#)
- [EQUIPMENT DETAIL SUB-PANE](#)
- [TERRAIN LINES DETAIL SUB-PANE](#)
- [BUILDING ROWS DETAIL SUB-PANE](#)
- [TREE ZONES DETAIL SUB-PANE](#)
- [GROUND ZONES DETAIL SUB-PANE](#)
- [CONTOUR ZONES DETAIL SUB-PANE](#)
- [USER-DEFINED VEHICLES DETAIL SUB-PANE](#)
- [OUTPUT DETAIL SUB-PANE](#)
- [PROJECT INFORMATION DETAIL SUB-PANE](#)
- [ROADWAY RESULTS DETAIL SUB-PANE](#)
- [EQUIPMENT RESULTS DETAIL SUB-PANE](#)
- [VALIDATION RESULTS DETAIL SUB-PANE](#)

### 8.1 DATA ENTRY TIPS

TNM provides multiple techniques and tools that assist users in entering the attribute values in the Object Details Pane to reduce the time necessary to set up complex models. Here are a few tips:

- When editing roadway traffic data in the [ROADWAYS DETAIL SUB-PANE](#), TNM 3.2 allows users to click the 'Copy Down' button to apply repetitive traffic attributes to all subsequent data grid rows for each roadway segment.
- The easiest way to create objects with many points is to use the mouse to arbitrarily create an object with the correct number of points, while not worrying about the geometry. All input tables in TNM 3.2 can accept values copied from a spreadsheet, apart from the Roadways Traffic tab in the [ROADWAYS DETAIL SUB-PANE](#).

**Note:** With a large number of coordinates to replace, it may take a minute or two for TNM to update all the data.

A simple means of copy and pasting data into TNM 3.2 is as follows:

1. Click in the Object Details Pane table of interest in TNM
2. Key 'Ctrl + A' to select the entire data table contents (all cells will appear highlighted when complete)

3. Key 'Ctrl + C' to copy the entire data table contents
4. Key 'Ctrl + V' to paste the entire data table contents into an external spreadsheet (doing so will display TNM's expected data format for each column)
5. Modify the spreadsheet contents as desired while maintaining the expected format
6. Copy the entire modified spreadsheet table contents
7. Click in the Object Details Pane table of interest in TNM
8. Key 'Ctrl + A' to select the entire data table (all cells will appear highlighted when complete)
9. Key 'Ctrl + V' to paste the entire modified spreadsheet table contents into TNM.

**Note:** Any Sequence or Point Numbers that may have been changed in the spreadsheet will not be reflected when pasted into the Object Details Pane because they are fixed quantities within TNM. However, their column is a required part of any spreadsheet used to manipulate data outside of TNM in order to maintain the expected format when pasting back into TNM.

- For QA/QC, TNM 3.2 allows users to easily sort and filter data entered in all Object Details Pane data grids as well as the Barrier Analysis Tables in the Barrier Analysis Module. For example, this feature can be used to catch objects with non-unique names or other undesirable data attributes.

**Note:** Any data sorting or filtering will not be retained when reopening the project in a future TNM session.

Users may take advantage of the sorting and filtering capabilities with the following methods:

- Click the column header to sort data grids by the value of a single column. The column header will become highlighted to indicate the sorting parameter.
- Hold down the 'Shift' key on the keyboard and click to select the desired column headers for sorting data grids by the value of multiple columns at once. The column header will become highlighted to indicate the sorting parameter.
- Click on the funnel icon to the right of the column header text to open the filter menu for each data column.

**Note:** Data from multiple columns can be filtered at once using the filter menu. The funnel icon in the column header will become highlighted to indicate the data have been filtered using a parameter pertaining to the respective column.

## 8.2 DATA EXPORT TIP

The data tables in the Object Details Pane and Barrier Analysis Module can be exported to .csv files at any time.

**Note:** Once saved, these files will not update to reflect any future changes made in the TNM application.

To export Object Details Pane or Barrier Analysis table data:

1. Click the Excel symbol in the bottom right corner of the desired table. A file explorer window opens.
2. Navigate to the desired output file directory in the file explorer window.
3. Enter the desired output file name in the file explorer window.
4. Click Save in the file explorer window to write the file.
5. Click Cancel in the file explorer window at any time to abandon exporting the table data.

## 8.3 RECEIVERS DETAIL SUB-PANE

The Receivers Detail sub-pane contains the data for each receiver that currently exists within the open project. Users can view and edit the general settings, Levels/Criteria, and Adjustment Factors of each receiver by clicking the respective tabs in the left column of the Receivers detail sub-pane.

**Note:** *Sequence Numbers cannot be edited.*

## 8.4 BARRIERS DETAIL SUB-PANE

The Barriers Detail sub-pane contains the data for each barrier that currently exists within the open project. Users can view and edit the general settings, Points, Segments, Structure, and Reflections of each barrier by clicking the respective tabs in the left column of the Barriers details sub-pane.

**Note:** *The Point Numbers as well as the On Structure and Reflections checkboxes cannot be edited.*

Click the “Edit” button in the Textual Pairing column of the Structure or Reflections tab to open the respective dialog box for pairing barrier and roadway segments. Once a barrier segment is paired, the respective On Structure or Reflections checkbox will appear checked. See the [TNM 3.2 FAQs](#) (FHWA-HEP-24-013) for more details.

## 8.5 ROADWAYS DETAIL SUB-PANE

The Roadways Detail sub-pane contains the data for each roadway that currently exists within the open project. Users can view and edit the general settings, Points, Segments, Traffic, and Flow Control of each roadway by clicking the respective tabs in the left column of the Roadways details sub-pane. See the [TNM 3.2 FAQs](#) (FHWA-HEP-24-013) for more details.

**Note:** *Point Numbers cannot be edited.*

## 8.6 EQUIPMENT DETAIL SUB-PANE

The Equipment Detail sub-pane contains the data for each equipment object that currently exists within the open project. Users can view and edit the general settings, Points, and Segments of each equipment object by clicking the respective tabs in the left column of the Equipment details sub-pane. See the [TNM 3.2 FAQs](#) (FHWA-HEP-24-013) for more details.

**Note:** *The Equipment Type, Equipment Operation, Equipment Height, Equipment Stationary, Is User Defined, and Point Numbers cannot be edited as they are properties inherent to each equipment object. See Section 2.4.2 of the TNM 3.2 Technical Manual for instructions on inputting User Defined Equipment data.*

## 8.7 TERRAIN LINES DETAIL SUB-PANE

The Terrain Lines Detail sub-pane contains the data for each terrain line that currently exists within the open project. Users can view and edit the general settings, Points, and Segments of each terrain line by clicking the respective tabs in the left column of the Terrain Lines detail sub-pane.

**Note:** *Point Numbers cannot be edited.*

## 8.8 BUILDING ROWS DETAIL SUB-PANE

The Building Rows Detail sub-pane contains the data for each building row that currently exists within the open project. Users can view and edit the general settings, Points, and Segments of each building row by clicking the respective tabs in the left column of the Building Rows detail sub-pane.

**Note:** *Point Numbers cannot be edited.*

## 8.9 TREE ZONES DETAIL SUB-PANE

The Tree Zones Detail sub-pane contains the data for each tree zone that currently exists within the open project. Users can view and edit the general settings, Points, and Segments of each tree zone by clicking the respective tabs in the left column of the Tree Zones details sub-pane.

**Note:** *Point Numbers cannot be edited.*

## 8.10 GROUND ZONES DETAIL SUB-PANE

The Ground Zones Detail sub-pane contains the data for each ground zone that currently exists within the open project. Users can view and edit the general settings, Points, and Segments for each ground zone by clicking the respective tabs in the left column of the Ground Zones details sub-pane.

**Note:** *Point Numbers cannot be edited.*

## 8.11 CONTOUR ZONES DETAIL SUB-PANE

The Contour Zones Detail sub-pane contains the data for each contour zone that currently exists within the open project. Users can view and edit the general settings, Points, and Segments of each contour zone by clicking the respective tabs in the left column of the Contour Zones details sub-pane.

**Note:** *Point Numbers cannot be edited.*

## 8.12 USER-DEFINED VEHICLES DETAIL SUB-PANE

The User Defined Vehicles Detail sub-pane contains the data for each user defined vehicle that currently exists within the open project. Users can view and edit the user defined vehicles general settings here.

## 8.13 OUTPUT DETAIL SUB-PANE

The Output Detail sub-pane is an application log that provides a running list of the user commands as well as processes that were initiated and executed during the current TNM session. The Output detail sub-pane also includes the timestamps for the user commands as well as processes initiation and execution.

## 8.14 PROJECT INFORMATION DETAIL SUB-PANE

The Project Information detail sub-pane lists the project metadata for the open project.

## 8.15 ROADWAY RESULTS DETAIL SUB-PANE

The Roadway Results detail sub-pane lists the calculation results of the roadway noise model operations for the open project **after** the receiver calculations have been generated using the functions in the Toolbar [CALCULATE TAB](#).

**Note:** When input changes are made, previously calculated results are reset and the data in this sub-pane will disappear.

## 8.16 EQUIPMENT RESULTS DETAIL SUB-PANE

The Equipment Results detail sub-pane lists the calculation results of the construction noise model operations for the open project **after** the receiver calculations have been generated using the functions in the Toolbar [CALCULATE TAB](#).

**Note:** When input changes are made, previously calculated results are reset and the data in this sub-pane will disappear.

## 8.17 VALIDATION RESULTS DETAIL SUB-PANE

The Validation Results detail sub-pane lists the input check error and warning messages for the open project **before** the receiver calculations are generated. The data in this sub-pane will disappear after addressing the disallowed inputs and initiating a new input check or receiver calculation using the functions in the Toolbar [CALCULATE TAB](#). See the [TNM 3.2 FAQs](#) (FHWA-HEP-24-013) for more details.

## 9. DRAWING IN THE PLAN BUILDER

In order to calculate noise levels affecting a specific area, TNM objects must be added to the project. Objects that can be drawn in the Plan Builder are as follows:


- [ADDING RECEIVERS TO THE PROJECT](#)
- [ADDING BARRIERS TO THE PROJECT](#)
- [ADDING ROADWAYS TO THE PROJECT](#)
- [ADDING EQUIPMENT TO THE PROJECT](#)
- [ADDING TERRAIN LINES TO THE PROJECT](#)
- [ADDING BUILDING ROWS TO THE PROJECT](#)
- [ADDING TREE ZONES TO THE PROJECT](#)
- [ADDING GROUND ZONES TO THE PROJECT](#)
- [ADDING CONTOUR ZONES TO THE PROJECT](#)

**Note:** There are rules regarding which objects can and cannot coincide in TNM. See Appendix H of the [TNM 3.2 Technical Manual](#) for a comprehensive list of input object intersection rules and rationale.

### 9.1 ADDING RECEIVERS TO THE PROJECT

At least one receiver must be added to the project to define the location at which to compute noise levels. Users may add as many receivers as desired to ensure coverage of all appropriate noise analysis locations. However, limiting the number of receiver locations will help manage calculation runtimes. See the [TNM 3.2 FAQs](#) (FHWA-HEP-24-013) for more information.

#### 9.1.1 TO ADD A RECEIVER

1. Click the Receiver icon  in the Edit Pane. The Receiver Defaults window appears.
2. Press the "D" key on the keyboard or click the Enable Object Add button in the [SHARED TOOLS FUNCTION](#).
3. Click in the Plan Builder at the desired receiver location. A blue square appears at that point indicating that a receiver has been applied. An example is shown in [FIGURE 44](#).
4. To delete the receiver, right click on the receiver point and select Delete from the menu options.





Figure 44 Added Receivers in the Plan Builder

After a receiver has been added to the project, the attributes of the receiver can be edited in the [RECEIVERS DETAIL SUB-PANE](#).


## 9.2 ADDING BARRIERS TO THE PROJECT

Barriers can be added to the project to account for line-of-sight blockage resulting in noise abatement. Barrier segment heights can be adjusted to produce the desired level of noise abatement. However, limiting the number of perturbations will help manage calculation runtimes. See the [TNM 3.2 FAQs](#) (FHWA-HEP-24-013) for more information.

### 9.2.1 TO ADD A BARRIER

1. Click the Barrier icon  in the Edit Pane. The Barrier Defaults window appears.
2. Press the "D" key on the keyboard or click the Enable Object Add button in the [SHARED TOOLS FUNCTION](#).
3. Click in the Plan Builder at the desired starting location for the barrier. A blue line will appear as drawing continues.  
**Note:** Barrier direction is defined relative to the start and end points.
4. Click as many mid-points as desired to draw the barrier.
5. Double click the end point location for the barrier. A solid, red, directional line with red circles appears in the Plan Builder showing the starting point, mid-points, and end point indicating the barrier has been applied. An example is shown in [FIGURE 45](#).
6. To delete the barrier, right click on the barrier and select Delete from the menu options.






**Figure 45** An Added Barrier in the Plan Builder

After a barrier has been added to the project, the attributes of the barrier can be edited in the [BARRIERS DETAIL SUB-PANE](#).

## 9.3 ADDING ROADWAYS TO THE PROJECT


To compute traffic noise levels, at least one roadway must be added to the project to define the source. Roadway noise changes with respect to attributes including traffic volume and speed of each vehicle type, vehicle acceleration due to flow control and roadway grade, as well as roadway geometry relative to the receivers and intervening objects.

### 9.3.1 TO ADD A ROADWAY

1. Click the Roadway icon  in the Edit Pane. The Roadway Defaults window appears.
2. Press the "D" key on the keyboard or click the Enable Object Add button in the [SHARED TOOLS FUNCTION](#).
3. Click in the Plan Builder at the desired starting location of the roadway. A blue line will appear as drawing continues.  
**Note:** Roadway direction is defined relative to the start and end points.
4. Click as many mid-points as desired to draw the roadway.
5. Double click the end point location for the roadway. A solid, black, directional line with black circles appears in the Plan Builder showing the starting point, mid-points, and end point indicating the roadway has been applied. An example is shown in [FIGURE 46](#).
6. To reverse the direction of travel, right click on the roadway and select Reverse Direction from the menu options. After doing so, check to make sure the roadway attributes are still set as desired in the [ROADWAYS DETAIL SUB-PANE](#).

- To delete the roadway, right click on the roadway and select Delete from the menu options.

**Note:** For multiple lane roads, individual roadways should be added equaling the number of lanes on the actual road in the correct direction of traffic flow.




**Figure 46** Added Roadways in the Plan Builder

After a roadway has been added to the project, the attributes of the roadway can be edited in the [ROADWAYS DETAIL SUB-PANE](#).

## 9.4 ADDING EQUIPMENT TO THE PROJECT

To compute construction noise levels, an Equipment object must be added to the project to define the source. Each Equipment object that is added must be applied directionally (i.e., if a construction site has moving construction equipment, the path of travel must be added to the map; if a construction site has non-moving construction equipment, the directionality must be added to the map by defining the equipment orientation). In addition to directionality, construction noise changes with respect to attributes including the source spectra and height of each equipment object, as well as the duration of noise generating activity.


### 9.4.1 TO ADD A STATIONARY EQUIPMENT OBJECT

- Click the Equipment icon  in the Edit Pane. The Equipment Defaults window appears.
- Use the Equipment Type dropdown list under Equipment Settings to select an object such that the non-editable Draw Type displays 'Point'.

**Note:** Default and User Defined Equipment objects will be included in this list. See Section 2.4.2 of the [TNM 3.2 Technical Manual](#) (FHWA-HEP-24-015) for instructions on inputting User

*Defined Equipment data.*


3. Press the "D" key on the keyboard or click the Enable Object Add button in the [SHARED TOOLS FUNCTION](#).
4. Click in the Plan Builder at the desired location of the stationary equipment. A blue line will appear as drawing continues.
5. Click a secondary point in the Plan Builder to define the direction of the 'front' of the stationary equipment object and apply the stationary equipment object to the map. A golden-brown dotted line terminated on one end by a yellow and black striped square and on the other end by a black arrow appears in the Plan Builder, indicating the stationary equipment has been added. The yellow and black striped square represents the stationary equipment location. The dotted line and black arrow illustrate the orientation of the stationary equipment. An example is shown in [FIGURE 47](#).
6. To delete the stationary equipment object, right click on the stationary equipment object and select Delete from the menu options.



**Figure 47** An Added Stationary Equipment Object in the Plan Builder

After an equipment object has been added to the project, the attributes of the equipment can be edited in the [EQUIPMENT DETAIL SUB-PANE](#).


## 9.4.2 TO ADD A NON-STATIONARY EQUIPMENT OBJECT

1. Click the Equipment icon  in the Edit Pane. The Equipment Defaults window appears.
2. Use the Equipment Type dropdown list under Equipment Settings to select an object such that the non-editable Draw Type displays 'PolyLine'.

**Note:** Default and User Defined Equipment objects will be included in this list. See Section 2.4.2 of the [TNM 3.2 Technical Manual](#) (FHWA-HEP-24-015) for instructions on inputting User

*Defined Equipment data.*

3. Press the "D" key on the keyboard or click the Enable Object Add button in the [SHARED TOOLS FUNCTION](#).
4. Click in the Plan Builder at the desired starting location of the non-stationary equipment. A blue line will appear as drawing continues.  
**Note:** *Non-stationary equipment direction is defined relative to the start and end points.*
5. Click as many mid-points as desired to draw the non-stationary equipment object.
6. Double click the end point location for the non-stationary equipment. A solid, golden-brown, directional line with yellow and black striped squares appear on the map showing the starting point, mid-points, and end point indicating the equipment has been applied. An example is shown in [FIGURE 48](#).
7. To reverse the direction of travel, right click on the non-stationary equipment object and select Reverse Direction from the menu options.
8. To delete the non-stationary equipment object, right click on the non-stationary equipment object and select Delete from the menu options.



**Figure 48** An Added Non-Stationary Equipment Object in the Plan Builder

After an equipment object has been added to the project, the attributes of the equipment can be edited in the [EQUIPMENT DETAIL SUB-PANE](#).


## 9.5 ADDING TERRAIN LINES TO THE PROJECT


Terrain lines define points along the ground profile of a TNM project for geophysical features such as



hills or valleys. See the [TNM 3.2 FAQs](#) (FHWA-HEP-24-013) for more information. The ground profile in TNM provides attenuation via acoustic shielding.

### 9.5.1 TO ADD A TERRAIN LINE

1. Click the Terrain Line icon  in the Edit Pane. The Terrain Line Defaults window appears.
2. Press the "D" key on the keyboard or click the Enable Object Add button in the [SHARED TOOLS FUNCTION](#).
3. Click in the Plan Builder at the desired starting location of the terrain line. A blue line will appear as drawing continues.
4. Click as many mid-points as desired to draw the terrain line.
5. Double click the end point location for the terrain line. A solid, nondirectional, green line and red circles appears in the Plan Builder indicating the terrain line has been applied. An example is shown in [FIGURE 49](#).
6. To delete the terrain line, right click on the terrain line and select Delete from the menu options.



**Figure 49** An Added Terrain Line in the Plan Builder


After a terrain line has been added to the project, the attributes of the terrain line can be edited in the [TERRAIN LINES DETAIL SUB-PANE](#).


## 9.6 ADDING BUILDING ROWS TO THE PROJECT

Building rows are used to represent the acoustic shielding from the built environment. Building rows provide partial attenuation due to gaps between buildings such that line of sight is not completely

blocked between source and receivers.

### 9.6.1 TO ADD A BUILDING ROW

1. Click the Building Rows icon  in the Edit Pane. The Building Row Defaults window appears.
2. Press the "D" key on the keyboard or click the Enable Object Add button in the [SHARED TOOLS FUNCTION](#).
3. Click in the Plan Builder at the desired starting location of the building row. A blue line will appear as drawing continues.
4. Click as many mid-points as desired to draw the building row.
5. Double click the end point location for the building row. A dotted, red, nondirectional line with red circles appears in the Plan Builder indicating the Building Row has been applied. An example is shown in [FIGURE 50](#).
6. To delete the building row, right click on the building row and select Delete from the menu options.




*Figure 50 An Added Building Row in the Plan Builder*

After a building row has been added to the project, the attributes of the building row can be edited in the [BUILDING ROWS DETAIL SUB-PANE](#).

## 9.7 ADDING TREE ZONES TO THE PROJECT


Tree zones are used to represent the acoustic shielding from thick, dense foliage and thick undergrowth.

### 9.7.1 TO ADD A TREE ZONE

1. Click the Tree Zones icon  in the Edit Pane. The Tree Zone Defaults window appears.
2. Press the "D" key on the keyboard or click the Enable Object Add button in the [SHARED TOOLS](#)

**FUNCTION.**

- Click in the Plan Builder at the desired starting location of the tree zone. A light blue polygon outlined with dark blue lines will appear as drawing continues.
- Click as many vertices as desired to draw the tree zone.
- Double click the end point location for the tree zone. A green polygon with a dotted grey perimeter and red circular vertices appears in the Plan Builder indicating the tree zone has been applied. An example is shown in **FIGURE 51**.
- To delete the tree zone, right click on the tree zone and select Delete from the menu options.




**Figure 51** An Added Tree Zone in the Plan Builder

After a tree zone has been added to the project, the attributes of the tree zone can be edited in the [TREE ZONES DETAIL SUB-PANE](#).

## 9.8 ADDING GROUND ZONES TO THE PROJECT


Ground zones are used to define the ground material in the area of interest (superseding the default ground type defined in the [PROJECT SETTINGS FUNCTION](#)). Each ground material has unique acoustic characteristics that apply when calculating noise levels. For example, a grass covered area provides greater attenuation than a paved area.

### 9.8.1 TO ADD A GROUND ZONE

- Click the Ground Zone icon  in the Edit Pane. The Ground Zone Defaults window appears.
- Press the "D" key on the keyboard or click the Enable Object Add button in the [SHARED TOOLS](#)

**FUNCTION.**

3. Click in the Plan Builder at the desired starting location of the ground zone. A light blue polygon outlined with dark blue lines will appear as drawing continues.
4. Click as many vertices as desired to draw the ground zone.
5. Double click the end point location for the ground zone. A grey polygon with a solid grey perimeter and red circular vertices appears in the Plan Builder indicating the ground zone has been applied. An example is shown in **FIGURE 52**.
6. To delete the ground zone, right click on the ground zone and select Delete from the menu options.




*Figure 52 An Added Ground Zone in the Plan Builder*

After a ground zone has been added to the project, the attributes of the ground zone can be edited in the [GROUND ZONES DETAIL SUB-PANE](#).

## 9.9 ADDING CONTOUR ZONES TO THE PROJECT


Contour zones define areas for TNM to compute sound level computations using a grid of receivers. The calculation results display gradations of sound level change within the spatial extent of the contour zone.

### 9.9.1 TO ADD A CONTOUR ZONE

1. Click the Contour Zone icon  in the Edit Pane. The Contour Zone Defaults window appears.
2. Press the "D" key on the keyboard or click the Enable Object Add button in the [SHARED TOOLS](#) **FUNCTION**.
3. Click in the Plan Builder at the desired starting location of the contour zone. A light blue



- polygon outlined with dark blue lines will appear as drawing continues.
4. Click as many vertices as desired to draw the contour zone.
  5. Double click the end point location for the contour zone. A blue polygon with a solid grey perimeter and red circular vertices appears in the Plan Builder indicating the contour zone has been applied. An example is shown in **FIGURE 53**.
  6. To delete the contour zone, right click on the contour zone and select Delete from the menu options.



**Figure 53** An Added Contour Zone in the Plan Builder

After a contour zone has been added to the project, the attributes of the contour zone can be edited in the CONTOUR ZONES DETAIL SUB-PANE.