## HAMMER TIME USING THE SCHMIDT HAMMER TO IMPROVE THE FORECASTING ACCURACY OF THE ROCKFALL ACTIVITY INDEX (RAI)

## FINAL PROJECT REPORT

by

Daisy M. Herrman and Margaret M. Darrow University of Alaska Fairbanks

> Sponsorship University of Alaska Fairbanks

> > for

Pacific Northwest Transportation Consortium (PacTrans) USDOT University Transportation Center for Federal Region 10 University of Washington More Hall 112, Box 352700 Seattle, WA 98195-2700

> In cooperation with U.S. Department of Transportation, Office of the Assistant Secretary for Research and Technology (OST-R)



#### DISCLAIMER

The contents of this report reflect the views of the authors, who are responsible for the facts and the accuracy of the information presented herein. This document is disseminated under the sponsorship of the U.S. Department of Transportation's University Transportation Centers Program, in the interest of information exchange. The Pacific Northwest Transportation Consortium, the U.S. Government and matching sponsor assume no liability for the contents or use thereof.

TECHNICAL REPORT DOCUMENTATION PAGE						
1. Report No.	<b>2. Government Accession No.</b> 01872753	3. Recipient's Catalog No				
4. Title and Subtitle		5. Report Date				
HAMMER	R TIME	July 6, 2023				
USING THE SCHMIDT HAMMER TO IMP OF THE ROCKFALL AC	ROVE THE FORECASTING ACCURACY TIVITY INDEX (RAI)	6. Performing Organizati	on Code			
7. Author(s) and Affiliations		8. Performing Organizati	on Report No.			
Daisy M. Herrman, Margaret M. Darrow. 0000-00 University of Alaska Fairbanks	03-4078-4746	2022-S-UAF-1				
9. Performing Organization Name and Addres	s	10. Work Unit No. (TRAIS	5)			
PacTrans						
Pacific Northwest Transportation Consortium		11. Contract or Grant No.				
University Transportation Center for Federal R	egion 10	69A3551747110				
University of Washington More Hall 112 Seattl	e, WA 98195-2700					
12. Sponsoring Organization Name and Addre	ss	13. Type of Report and Period Covered				
United States Department of Transportation		Research, 1/16/2022-4/1	5/2023			
1200 New Jersey Avenue SE	ation	14. Sponsoring Agency Co	ode			
Washington, DC 20590						
15. Supplementary Notes						
Report uploaded to: www.pactrans.org						
16. Abstract						
The Schmidt hammer is a widely used and inexpensive instrument for estimating rock strength either in the lab or in the field. Our research team tested the accuracy and repeatability of the Schmidt hammer to estimate rock strength on six Alaskan rock slopes and four Washington/Oregon rock slopes. We determined <i>in situ</i> rock hardness by using two different Schmidt hammers (Types L and N); conducted unconfined compressive strength (UCS) testing for select Alaskan rock samples; and summarized the advantages and disadvantages of using the Schmidt hammer in the field. Parameters that potentially affect Schmidt hammer results include testing methodology, sample testing conditions, and data reduction. Our results indicated that major structures within a rock unit (such as bedding or foliation), variation in mineralogy, and moisture content will significantly affect Schmidt hammer results. After data collection, several correction methods can be used to process the Schmidt hammer results. The choice of method depends on the intent of the measurements (i.e., strength of the intact rock or the rock mass), and the application of any method can alter the final results. Our UCS results generally correlated to the Schmidt hammer rebound values (e.g., rock types with high rebound values also had high UCS values). Before utilizing the Schmidt hammer, we suggest users determine the final goal before selecting the Schmidt hammer and testing methodology; identify the rock type and potential discontinuities that can influence results; identify the bias in sample or site selection; and select the most applicable data reduction method for the identified goal.						
17. Key Words		18. Distribution Staten	nent			
Engineering geology, Schmidt hammer, streng	th testing		T			
19. Security Classification (of this report)	20. Security Classification (of this page)	21. No. of Pages	22. Price			
Unclassified.	25	N/A				

Form DOT F 1700.7 (8-72)

Reproduction of completed page authorized.

SymbolWhen You KnowMultiply ByTo FindSymbolIEENGTHftfeed0.305metersmftfeed0.305metersmftfeed0.305metersmmile0.305metersmmmiles0.305metersmmmiles0.305square millimetersm1mmiles0.082square metersm1square field0.083square metersm1gatasquare metersm1mmiles2.957millitlersmmiles2.957millitlersmftgators2.957millitlersmgators0.083square metersm1ftfuid ounces2.957millitlersmftgators2.957millitlersmgators0.0810.967equaremftfuid ounces2.957millitlersmftfuid ounces2.957millitlersmftfuid ounces2.957millitlersmftfuid ounces2.957millitlersmftfuid ounces1.060metersmftfuid ounces1.060metersmftfuido ouncesfuidometersmftfuidofuidometersmftfuidofuidofuidomft <th colspan="7">APPROXIMATE CONVERSIONS TO SI UNITS</th>	APPROXIMATE CONVERSIONS TO SI UNITS						
Incluses         LENGTH         Image: Constraint of the second se	Symbol	When You Know	Multiply By	To Find	Symbol		
in inches         22.4 constrained in the set of the set			LENGTH				
ftfeet0.305melersmmiles0.314melersmmiles0.514melersmmiles1.61klometersmmiles0.645.2square mellimetersmsquare field0.083square metersmsquare field0.083square metersmsquare square square field0.083square metersmsquare mellis2.59square metersmmile0.028cubic metersmmile0.028cubic metersmft*0.028cubic metersmgalagalons3.755littersmft*0.028cubic metersmmoutic pards0.755cubic metersmMgal0.0160.028cubic metersmgal0.0160.028cubic metersmMgal0.0160.028cubic metersmMgal0.0160.028cubic metersMMgal0.0160.045galgalgalgal1.0160.028cubic metersMMgal0.0160.045klogramsMMgal1.0160.028cubic metersMMgal1.0160.016cardicalm*MMgal1.0160.028cardicalm*MMgal1.0160.016cardicalm*M<	in	inches	25.4	millimeters	mm		
ydyards0.914metersmmiles1.61kilometersmrifcsquare inches645.2square milimetersmrifsquare fet0.033square milimetersmac.square fet0.033square milimetersmac.acres0.405hectareshaac.square milimetersmmac.square field0.259square kilometersKmgalgalons3.785litersLgalgalons3.785litersLgaloubic feet0.028cubic metersmyd*cubic greater than 1000 L shall be shown in m*myd*outors (2000 lb)0.907megagrams (or "metric tor")ggyd*outors (2000 lb)0.907megagrams (or "metric tor")ggyd*short tors (2000 lb)0.976kilogramsgdyd*short tors (2000 lb)0.976kilogramskilogramsftfoot-candles10.78kilogramskilogramsjd*poundforce per square inch4.45newtonskilogramsjdifipoundforce per square inch3.28feetkilopsacalskilom*meters0.021miliesmggquare milers0.021square inchesnmmeters0.021square inchesnftpoundforce per square inch4.45newtonskilopsacalsft <td>ft</td> <td>feet</td> <td>0.305</td> <td>meters</td> <td>m</td>	ft	feet	0.305	meters	m		
miles         1.61         klometers         km           inf         square inches         645.2         square meters         m <sup>2</sup> yd <sup>2</sup> square yard         0.836         square meters         m <sup>2</sup> yd <sup>2</sup> square relets         m <sup>2</sup> square meters         m <sup>2</sup> acreas         0.405         hectares         ha           m <sup>2</sup> square miles         2.59         square kilometers         m <sup>2</sup> floid ounces         2.837         millitiers         mL           gal galons         3.785         itters         L           ft <sup>4</sup> cubic feet         0.028         cubic meters         m <sup>2</sup> outies grate         0.785         cubic meters         m <sup>2</sup> outies grate         0.454         klograms         kg           gal         outies (200 lb)         0.907         megagrans (cr *metric tor)         Mg (or *p)           of foot-bandles         0.176         luz         kg         cdim*           gate         poundforce         4.46         mextons         N           foot-bandles         0.076         luz         kk         cdim*           foot-bandl	yd	yards	0.914	meters	m		
NATE-A $qalare inches645.2square millimetersm_1^{r2}t_1^{r2}square fet0.033square millimetersm_1^{r2}qalare inders0.405hectareshaacres0.405hectareshaacres0.405hectareshaqalare inders2.50square kilometersKmgalaracres0.405hectareshagalargalors3.785littersLgalarcubic reget0.028cubic metersm_1yd^3cubic gards0.785cubic metersm_1yd^3cubic gards0.785cubic metersm_1yd^3ounces2.835gramsggyd^3ounces0.785cubic metersMgg(or "t)Tshort tons (2000 lb)0.907megagrams (or "metric ton")MgG(or "t)Tfoot-candies10.78luxkdfifoot-candies10.78luxkdfipoundforce per square inch4.45newtonsMPbilinitionpoundforce per square inch10.81belospacealsKPbilinitionsquare field0.264nichesfifipoundforce per square inch4.45newtonsMPbilinitionsquare inches1.204yandsyandsyandsfisquare meters0.204millinitionfi$	mi	miles	1.61	kilometers	km		
int         square inches         645.2         square meters         mn <sup>m</sup> yd*         square (ref         0.033         square meters         m <sup>2</sup> square meters         0.436         square meters         m <sup>2</sup> ac         acres         0.405         hectares         ha           m <sup>1</sup> square miles         2.59         square meters         m <sup>2</sup> m <sup>1</sup> square meters         M <sup>2</sup> square meters         m <sup>2</sup> m <sup>1</sup> square meters         M <sup>2</sup> square meters         m <sup>2</sup> m <sup>1</sup> square meters         M <sup>2</sup> square meters         m <sup>2</sup> m <sup>1</sup> square meters         m <sup>2</sup> square meters         m <sup>2</sup> m <sup>2</sup> square meters         m <sup>2</sup> square meters         m <sup>2</sup> m <sup>2</sup> square meters         m <sup>2</sup> square meters         m <sup>2</sup> gal         galoris         square meters         m <sup>2</sup> square meters         m <sup>2</sup> galoris         galoris         m <sup>2</sup> square meters         m <sup>2</sup> square meters         m <sup>2</sup> square meters         0.000         9.000	. 2		AREA		2		
It of a square intent         C 0033         Square intents         m           acres         0.405         hectares         ha           acres         0.405         hectares         ha           mile         9 aquare indices         king         king           gal         3.785         litters         L           gal         0.785         cubic meters         m           yd*         cubic gards         3.785         litters         L           yd*         cubic gards         3.785         cubic meters         m           yd*         cubic gards         0.785         cubic meters         m           yd*         cubic gards         0.785         cubic meters         m           yd*         ounos         S.355         grans         gg         m           yd*         ounos         S.67         millithers         m         m           yd*         pounds         0.454         kiograms         gg         m           yd*         file foot-candles         10.76         kiz         m         m           foot-candles         10.76         kiz         m         m           foot-candles         10	in <sup>*</sup>	square inches	645.2	square millimeters	mm <sup>2</sup>		
jac         actros         indextres         indextr	vd <sup>2</sup>	square vard	0.093	square meters	$m^2$		
m <sup>2</sup> square miles         2.59         square kilometers         km <sup>2</sup> r         fluid ounces         28.57         milliliters         mL           gail         gailons         3.785         liters         L           ya <sup>a</sup> ouble (parts)         0.785         ouble meters         m <sup>3</sup> ya <sup>a</sup> ouble (parts)         0.785         ouble meters         m <sup>3</sup> va         ouble (parts)         0.785         ouble meters         m <sup>3</sup> va         ouble (parts)         0.785         ouble meters         m <sup>3</sup> va         ouble (parts)         0.454         kilogarns         kg           T         short (parts)         0.907         megagrams (or "metric ton")         Mg (or "t)           °F         Fahrenheit         5 (f-32)9         Celsius         °C         °C           ord (f-32)/18         T         tklopascals         Ng (or "t)         Ng (or "t)           °F         foot-candles         10.76         lux         anded/m <sup>2</sup> C4/m <sup>2</sup> for         foot-candles         0.0216         square kilopascals         Ng (parts)           food-candles         10.76         lux <t< td=""><td>ac</td><td>acres</td><td>0.405</td><td>hectares</td><td>ha</td></t<>	ac	acres	0.405	hectares	ha		
Incompose         VOLUME         mulliters         mulliters           galons         3.765         ittens         mulliters           galons         3.765         ittens         mulliters           galons         3.765         ittens         mulliters           galons         0.028         cubic meters         mulliters           with the point of the	mi <sup>2</sup>	square miles	2.59	square kilometers	km <sup>2</sup>		
fl did gal gal gal vd <sup>2</sup> fl did cubic cetts         fl did cubic cetts         fl did cubic cetts         fl did cubic cetts         fl did cubic cetts         fl did cetts         f			VOLUME				
gal         galons         3.785         liters         L           yd <sup>2</sup> cubic yards         0.765         cubic meters         m <sup>3</sup> yd <sup>2</sup> cubic yards         0.765         cubic meters         m <sup>3</sup> NOTE: volumes greater than 1000 L shall be shown in m <sup>3</sup> gg         gg         gg           outoes         28.35         grams         gg           outoes         0.907         megagrams (or "metric ton")         Mg (or "t")           T         shot tons (2000 ib)         0.907         megagrams (or "metric ton")         Mg (or "t")           outoes         0.454         kilograms (or "metric ton")         Mg (or "t")           outoes         10.76         lux         k         k           of to-candles         10.76         lux         k         k           of toot-candles         10.76         lux         k         k           tof         foot-candles         10.76         newtons         N           tof         poundforce per square inch         6.89         kilopascals         kPa           tof         poundforce per square inch         0.89         inches         inf           m         milterers         0.28 </td <td>fl oz</td> <td>fluid ounces</td> <td>29.57</td> <td>milliliters</td> <td>mL</td>	fl oz	fluid ounces	29.57	milliliters	mL		
ft <sup>n</sup> cubic refet         0.028         cubic meters         m <sup>n</sup> NOTE: volumes greater than 1000 Lshall be shown in m <sup>n</sup> NOTE: volumes greater than 1000 Lshall be shown in m <sup>n</sup> NOTE: volumes greater than 1000 Lshall be shown in m <sup>n</sup> OZ         cunces         28.35         grams         g           Dib         pounds         0.454         kilograms         kg           T         short tons (2000 lb)         0.907         megagrams (or "metric ton")         kg           T         Fahrenheit         5 (F-32)/9         Celsius         b         C           F         Fahrenheit         10.76         Lux         kg         d/m <sup>2</sup> T         foot-candles         10.76         Lux         kg         d/m <sup>2</sup> T         foot-damberts         3.426         cantela/m <sup>2</sup> kg         d/m <sup>2</sup> T         poundforce per square inch         6.89         kilopascals         N         N           Bifin <sup>m</sup> poundforce per square inch         6.89         inches         n         N           Bymbol         Milley By         To Find         Symbol         Symbol         N           Milley S         notacles         notacles	gal	gallons	3.785	liters	L		
ydr         Cubic yards         0.765         cubic meters         m"           NOTE: volumes greater than 1000 Lshalls be shown in m           MASS           oz         ounces         28.35         grams         g           lb         pounds         0.454         kilograms         kg           T         short tons (2000 lb)         0.907         megagrams (or "metric ton")         Mg (or "t)           °F         Fahrenheit         5 (F-32/1)         Celsius         °C           IELUMINATION           FORCE and PRESSURE or STERSS           FORCE and PRESSURE or STERS           UPONDIFICE and VIELUMINATION           IEROSTHE           IEROSTHE ONVERSIONS FUNCTS           Symbol         When You Know         Multiply By         To Find         Symbol           Meters         0.039         inches         in           meters         0.039         inches         in           Meters         0.039         inches         in           Meters         0.039         inches         in           Supoundforce per square inch         0.621         <	fť	cubic feet	0.028	cubic meters	m³		
Autorial Description         MASS         g           oz         ounces         28.35         grams         g           T         short tons (2000 lb)         0.907         megagrams (or "metric ton")         Mg (or "t")           "F         Fahrenheit         5 (F-32/)         Celsius         °C           or (F-32/)         Celsius         °C         °C           f         foot-Lamberts         10.76         lux         k           f         foot-Lamberts         34.26         candiel/m²         ck           f         foot-Lamberts         34.26         candiel/m²         k/r           f         poundforce per square inch         6.89         kilopascals         k/r           f         poundforce per square inch         6.89         kilopascals         k/r           f         matters         0.039         inches         inf           m         meters         0.828         feet         ft           m         meters         0.821         miles         miles           m         meters         0.036         inches         miles         inf           m         meters         0.038         feet         ft         ft	ya	cubic yards	U.765	cubic meters	m		
APPROVINGE         22.35         grams         g           bit         pounds         0.454         kilograms         kg           T         short tons (2000 lb)         0.907         megagrams (or "metric ton")         Mg (or "t")           °F         Fahrenheit         5 (F-32)/9         Calsius         °C           °F         Fahrenheit         5 (F-32)/9         Calsius         calsius           °F         Fahrenheit         5 (F-32)/9         Calsius         calsius           °F         Fahrenheit         5 (F-32)/9         Calsius         calsius           °F         Pahrenheit         5 (F-32)/9         Calsius         calsius           °F         Pahrenheit         5 (F-32)/9         Calsius         calsius           °F         Palrenheit         6 (S1         metrons         N           °F         Neters         0		NOTE. VOI	MACC	De shown in m			
Duta         Dutas         20.30 (Mig (or %))         gents	07	00000	1VIA33	aromo			
m         medgame         Mg (or "t)           response         TEMPERATURE (exact degrees)         "c"           °F         Fahrenheit         5 (F-32/9)         Celsius         "c"           °F         foot-candles         10.76         Lux         k           °f         foot-candles         10.76         Lux         k           °f         poundforce         4.45         newtons         N           bit/in <sup>n</sup> poundforce maguare inch         6.89         kilopascals         MP           Symbol         When You Know         Multiply By         To Find         Symbol         Symbol           mm         melters         0.039         inches         in         n           mm         melters         0.021         miles         mil	lb	pounds	0 454	kilograms	y ka		
TEMPERATURE (exact degrees)         0           °F         Fahrenheit         5 (f-32)/9         Celsius         °C           fc         foot-candles         10.76         lux         k           fd         foot-candles         10.76         lux         k           fd         foot-candles         10.76         lux         k           fd         poundforce         FORCE and PRESSURE or STRESS         N           lbf         poundforce per square inch         6.89         kilopascals         kPa           Symbol         When You Know         Multiply By         To Find         Symbol         Symbol           mm         meters         0.328         feet         ft         ft           mm         meters         0.621         miles         miles         miles           mm         square meters         1.09         yards         yd²	T	short tons (2000 lb)	0.907	megagrams (or "metric ton")	Mg (or "t")		
°F     Fahrenheit     5 (F-32)/9 or (F-32)/1.8     °C       ft     foot-candles     10.76     Lux     k       ft     foot-candles     10.76     k     cdm²       ft     poundforce     4.45     newtons     N       bf     poundforce per square inch     6.89     kilopascals     kPa       Symbol     When You Know     Multiply By     To Find     Symbol       Symbol When You Know     Multiply By     To Find     Symbol       Merers     0.039     inches     in       m     meters     3.28     feet     ft       m     meters     0.0016     square inches     in²       m     square meters     10.764     square feet     ft²       m <sup>2</sup> square meters     1.95     square gaues     gd       m <sup>3</sup> square meters     1.95     square feet     ft²       m <sup>4</sup> square meters     1.95     square feet     ft²       m <sup>4</sup> <		TE	MPERATURE (exact de	grees)			
ILLUMINATION         IX         IX           fc         foot-Lamberts         10.76         lux         k           fl         foot-Lamberts         3.426         candela/m <sup>2</sup> cd/m <sup>2</sup> FORCE and PRESSURE or STRESS         FORCE and PRESSURE or STRESS         N         N           Ibf/in <sup>2</sup> poundforce per square inch         6.89         kilopascals         N           Symbol         When You Know         Multiply By         To Find         Symbol           Symbol         When You Know         Multiply By         To Find         Symbol           m         meters         3.28         feet         ft           m         meters         3.28         feet         ft           m         meters         0.621         miles         mile           m <sup>2</sup> square millimeters         0.621         miles         mile           m <sup>2</sup> square meters         10.764         square square         ft <sup>2</sup> m <sup>2</sup> square meters         0.366         square square         gt <sup>2</sup> m <sup>2</sup> square feet         ft <sup>2</sup> gt <sup>2</sup> gt <sup>2</sup> m <sup>3</sup> square feet         ft <sup>2</sup>	°F	Fahrenheit	5 (F-32)/9	Celsius	°C		
ILLUMINATIONfcfoot-candies10.76luxkfcfoot-candies10.76candela/m²cd/m²FORCE and PRESSURE or STRESSIbifpoundforce4.45newtonsNpoundforce per square inch6.89kilopascalsKPaSymbolWhen You KnowMultiplyTo FindSymbolSymbolWhen You KnowMultiplyTo FindSymbolSymbolWhen You KnowMultiplyTo FindSymbolMultiple S0.039inchesmeters0.039inchesinmeters0.039inchesinmeters0.028inmeters0.028inmeters0.016square metersinNgaure meters0.0016square featifmeters0.0264gallonsgallonsgallonsgallonsgallon in meters0.035ound force of volspan="2"meters <t< td=""><td></td><td></td><td>or (F-32)/1.8</td><td></td><td></td></t<>			or (F-32)/1.8				
fc         foot-candles         10.76 toot-Lamberts         lux         k           ff         foot-Lamberts         3.426         candela/m <sup>2</sup> candela/m <sup>2</sup> bf         poundforce         4.45         newtons         N           bt/in <sup>2</sup> poundforce per square inch         6.89         kilopascals         kPa           Symbol         Venery colspan="4">Symbol         Symbol           Symbol When You Know         Multiply By         To Find         Symbol           Symbol When You Know         Multiply By         To Find         Symbol           Symbol When You Know         Multiply By         To Find         Symbol           Multiply By         To Find         Symbol           Maltimeters         0.016         Symare inters         N           mar <sup>2</sup> Square meters         0.016         Square feet         N           mar <sup>2</sup> Square meters         0.264         galons         galons         galons         galons <td colspa<="" td=""><td></td><td></td><td>ILLUMINATION</td><td></td><td></td></td>	<td></td> <td></td> <td>ILLUMINATION</td> <td></td> <td></td>			ILLUMINATION			
fl         foot-Lamberts         3.426         candela/m <sup>4</sup> od/m <sup>4</sup> FORCE and PRESSURE or STRESS           Newtons St UNITS           poundforce per square inch         6.89         kilopascals         KPa           APPROXIMATE CONVERSIONS FROM SI UNITS           Symbol         When You Know         Multiply By         To Find         Symbol           Symbol When You Know         Multiply By         To Find         Symbol           m         CENT           m         milimeters         0.039         inches         in           m         meters         3.28         feet         ft           m         meters         0.621         miles         mile           m <sup>2</sup> square milimeters         0.0016         square inches         in <sup>2</sup> m <sup>2</sup> square meters         1.195         square square         gt           m <sup>2</sup> square meters         0.386         square square         gt           m <sup>2</sup> square meters         1.195         square         gt           m <sup>3</sup> cubic meters         0.386         square         gt	fc	foot-candles	10.76	lux	lx		
FORCE and PRESSURE or STRESS         Ibf       poundforce per square inch       6.89       witopascals       N         APPROXIMATE CONVERSIONS FROM SI UNITS         Symbol       When You Know       Multiply By       To Find       Symbol         Symbol       When You Know       Multiply By       To Find       Symbol         Symbol       When You Know       Multiply By       To Find       Symbol         Symbol       When You Know       Multiply By       To Find       Symbol       Symbol       When You Know       Multiply By       To Find       Symbol       Symbol       When You Know       Multiply By       To Find       Symbol         ILENGTH       LENGTH         mm       millineters       0.039       inches       int <sup>2</sup> mm <sup>2</sup> square meters       1.09       yards       yd <sup>2</sup> m <sup>2</sup> square meters       <	fl	foot-Lamberts	3.426	candela/m <sup>2</sup>	cd/m <sup>2</sup>		
Ibf     poundforce     4.45     newtons     N       bif/in <sup>2</sup> poundforce per square inch     6.89     kilopascals     kPa       APPROXIMATE CONVERSIONS FROM SI UNITS       Symbol     When You Know     Multiply By     To Find     Symbol       Symbol     When You Know     Multiply By     To Find     Symbol       m     millimeters     0.039     inches     in       m     meters     3.28     feet     ft       m     meters     0.621     miles     mil       m <sup>2</sup> square millimeters     0.0016     square inches     in <sup>2</sup> m <sup>2</sup> square meters     10.764     square feet     ft <sup>2</sup> m <sup>2</sup> square meters     1.195     square gards     yd <sup>2</sup> m <sup>3</sup> square meters     0.386     square miles     mi <sup>2</sup> km <sup>3</sup> square kilometers     0.386     square miles     mi <sup>2</sup> m <sup>4</sup> square kilometers     0.034     fluid ounces     fl oz       L     ilters     0.264     galons     gal       m <sup>3</sup> cubic meters     35.314     cubic feet     ft <sup>3</sup> m <sup>3</sup> cubic meters     1.307     oubic feet     ft <sup>3</sup> <		FOR	CE and PRESSURE or S	STRESS			
Ibrin     poundrorce per square incn     b.89     kilopascals     kilopascals     krea       APPROXIMATE CONVERSIONS FROM SI UNITS       Symbol     When You Know     Multiply By     To Find     Symbol       mm     milimeters     0.039     inches     in       m     meters     3.28     feet     ft       m     meters     0.621     miles     miles       mm <sup>2</sup> square millimeters     0.0016     square inches     in <sup>2</sup> m <sup>2</sup> square meters     1.0764     square inches     in <sup>2</sup> m <sup>2</sup> square meters     1.0764     square grads     yd <sup>2</sup> ha     hectares     2.47     acces     ac       km <sup>2</sup> square meters     0.386     square miles     mi <sup>2</sup> Max     square kilometers     0.386     square miles     mi <sup>2</sup> Max     0.0264     gallons     gal       m <sup>3</sup> cubic meters     1.307     cubic feet     ft <sup>2</sup> m <sup>3</sup> cubic meters     1.307     cubic feet     ft <sup>2</sup> m <sup>3</sup> cubic meters     1.307     cubic feet     ft <sup>2</sup> g     grams     0.035     ources     oz       kg     kilograms     2.202 </td <td>lbf</td> <td>poundforce</td> <td>4.45</td> <td>newtons</td> <td>N</td>	lbf	poundforce	4.45	newtons	N		
APPROXIMATE CONVERSIONS FROM SI UNITS         Symbol       When You Know       Multiply By       To Find       Symbol         mm       millimeters       0.039       inches       in         m       meters       3.28       feet       ft         m       meters       1.09       yards       yd         km       kilometers       0.621       miles       miles         m <sup>2</sup> square millimeters       0.0016       square inches       ft <sup>2</sup> m <sup>2</sup> square meters       10.764       square feet       ft <sup>2</sup> m <sup>2</sup> square meters       1.195       square yards       yd <sup>2</sup> na       hectares       2.47       acres       ac         km <sup>2</sup> square kilometers       0.386       square miles       m <sup>2</sup> m <sup>3</sup> cubic meters       0.386       square miles       gal         m <sup>3</sup> cubic meters       0.264       galons       gal         m <sup>3</sup> cubic meters       1.307       cubic yards       yd <sup>3</sup> g       grams       0.035       ounces       oz         m <sup>3</sup> cubic meters       1.807       yd <sup>3</sup> jb </td <td>lbt/in<sup>-</sup></td> <td>poundforce per square inch</td> <td>6.89</td> <td>kilopascals</td> <td>kPa</td>	lbt/in <sup>-</sup>	poundforce per square inch	6.89	kilopascals	kPa		
SymbolWhen You KnowMultiply ByTo FindSymbolmmILENGTHmmmillimeters0.039inchesinfmmeters3.28feetftmmeters1.09yardsydkmkilometers0.621milesmilesmm²square millimeters0.0016square inchesin²m²square meters10.764square feetft²m²square meters1.95square yardsyd²m²square meters0.386square milesm²square kilometers0.386square milesm²square kilometers0.386square milesm²m1milliliters0.034fluid ouncesfl ozubic meters35.314cubic feetft²m³cubic meters35.314cubic yardsgalm³cubic meters35.314cubic yardsjbm³cubic meters1.307cubic yardsjbm³cubic meters2.202poundslbm³cubic meters1.8C+32Fahrenheitrem³cubic meters0.935ouncesozk (lograms0.202poundslbrem³cubic meters1.8C+32Fahrenheitrem³cubic meters1.8C+32Fahrenheitfcm³cubic meters1.8C+32Fahrenheitftm³cubic meters0.925poundfo	APPROXIMATE CONVERSIONS FROM SI UNITS						
LENGTHmmmillimeters0.039inchesinmmeters3.28feetftmmeters0.621milesmilesAREAmm²square millimeters0.0016square inchesin²m²square meters10.764square feetft²m²square meters10.764square feetft²m²square meters0.0016square milesyd²hahectares2.47accresacckm²square kilometers0.386square milesm²Netters0.034fluid ouncesflozLitlers0.034glonsgalm³cubic meters1.307cubic feetft²m³cubic meters1.307cubic spansyd³m³cubic meters1.307cubic spansjbggrams0.035ounceszcggrams0.035pundsjbMg (or "t")megagrams (or "metric tor")1.103short tons (2000 lb)TFEMPERATURE (exact degrees)°CCelsius1.8C+32Fahrenheit°FLLUMINATIONICelsiusfck²lux0.0929foot-candlesfcc/dm²i.8C+32poundforce per square inchlbf fin²c/dm²i.8c+32poundforce per square inchlbf fin²Supurificities tore tore t							
mmmillimeters0.039inchesinmmeters3.28feetftmmeters1.09yardsydkmkilometers0.621milesmilAREAmn²square millimeters0.0016square feetft²m²square meters10.764square feetft²m²square meters1.195square milesyd²hahectares2.47acresackm²square kilometers0.386square milesm²m²square kilometers0.384fluid ouncesfl ozkm²square kilometers0.334fluid ouncesfl ozkm²square stilometers0.034fluid ouncesfl ozLlitters0.264gallonsgalm³cubic meters1.307cubic feetft²m³cubic meters1.307cubic startsyd³tshort tons (2000 lb)TTyggrams0.035ouncesozMg (or "t")megagrams (or "metric ton")1.103short tons (2000 lb)TvcCcalealm²0.2919foot-candlesfccd/m²candela/m²0.2919foot-candlesfccd/m²kilopacals0.225poundforce per square inchlb/fin²% lis its extend for the laterational System of UnitsApropriate rounding should be made to comput with Section 4.04 ASTME780	Symbol	When You Know	Multiply By	To Find	Symbol		
m         meters         3.28         feet         ft           m         meters         1.09         yards         yd           km         kilometers         0.621         miles         mil           mm²         square milimeters         0.0016         square inches         in²           m²         square meters         10.764         square feet         ft²           m²         square meters         1.195         square geet         ft²           m²         square meters         1.195         square yards         yd²           ha         hectares         2.47         acres         acres         m²           square kilometers         0.386         square miles         m²         m²           square kilometers         0.386         square miles         m²           mL         milliliters         0.034         gallons         gal           m³         cubic meters         35.314         cubic feet         ft²           m³         cubic meters         2.202         pounds         lb           Mg (or "t")         megagrams (or "metric tor")         1.103         short tors (2000 lb)         T            candela/m²	Symbol	When You Know	Multiply By LENGTH	To Find	Symbol		
m         meters         1.09         yards         yd           km         kilometers         0.621         miles         mil           mm²         square millimeters         0.0016         square inches         in²           m²         square meters         10.764         square feet         ft²           m²         square meters         1.195         square yards         yd²           ha         hectares         2.47         acres         ac           km²         square kilometers         0.386         square miles         mi²           m²         square kilometers         0.386         square miles         mi²           m         square kilometers         0.386         square miles         mi²           m1         milliiters         0.034         fluid ounces         floz           L         liters         0.0264         gallons         gal           m³         cubic meters         1.307         cubic yards         yd³           m³         cubic meters         2.202         pounds         lb           Mg (or "t")         megagrams (or "metric ton")         1.103         short tons (2000 lb)         T           Mg (or "t")	Symbol mm	When You Know millimeters	Multiply By LENGTH 0.039	To Find inches	<b>Symbol</b>		
NmNumerics0.021milesmileAREAmm²square millimeters0.0016square inchesin²m²square meters10.764square jardsyd²m²square meters1.195square yardsyd²hahectaresacm²square meters1.195square yardsyd²hahectares2.47acresackm²square kilometers0.386square milesmi²m1milliliters0.034fluid ouncesfl colm3cubic meters0.264galonsgalm3cubic meters0.264galonsgalomsggrams0.035ouncescubic metersggrams0.035ouncesozggrams0.035ouncesozMASS2.202poundsbibMg (or "t")negagams (or "metric ton")1.103short tons (2000 lb)TFLEUUMINATIONkl	Symbol mm m	When You Know millimeters meters	Multiply By LENGTH 0.039 3.28	To Find inches feet	Symbol		
ARCEAmm²square millimeters0.0016square inchesin²m²square meters10.764square feetft²m²square meters1.195square yardsyd²hahectares2.47acresackm²square kilometers0.386square milesm²VOLUMEmlmilliliters0.034fluid ouncesfl ozLlitters0.034gallonsgalm³cubic meters35.314cubic feetft³cubic meters35.314cubic feetft³m³cubic meters1.307cubic yardsyd³MASSggrams0.035ouncesozkgkliograms2.202poundslbMg (or "t")megagrams (or "metric tor")1.103short tons (2000 lb)TTEMPERATURE (exact degrees)°CCelsius1.8C+32Fahrenheit°FILLUMINATIONkglux0.0929foot-candlesfccondela/m²0.225poundforce per square inchlbfNnewtons0.225poundforce per square inchlbf/in²Si is the symbol for the International System of Linits. Appropriate round ing should be made to complue with Section 4 of ASIMEGED	mm m m	When You Know millimeters meters meters	Multiply By LENGTH 0.039 3.28 1.09 0.651	To Find inches feet yards milee	Symbol in ft yd		
Inim     square meters     0.0016     square fieldes     Initial fieldes       m <sup>2</sup> square meters     10.764     square feet     ff       m <sup>2</sup> square meters     1.195     square yards     yd <sup>2</sup> ha     hectares     2.47     acres     ac       km <sup>2</sup> square kilometers     0.386     square miles     m <sup>2</sup> ML     milliliters     0.034     fluid ounces     fl oz       L     liters     0.264     gallons     gal       m <sup>3</sup> cubic meters     35.314     cubic feet     ft <sup>3</sup> m <sup>3</sup> cubic meters     1.307     cubic yards     yd <sup>3</sup> FEMPERATURE (exact degrees)       g     grams     0.035     ounces     oz       kg     kilograms     2.202     pounds     lb       Mg (or "t")     megagrams (or "metric tor")     1.103     short tons (2000 lb)     T       °C     Celsius     1.8C+32     Fahrenheit     °F       ILLUMINATION       kx     lux     0.0929     foot-candles     fc       cd/m <sup>2</sup> candela/m <sup>2</sup> 0.2919     foot-candles     fl       FORCE and PRESSURE or STRESS       N     newtons     0.225 </td <td>Symbol mm m km</td> <td>When You Know millimeters meters meters kilometers</td> <td>Multiply By LENGTH 0.039 3.28 1.09 0.621 ABEA</td> <td>To Find inches feet yards miles</td> <td>in ft yd mi</td>	Symbol mm m km	When You Know millimeters meters meters kilometers	Multiply By LENGTH 0.039 3.28 1.09 0.621 ABEA	To Find inches feet yards miles	in ft yd mi		
m²     square meters     10.767     square varies     107       m²     square meters     1195     square varies     yd²       ha     hectares     2.47     acres     ac       km²     square kilometers     0.386     square miles     mi²       mL     milliliters     0.034     fluid ounces     fl oz       L     liters     0.264     gallons     gal       m³     cubic meters     35.314     cubic feet     ft³       m³     cubic meters     1.307     cubic yards     yd³       MASS       g     grams     0.035     ounces     oz       kg     kilograms     2.202     pounds     lb       Mg (or "t")     megagrams (or "metric ton")     1.103     short tons (2000 lb)     T       ILLUMINATION       VCE and PRESSURE or STRESS       N     newtons     0.225     poundforce     lbf       IS is the sympler to the thermational System of Units. Appropriate rounding should be mede to comply with Section 4 of ASTME F80	Symbol mm m km	When You Know millimeters meters kilometers	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016	To Find inches feet yards miles	Symbol in ft yd mi		
ha hectares 2.47 acres ac km <sup>2</sup> square kilometers 0.386 square miles mi <sup>2</sup> mL milliliters 0.034 fluid ounces fl oz L liters 0.264 gallons gal m <sup>3</sup> cubic meters 35.314 cubic feet ft <sup>3</sup> m <sup>3</sup> cubic meters 1.307 cubic yards yd <sup>3</sup>	Symbol mm m km m <sup>2</sup> m <sup>2</sup>	When You Know millimeters meters kilometers square millimeters square meters	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764	To Find inches feet yards miles square inches square feet	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup>		
km²         square kilometers         0.386         square miles         mi²           mL         milliliters         0.034         fluid ounces         fl oz           L         liters         0.264         gallons         gal           m³         cubic meters         35.314         cubic feet         fl³           m³         cubic meters         1.307         cubic syards         yd³           MASS           g         grams         0.035         ounces         oz           kg         kilograms         2.202         pounds         lb           Mg (or "t")         megagrams (or "metric ton")         1.103         short tons (2000 lb)         T           °C         Celsius         1.8C+32         Fahrenheit         °F           °C         Celsius         1.8C+32         Fahrenheit         °F           LLUMINATION         Lux         0.0929         foot-candles         fc           cd/m²         0.2919         foot-candles         fl           Ka         newtons         0.225         poundforce per square inch         lbf           KPa         kilopascals         0.145         poundforce per square inch         lbf/in² </td <td>Symbol mm m km m<sup>2</sup> m<sup>2</sup> m<sup>2</sup></td> <td>When You Know millimeters meters kilometers square millimeters square meters square meters</td> <td>Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195</td> <td>To Find inches feet yards miles square inches square feet square yards</td> <td>Symbol in ft yd mi in<sup>2</sup> ft<sup>2</sup> vd<sup>2</sup></td>	Symbol mm m km m <sup>2</sup> m <sup>2</sup> m <sup>2</sup>	When You Know millimeters meters kilometers square millimeters square meters square meters	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195	To Find inches feet yards miles square inches square feet square yards	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> vd <sup>2</sup>		
VOLUME         mL       milliliters       0.034       fluid ounces       fl oz         L       liters       0.264       gallons       gal         m³       cubic meters       35.314       cubic feet       ft³         m³       cubic meters       1.307       cubic yards       yd³         MASS         g       grams       0.035       ounces       oz         kg       kilograms       2.202       pounds       lb         Mg (or "t")       megagrams (or "metric ton")       1.103       short tons (2000 lb)       T         °C       Celsius       1.8C+32       Fahrenheit       °F         °C       Celsius       1.8C+32       Fahrenheit       °F         LLUMINATION       ILLUMINATION       I       I       I       I         k       lux       0.0929       foot-candles       fc         cd/m²       0.2219       foot-Lamberts       fl         N       newtons       0.2225       poundforce per square inch       lbf         kPa       kilopascals       0.145       poundforce per square inch       lbf	Symbol mm m km m <sup>2</sup> m <sup>2</sup> ha	When You Know millimeters meters kilometers square millimeters square meters square meters hectares	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47	To Find inches feet yards miles square inches square feet square yards acres	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac		
mL     milliliters     0.034     fluid ounces     fl oz       L     liters     0.264     gallons     gal       m³     cubic meters     35.314     cubic feet     ft³       m³     cubic meters     1.307     cubic yards     yd³       m³     cubic meters     1.307     cubic yards     yd³       m³     cubic meters     1.307     cubic yards     yd³       MASS       g     grams     0.035     ounces     oz       kg     kilograms     2.202     pounds     lb       Mg (or "t")     megagrams (or "metric ton")     1.103     short tons (2000 lb)     T       %C     Celsius     1.8C+32     Fahrenheit     °F       ILLUMINATION       lx     lux     0.0929     foot-candles     fc       cd/m²     0.2919     foot-Lamberts     fl       FORCE and PRESSURE or STRESS       N     newtons     0.225     poundforce per square inch     lbf       klopascals     0.145     poundforce per square inch     lbf/in²	Symbol mm m km km m <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup>	When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square kilometers	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386	To Find inches feet yards miles square inches square feet square yards acres square miles	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup>		
L liters 0.264 gallons gal m <sup>3</sup> cubic meters 35.314 cubic feet ft <sup>3</sup> m <sup>3</sup> cubic meters 1.307 cubic yards yd <sup>3</sup> MASS g grams 0.035 ounces oz kg kilograms 2.202 pounds lb Mg (or "t") megagrams (or "metric ton") 1.103 short tons (2000 lb) T Mg (or "t") megagrams (or "metric ton") 1.103 short tons (2000 lb) T <sup>o</sup> C Celsius 1.8C+32 Fahrenheit °F Celsius 1.8C+32 Fahrenheit °F ILLUMINATION k lux 0.0929 foot-candles fc cd/m <sup>2</sup> 0.2919 foot-Lamberts fl FORCE and PRESSURE or STRESS N newtons 0.225 poundforce per square inch lbf/in <sup>2</sup>	Symbol mm m km mm <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup>	When You Know millimeters meters kilometers square millimeters square meters square meters hectares square kilometers	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME	To Find inches feet yards miles square inches square feet square yards acres square miles	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup>		
m <sup>2</sup> cubic meters     35.314     cubic teet     ft <sup>2</sup> m <sup>3</sup> cubic meters     1.307     cubic yards     yd <sup>3</sup> MASS       g     grams     0.035     ounces     oz       kg     kilograms     2.202     pounds     lb       Mg (or "t")     megagrams (or "metric ton")     1.103     short tons (2000 lb)     T       TEMPERATURE (exact degrees)       °C     Celsius     1.8C+32     Fahrenheit     °F       ILLUMINATION       lx     lux     0.0929     foot-candles     fc       cd/m <sup>2</sup> candela/m <sup>2</sup> 0.2919     foot-Lamberts     fl       FORCE and PRESSURE or STRESS       N     newtons     0.225     poundforce     lbf       kPa     kilopascals     0.145     poundforce per square inch     lbf/in <sup>2</sup>	Symbol mm mkm km mm <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> mL	When You Know millimeters meters kilometers square millimeters square meters square meters hectares square kilometers milliliters	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz		
Init     Cubic filterers     I.SO/     Cubic yards     yd       MASS       g     grams     0.035     ounces     oz       kg     kilograms     2.202     pounds     lb       Mg (or "t")     megagrams (or "metric ton")     1.103     short tons (2000 lb)     T       °C     Celsius     1.8C+32     Fahrenheit     °F       ILLUMINATION       lx     lux     0.0929     foot-candles     fc       cd/m²     candela/m²     0.2919     foot-Lamberts     fl       FORCE and PRESSURE or STRESS       N     newtons     0.225     poundforce per square inch     lbf/in²       *St is the symbol for the International System of Units. Appropriate rounding should be made to comply with Section 4 of ASTME F380	Symbol mm m km m <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> mL	When You Know millimeters meters kilometers square millimeters square meters square meters hectares square kilometers milliliters	Multiply By  LENGTH  0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces gallons	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal		
g     grams     0.035     ounces     oz       kg     kilograms     2.202     pounds     lb       Mg (or "\")     megagrams (or "metric ton")     1.103     short tons (2000 lb)     T       °C     Celsius     1.8C+32     Fahrenheit     °F       ILLUMINATION       lx     lux     0.0929     foot-candles     fc       cd/m²     candela/m²     0.2919     foot-candles     fl       FORCE and PRESSURE or STRESS       N     newtons     0.225     poundforce per square inch     lbf       kPa     kilopascals     0.145     poundforce per square inch     lbf/in²	Symbol mm m km m <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> mL L m <sup>3</sup> m <sup>3</sup>	When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square kilometers milliliters liters cubic meters	Multiply By  LENGTH  0.039  3.28  1.09  0.621  AREA  0.0016  10.764  1.195  2.47  0.386  VOLUME  0.034  0.264  35.314  4.307	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces gallons cubic feet	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal ft <sup>3</sup> vd <sup>3</sup>		
y     grams     0.035     ounces     02       kg     kilograms     2.202     pounds     lb       Mg (or "t")     megagrams (or "metric ton")     1.103     short tons (2000 lb)     T       TEMPERATURE (exact degrees)       °C     Celsius     1.8C+32     Fahrenheit     °F       LLUMINATION     ILLUMINATION     fc       lx     lux     0.0929     foot-candles     fc       cd/m²     candela/m²     0.2919     foot-Lamberts     fl       FORCE and PRESSURE or STRESS       N     newtons     0.225     poundforce per square inch     lbf/in²       %Is the symbol for the International System of Units. Appropriate rounding should be made to comply with Section 4 of ASTM E380	Symbol mm m km m <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> mL L m <sup>3</sup> m <sup>3</sup>	When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square kilometers milliliters liters cubic meters cubic meters	Multiply By  LENGTH  0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces gallons cubic feet cubic yards	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal ft <sup>3</sup> yd <sup>3</sup>		
Ng (or "t")     megagrams (or "metric ton")     1.103     short tons (2000 lb)     T       TEMPERATURE (exact degrees)       °C     Celsius     1.8C+32     Fahrenheit     °F       ILLUMINATION     ILLUMINATION       lx     lux     0.0929     foot-candles     fc       cd/m²     candela/m²     0.2919     foot-candles     fl       FORCE and PRESSURE or STRESS       N     newtons     0.225     poundforce per square inch     lbf/in²       St is the symbol for the International System of Units     Appropriate rounding should be made to comply with Section 4 of ASTM E380	Symbol mm m km m <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> mL L m <sup>3</sup> m <sup>3</sup>	When You Know millimeters meters meters kilometers square millimeters square meters hectares square kilometers milliliters liters cubic meters cubic meters	Multiply By  LENGTH  0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.025	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces gallons cubic feet cubic yards	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal ft <sup>3</sup> yd <sup>3</sup>		
TEMPERATURE (exact degrees)         °C       Celsius       1.8C+32       Fahrenheit       °F         ILLUMINATION       ILLUMINATION         Ix       lux       0.0929       foot-candles       fc         cd/m²       candela/m²       0.2919       foot-candles       fl         FORCE and PRESSURE or STRESS         N       newtons       0.225       poundforce       lbf         kPa       kilopascals       0.145       poundforce per square inch       lbf/in²	Symbol mm m km m <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> m km <sup>2</sup> g ka	When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square kilometers milliliters liters cubic meters cubic meters grams kilograms	Multiply By           LENGTH           0.039           3.28           1.09           0.621           AREA           0.0016           10.764           1.195           2.47           0.386           VOLUME           0.034           0.264           35.314           1.307           MASS           0.035           2.202	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces gallons cubic feet cubic yards ounces pounds	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal ft <sup>3</sup> yd <sup>3</sup> oz lb		
°C     Celsius     1.8C+32     Fahrenheit     °F       ILLUMINATION       Ix     lux     0.0929     foot-candles     fc       cd/m²     candela/m²     0.2919     foot-Lamberts     fl       FORCE and PRESSURE or STRESS       N     newtons     0.225     poundforce     lbf       kPa     kilopascals     0.145     poundforce per square inch     lbf/in²	Symbol mm m km m <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> mL L mL L m <sup>3</sup> m <sup>3</sup> m <sup>3</sup>	When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square kilometers milliliters liters cubic meters cubic meters grams kilograms megagrams (or "metric ton")	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces gallons cubic feet cubic feet cubic yards ounces pounds short tons (2000 lb)	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal ft <sup>3</sup> yd <sup>3</sup> oz lb T		
ILLUMINATION         Ix       lux       0.0929       foot-candles       fc         cd/m²       candela/m²       0.2919       foot-Lamberts       fl         FORCE and PRESSURE or STRESS         N       newtons       0.225       poundforce       Ibf         kPa       kilopascals       0.145       poundforce per square inch       Ibf/in²	Symbol mm mkm km <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> km <sup>2</sup> kg kg kg (or "t")	When You Know millimeters meters kilometers square millimeters square meters square meters hectares square kilometers milliliters liters cubic meters cubic meters grams kilograms megagrams (or "metric ton")	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact dec	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces gallons cubic feet cubic yards ounces pounds short tons (2000 lb) gares	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal ft <sup>3</sup> yd <sup>3</sup> oz lb T		
Ix     Iux     0.0929     foot-candles     fc       cd/m²     candela/m²     0.2919     foot-Lamberts     fl       FORCE and PRESSURE or STRESS       N     newtons     0.225     poundforce     lbf       kPa     kilopascals     0.145     poundforce per square inch     lbf/in²	Symbol mm mkm km mm <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> km <sup>2</sup> kg Mg (or "t")	When You Know millimeters meters kilometers square millimeters square meters square meters hectares square kilometers milliliters liters cubic meters cubic meters grams kilograms megagrams (or "metric ton") Celsius	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact deg 1.8C+32	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces gallons cubic feet cubic yards ounces pounds short tons (2000 lb) grees) Fahrenheit	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal ft <sup>3</sup> yd <sup>3</sup> oz lb T °F		
cd/m²     candela/m²     0.2919     foot-Lamberts     fl       FORCE and PRESSURE or STRESS       N     newtons     0.225     poundforce     Ibf       kPa     kilopascals     0.145     poundforce per square inch     Ibf/in²	Symbol mm mkm km <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> km <sup>2</sup> g kg Mg (or "t")	When You Know millimeters meters kilometers square millimeters square meters square meters hectares square kilometers milliliters liters cubic meters cubic meters grams kilograms megagrams (or "metric ton") TE Celsius	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact deg 1.8C+32 ILLUMINATION	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces gallons cubic feet cubic yards ounces pounds short tons (2000 lb) grees) Fahrenheit	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal ft <sup>3</sup> yd <sup>3</sup> oz lb T °F		
FORCE and PRESSURE or STRESS           N         newtons         0.225         poundforce         Ibf           kPa         kilopascals         0.145         poundforce per square inch         Ibf/in <sup>2</sup> *SI is the symbol for the International System of Units         Appropriate rounding should be made to comply with Section 4 of ASTM E380	Symbol mm mkm km mm <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> mL L mL m <sup>3</sup> m <sup>3</sup> m <sup>3</sup> m <sup>3</sup> c	When You Know millimeters meters kilometers square millimeters square meters square meters hectares square kilometers milliliters liters cubic meters cubic meters grams kilograms megagrams (or "metric ton") TE Celsius lux	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact deg 1.8C+32 ILLUMINATION 0.0929	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces gallons cubic feet cubic yards ounces pounds short tons (2000 lb) grees) Fahrenheit foot-candles	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal ft <sup>3</sup> yd <sup>3</sup> oz lb T °F fc		
N     newtons     0.225     poundforce     Ibf       kPa     kilopascals     0.145     poundforce per square inch     Ibf/in <sup>2</sup>	Symbol mm mkm km mm <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> mL L m <sup>3</sup> m <sup>3</sup> m <sup>3</sup> m <sup>3</sup> c lx cd/m <sup>2</sup>	When You Know millimeters meters kilometers square millimeters square meters square meters hectares square kilometers milliliters liters cubic meters cubic meters grams kilograms megagrams (or "metric ton") TE Celsius lux candela/m <sup>2</sup>	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact deg 1.8C+32 ILLUMINATION 0.0929 0.2919	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces gallons cubic feet cubic feet cubic yards ounces pounds short tons (2000 lb) grees) Fahrenheit foot-candles foot-Lamberts	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal ft <sup>3</sup> yd <sup>3</sup> oz lb T °F fc fl		
kPa     kilopascals     0.145     poundforce per square inch     Ibf/in <sup>2</sup> SL is the symbol for the International System of Units     Appropriate rounding should be made to comply with Section 4 of ASTM E380	Symbol mm mkm km mm <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> mL L m <sup>3</sup> m <sup>3</sup> m <sup>3</sup> c lx cd/m <sup>2</sup>	When You Know millimeters meters kilometers square millimeters square meters square meters hectares square kilometers milliliters liters cubic meters cubic meters grams kilograms megagrams (or "metric ton") TE Celsius lux candela/m <sup>2</sup>	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact deg 1.8C+32 ILLUMINATION 0.0929 0.2919 CCE and PRESSURE or S	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces gallons cubic feet cubic yards ounces pounds short tons (2000 lb) grees) Fahrenheit foot-candles foot-Lamberts	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal ft <sup>3</sup> yd <sup>3</sup> oz lb T °F fc fl		
SI is the symbol for the International System of Units. Appropriate rounding should be made to comply with Section 4 of ASTM E380	Symbol mm mkm km m <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> c kg Mg (or "t") °C k cd/m <sup>2</sup>	When You Know millimeters meters kilometers square millimeters square meters square meters hectares square kilometers milliliters liters cubic meters cubic meters cubic meters grams kilograms megagrams (or "metric ton") TE Celsius lux candela/m <sup>2</sup> FOR	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact deg 1.8C+32 ILLUMINATION 0.0929 0.2919 CCE and PRESSURE or S 0.225	To Find inches feet yards miles square inches square feet square yards acres square miles fluid ounces gallons cubic feet cubic yards ounces pounds short tons (2000 lb) grees) Fahrenheit foot-candles foot-Lamberts STRESS poundforce	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal ft <sup>3</sup> yd <sup>3</sup> oz lb T °F fc fl lbf		
should be made to comply with bedien of Ability of the source of the sou	Symbol mm mkm km <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> km <sup>2</sup> m <sup>2</sup> ha km <sup>2</sup> km <sup>2</sup> k	When You Know         millimeters         meters         meters         kilometers         square millimeters         square meters         square meters         hectares         square kilometers         milliliters         liters         cubic meters         grams         kilograms         megagrams (or "metric ton")         Te         Celsius         lux         candela/m²         FOR         newtons         kilopascals	Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact deg 1.8C+32 ILLUMINATION 0.0929 0.2919 CCE and PRESSURE or S 0.225 0.145	To Find         inches         feet         yards         miles         square inches         square feet         square yards         acres         square miles         fluid ounces         gallons         cubic feet         cubic yards         ounces         pounds         short tons (2000 lb)         grees)         Fahrenheit         foot-candles         foot-Lamberts         STRESS         poundforce         poundforce per square inch	Symbol in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac mi <sup>2</sup> fl oz gal ft <sup>3</sup> yd <sup>3</sup> oz lb T °F fc fl lbf lbf/in <sup>2</sup>		

# SI\* (MODERN METRIC) CONVERSION FACTORS

## TABLE OF CONTENTS

Acknowledgments	viii
Executive Summary	ix
CHAPTER 1.PROJECT MOTIVATION AND BACKGROUND	1
1.1. Introduction and Background	1
1.2. Research Approach	2
CHAPTER 2.METHODOLOGY	5
2.1. Literature Review	5
2.2. Schmidt Hammer Testing Procedure	7
2.3. Unconfined Compressive Strength (UCS) Testing	9
2.3.1. Sample Collection and Preparation	9
2.3.2. Testing Procedure	11
CHAPTER 3.RESULTS	13
3.1. Schmidt Hammer (SH) Data	13
3.2. UCS Testing Results	13
CHAPTER 4. SUMMARY AND PROS AND CONS OF THE SCHMIDT HAMMER	17
CHAPTER 5.REFERENCES	21

## LIST OF FIGURES

Figure 1.1 Field sites for lidar data collection and rock slope characterization	.3
Figure 2.1 Examples of Schmidt hammer (SH) testing locations	.8
Figure 2.2 View of rock specimens (within yellow ellipse) transported in the back of a pick-up	
truck for strength testing	.9
Figure 2.3 Images of (a) cylindrical and (b) prism samples before strength testing	10
Figure 2.4 Examples of the LL71 mudstone behavior during sample preparation	1
Figure 2.5 Cylindrical rock sample loaded into the UCS testing machine	2

## LIST OF TABLES

Table 2.1 Summary of Schmidt Hammer testing sites	8
Table 3.1 Summary of SH results and moisture content for all field sites.	14
Table 3.2 Summary of results from the UCS tests.	15

## ACKNOWLEDGMENTS

Our team would like to acknowledge the time and efforts of Dr. Matt Bray, Matthew Encelewski, and Drs. Michael Olsen, Joe Wartman, and Ben Leshchinsky of the "RAI of Data" research team.

#### **EXECUTIVE SUMMARY**

The Schmidt hammer is a widely used and inexpensive instrument for estimating rock strength either in the lab or in the field. This indirect testing method can provide rock strength information without destroying the sample like other testing procedures (e.g., unconfined compressive strength (UCS) testing). In collaboration with another PacTrans-funded project (Darrow et al. *In Review*), our research team tested the accuracy and repeatability of the Schmidt hammer to estimate rock strength on six Alaskan rock slopes and four Washington/Oregon rock slopes, all sites of long-term data collection and rockfall analysis. For this project, we 1) determined *in situ* rock hardness and weathering conditions at field sites using two different Schmidt hammers (Types L and N); 2) conducted a comprehensive literature review of up-to-date analyses of strength testing using the Schmidt hammer; 3) conducted UCS testing for select Alaskan rock samples; 4) performed a preliminary statistical analysis of Schmidt hammer results as they relate to varying lithology; and 5) summarized the pros and cons of using the Schmidt hammer in the field.

Our literature review identified several parameters that potentially affect Schmidt hammer results, including testing methodology, sample testing conditions, and data reduction. All of these parameters affect the rebound values' correlation to UCS values. Our results indicated that major structures within a rock unit (such as bedding or foliation), variation in mineralogy, and moisture content will significantly affect Schmidt hammer results. After data collection, several correction methods can be used to process the Schmidt hammer results. The choice of method depends on the intent of the measurements (i.e., strength of the intact rock or the rock mass), and the application of any method can alter the final results.

At the Alaska sites, we collected large rock samples representative of each major lithology from each slope for strength testing. Here we present the UCS results of six of the rock types. The UCS results generally correlated to the Schmidt hammer rebound values (e.g., rock types with high rebound values also had high UCS values).

Based on this research, we suggest considering the following before using the Schmidt hammer:

• The selection of Schmidt hammer type is up to the user. The N-Type is potentially a better candidate for general use because of lower scatter in its results.

- Determine the final goal before using the Schmidt hammer and selecting a testing methodology (i.e., acquiring results representative of the rock mass or the intact rock).
- Before recording any values, identify the rock type and determine potential bedding, foliation, persistent jointing, faults, etc. that can influence results at the testing location.
- Differences in testing environments, for example in the field on *in situ* rock versus in the lab on large samples, may affect results as a result of the bias of sample selection.
- Select the most applicable data reduction method for the Schmidt hammer results. The method used will change the final averaged rebound results.

This report is the initial summary of our results. A comprehensive analysis, including the remaining UCS testing, comparison to point load tests and Schmidt hammer tests on lab samples, and the effect of proximity to discontinuities on Schmidt hammer field measurements, will be included in the first author's Master's thesis.

#### **CHAPTER 1. PROJECT MOTIVATION AND BACKGROUND**

#### 1.1. Introduction and Background

Slopes pose a significant hazard to transportation infrastructure and mobility across the Pacific Northwest (PNW) because of the combination of the region's geology, topography, high precipitation rates, and seismicity. Rockfall hazards result in frequent road closures, lane restrictions, infrastructure damage, loss of life, and injuries to motorists, cyclists, and pedestrians. Thus, rockfall directly affects driver safety, mobility, and accessibility for many critical lifelines. Recent PacTrans-supported research by Holtan (2021) documented the significant mobility and economic impacts that rockfall has on major roads across the PNW, including road closures for a month or more and emergency repair costs of over \$1 million for large events.

The authors are part of a research team that received PacTrans support in 2020 to modify the rockfall activity index (RAI) to account for rockfall attenuation after earthquakes (Darrow et al. 2022). The RAI can be used as a tool by engineers to understand the relative risk between rock slopes, and which slopes are best-suited for mitigation. The team assessed the efficacy, accuracy, and reliability of the RAI methodology and concluded that the automated morphological mapping is highly reliable but that the activity rates for the morphological classes vary more widely than initially estimated by Dunham et al. (2017). These activity rates, which quantify the "activity "or instability rate of the morphological classes, directly control the RAI mapping of rockfall "hotspots." Our verification and accuracy studies of the RAI suggested that the activity rates are not always consistent, generic values, but instead they vary as a function of geology and rock material properties (e.g., well-indurated, freshly weathered crystalline rocks are less active than softer fine-grained rocks such as siltstones), as well as local climate conditions. In 2021, our research team received additional PacTrans support to improve and refine both the accuracy and the interpretation of the RAI analysis to promote its wider adoption by transportation authorities and consulting engineers in the PNW and across the nation (project title - "A RAI of Data: Generalizing the Data-Driven Rockfall Activity Index (RAI) Based on Long-Term Observations of Well Characterized Slopes," hereafter referred to as "A RAI of Data" (Darrow et al. - In Review)). One element of the "A RAI of Data" project was to modify the procedure to estimate the RAI activity rate based on *in situ* rock strength testing with a Schmidt hammer. The Schmidt hammer is a well-established, widely adopted (Aydin and Basu 2005;

Wang and Wan 2019), and easy-to-use field instrument for assessing rock strength in the field. This "Hammer Time" research (presented here) complements the funded "A RAI of Data" project by measuring the accuracy and repeatability of Schmidt hammer data to determine rock strength and weathering conditions, using sites in Alaska, Washington, and Oregon as case studies; the results complement the RAI procedure to conduct "hotspot" mapping, thus improving the accuracy of the RAI methodology. This research represents a key component of the lead author's Master's thesis.

#### 1.2. Research Approach

Here we detail results from Alaska, Washington, and Oregon sites, where we tested the accuracy and repeatability of Schmidt hammer data to determine rock strength and weathering conditions. The following is a summary of the project tasks.

**Task 1:** We determined *in situ* rock strength and weathering conditions for Alaska and Washington/Oregon field sites. The selected project areas were the sites of long-term, PacTransfunded data collection in Alaska (along the Parks Highway near the Nenana River Canyon and the Long Lake area of the Glenn Highway; see Figure 1.1) and four project areas in Washington and Oregon (Hewett Lake, Washington (State Route 14); Eddyville, Oregon (US Route 20); Yellow Creek, Oregon (State Highway 138); and Canyonville, Oregon (Interstate 5); see Figure 1.1). We included a comprehensive literature review of up-to-date analyses of strength testing with the Schmidt hammer, identifying knowledge gaps evident from the literature, and described the methodology used in the field.

**Task 2:** We conducted unconfined compressive strength (UCS) tests on selected Alaskan rock samples. As this project represents part of a Master's thesis, these tests are ongoing; results presented here are preliminary.

**Task 3:** We performed a preliminary statistical analysis of the Schmidt hammer results as related to lithology and rock slope classifications. Natural rock is inherently variable, with differences in mineralogy, grain size, microfractures, alteration, and weathering. Depending on its porosity, it also may vary as a result of environmental conditions, such as moisture content. All of these differences were reflected in the variability of the Schmidt hammer results, described through a brief statistical analysis.

**Task 4:** We summarized the advantages and disadvantages of using the Schmidt hammer in the field, identifying any major concerns with this method. This summary, based on a

comprehensive case study of multiple sites from two vastly different parts of the PNW, provides practitioners with a practical guide to employ this test method as part of the RAI approach.



Figure 1.1 Field sites for lidar data collection and rock slope characterization. (a) ALASKA FIELD SITES: Examples of Nenana Canyon area, Parks Highway (left), and Long Lake area, Glenn Highway (right);

(b) WASHINGTON/OREGON FIELD SITES: counterclockwise from middle right – Hewett Lake, Washington (State Route 14); Eddyville, Oregon (U.S. Route 20); Yellow Creek, Oregon (State Highway 138); Canyonville, Oregon (Interstate 5).

In both map views, blue lines represent major roadways in each state; note that (a) is only a portion of Alaska. Base map imagery from ADOT&PF (2020), AGC (2020), OGEO (2023a and b), WA DNR (2023a and b).

#### **CHAPTER 2. METHODOLOGY**

#### 2.1. Literature Review

The Schmidt hammer is a widely used and inexpensive field instrument for quickly estimating rock strength both in the lab and in the field. It is considered an indirect method able to determine rock hardness without destroying the rock sample. There are two types of Schmidt hammers used specifically for rock: N-Type with an impact energy of 2.207 Nm (1.63 ft-lbf) and L-type with an impact energy of 0.735 Nm (0.54 ft-lbf). The Schmidt hammer contains a spring-loaded piston that automatically releases as the plunger is pressed orthogonally against a surface. The impact energy from the piston rebounds through the surface material. Hard materials have a high return measurement, i.e., the piston height after impact, called a rebound value (R). This value is an indication of material hardness, which is correlated to the unconfined compressive strength (UCS).

Our literature review highlighted several aspects of Schmidt hammer testing that need further evaluation. Identified parameters that can affect Schmidt hammer results include testing methodology, sample testing conditions, and data reduction. All of these parameters affect correlation to UCS values. Because there are two types of Schmidt hammers, determining potential variances between them is important because this will inform which hammer is used for a specific rock type. The literature contains differing recommendations for which hammer type is best for rock strength testing. The IRSM (1978) suggested using an L-Type hammer, while the ASTM (ASTM International 2014) did not specify. Aydin and Basu (2005) suggested that using the N-Type hammer will reduce scatter because of its higher impact strength. The rock strength threshold for each hammer is not strictly defined, leading to ambiguity about which device to use. Both hammers can be used to estimate rock strength, but the L-Type may be more accurate for weaker rock (UCS < 10 MPa) whereas the N-Type is more accurate for harder rock (UCS >10-250 MPa) (Aydin and Basu 2005). Additionally, strict rules have not been established for how many readings are necessary to capture a representative R value. The number of impacts at the testing site can alter measurements and introduce scatter. According to Hucka (1965) and Poole and Farmer (1980), multiple impacts in one spot are more consistent, but Aydin and Basu (2005) indicated that the readings likely represent an altered state of the rock as a result of compaction of the rock surface. One impact can be more representative, but potentially less consistent.

Rock is a heterogeneous material with inherent anisotropy due to varied mineral composition and crystalline structure. Major structures within a rock unit, such as bedding or foliation, can significantly alter the R value, depending on impact orientation. To eliminate some of these variables, researchers conducted Schmidt hammer testing on lab core samples rather than in situ rock surfaces (e.g., Aydin and Basu 2005; Wang and Wan 2019), since different testing environments can affect measured rebound values. As indicated by ASTM D5873-14 (ASTM International 2014), lab samples are intact rock specimens free of the major discontinuities, weathering, and alteration that may weaken a natural rock face in the field. Additionally, lab core samples provide a smooth testing surface, eliminating asperities or irregularities that reduce the resulting measurement as a result of energy loss on impact (Aydin and Basu 2005; ASTM International 2014; Wang and Wan 2019). Testing on an *in situ* rock surface may be affected by those variations in the rock mass. Proximity to sample boundaries in the lab and to discontinuities in the field cause low R values (IRSM 1978; ASTM International 2014). Even discontinuities invisible below the surface can reduce R values by dissipating energy and introducing scatter. The IRSM (1978) suggested testing 6 cm (2.36 in.) from the sample edge and major discontinuities, whereas ASTM International (2014) suggested a 15-cm (5.91-in.) distance from the sample edge and 6 cm (2.36 in.) from major discontinuities. Weathering also alters the R value, especially in rock types with coarse-grained minerals as a result of different weathering susceptibilities (Aydin and Basu 2005). Moisture content is another parameter that can vary significantly between lab and field settings. When the moisture content is higher, the rock's compressive strength is lower because of an increase in pore water pressure (Liu et al. 2011).

Data reduction methods to determine a representative R value vary depending on the intention of the study; the strength value can be representative of the intact rock or of the rock mass. The IRSM (1978) recommended averaging the upper 50 percent of 20 single impact readings. ASTM International (2014) suggested taking ten impacts, averaging those ten readings, removing the R values that differ from the average by 7 or more, and then averaging the remaining values. Shorey et al. (1984) recommended taking the lower mean of averaged values, whereas Amaral et al. (1999) recommended taking all values into account. The data reduction method can alter the results significantly, changing the estimated rock strength. The R value by itself can be used as an index of rock hardness, but in most studies, the R values were converted

to UCS through empirical relationships. There is a wide range of empirical formulas, but there is no one universal formula; instead, each is for a specific rock type / strength, hammer type, and R value. Aydin and Basu (2005) provided a summary of empirical formulas, relevant lithologies, rock strength, and R value ranges from several sources.

#### 2.2. Schmidt Hammer Testing Procedure

Before going to the field, we calibrated each hammer by using a Silver Schmidt Calibration Anvil as per the manufacturer's specifications (Proceq 2017). Following the Rock Schmidt Rebound Hammer calibration procedure, ten hits on the anvil per hammer type were performed and then averaged. The average value for each hammer type was within the expected range provided by the manufacturer. If a Schmidt hammer falls out of calibration, a correction factor can be applied to measured values (IRSM 1978). Our team collected field data during two campaigns: June 8-12, 2022, for the Alaska sites; and August 15-19, 2022, for the southern Washington and Oregon sites (Table 2.1). At all sites we collected readings using two Schmidt hammer (SH) devices (Rock Schmidt Rebound Hammer Types N and L) to conduct a systematic comparison for multiple rock types and weathering conditions in a field setting. Two individuals conducted the testing with both hammer types. All SH tests were conducted following ASTM standards (ASTM International 2014) with the exception that we did not use the grinding stone on the *in situ* rock surfaces. Before testing began, we developed a procedure to address the influence of various parameters on the results.

At each site, we identified a minimum of ten SH testing locations along the rock slope face. At each location, we constructed a grid of ten points within a 1-m<sup>2</sup> area (see Figure 2.1a for a grid example). Testing locations were georeferenced by using a Leica GS18 real-time kinematic global positioning system (RTK-GPS) at the Alaska sites, and a combination of Leica GS18 and GS14 rover and base pairs at the Washington and Oregon sites. To address potential user bias, we developed an additional testing grid of ten points (Figure 2.1b) for locations where two individuals took measurements. The distance between each testing point on the grid was greater than 6 cm (2.36 in.) to prevent any overlap of deformation on the rock face. To check for the potential effect of multiple shots and different hammer types, we took a measurement with each hammer type at each point, alternating which hammer type was used first at the different locations. If applicable, we noted the orientation to foliation or bedding because this can affect rebound values. Testing parallel rather than perpendicular to bedding or foliation may cause the

recorded rebound values to be lower because of the dissipation of energy along the bedding or foliation plane. Additionally, at every other SH location we collected a water content sample in a sealed tin and transported these to the University of Alaska Fairbanks (UAF) for testing.

Name	Abbreviation	Highway	State	Rock type(s)
Long Lake MP71	LL71	Glenn Highway	AK	mudstone
Long Lake MP75	LL75	Glenn Highway	AK	rhyodacite, sandstone
Long Lake MP85.5	LL85.5	Glenn Highway	AK	gabbro
Long Lake MP87	LL87	Glenn Highway	AK	sandstone
Nenana Canyon MP239	NC239	Parks Highway	AK	diabase; schist unit consisting of white mica schist, muscovite sericite schist, and quartzite
Nenana Canyon MP241	NC241	Parks Highway	AK	quartzite
Hewett Lake	HL	State Route 14	WA	basalt
Eddyville	EDE	U.S. Route 20	OR	sandstone, siltstone
Yellow Creek	YC	State Highway 138	OR	sandstone, siltstone
Canyonville	CNM	Interstate 5	OR	tuff

Table 2.1 Summar	of Schmidt hammer	testing sites
------------------	-------------------	---------------



**Figure 2.1** Examples of Schmidt hammer (SH) testing locations: (a) a grid set-up on the slope face (yellow X's indicate impact locations) used for standard and "Super Sites" tested by one individual; (b) a grid set-up for two individuals taking measurements (indicated by yellow X's and O's).

We established additional SH testing locations on the rock face to determine the effects of repeated impacts from the SH—we called these locations "Super Sites" (SS). At these

locations, we measured a grid of ten testing points using only one hammer type; we alternated hammers between SS testing sites. On each point in the grid, we measured ten consecutive R values. These locations were used to determine possible changes to rebound measurements with successive impacts.

#### 2.3. Unconfined Compressive Strength (UCS) Testing

#### 2.3.1. Sample Collection and Preparation

At the Alaska sites, we collected large rock samples representative of each major lithology from each slope and transported them to the Geological Engineering laboratory at UAF for sample preparation for strength testing (Figure 2.2). Large rocks were selected on the basis of their dimensions and lack of discontinuities to ensure ample material for laboratory testing.



Figure 2.2 View of rock specimens (within yellow ellipse) transported in the back of a pick-up truck for strength testing.

For competent rock blocks (i.e., the LL75 rhyodacite and NC239 diabase), we prepared five cylindrical core samples according to the ASTM D7012 standard, Method C, which requires a minimum required diameter of 57 mm (2.24 in.) (ASTM International 2014). We used a 5.08-cm (2-in.) diameter coring bit and trimmed each core to a length of 10.16 cm (4 in.) to obtain the

2:1 length-to-diameter ratio per the ASTM specifications (ASTM International 2014) (see Figure 2.3a).

Because of the prominent bedding, foliation, and jointing within the LL71 mudstone, LL75 and LL87 sandstone, LL85 gabbro, and NC schist units, none of these rocks would produce an intact core sample. Therefore, we took an alternative approach to make UCS samples from these rock types. Du et al. (2019) and Durmekova et al. (2021) indicated that cylindrical samples with a length-to-diameter ratio of 2:1 and prism samples with a length-to-width ratio of 2:1 yielded similar results, with only minor differences in UCS strength between the two specimen shapes. Instead, these authors found that decreasing the length-to-width ratio had a more significant effect on the strength results, typically causing them to increase.

Therefore, we prepared prism samples for the rock types that would not produce cores. First, we cut slabs of rock with a large masonry saw. Using a smaller saw, we cut the slabs precisely to the dimensions of 10.16 cm x 5.08 cm x 5.08 cm (4 in. x 2 in. x 2 in.) (Figure 2.3b); to maintain consistency with the cylindrical samples, we used a length-to-width ratio of 2:1.



Figure 2.3 Images of (a) cylindrical and (b) prism samples before strength testing. Prominent discontinuities are marked on each sample in black.

We ground the loading surfaces of each sample level to within a 0.02-mm (0.000787-in.) tolerance with a grinder. Before testing, we collected length, width, and diameter measurements ( $\pm 0.00127$  cm / 0.0005 in.) and mass measurements ( $\pm 0.05$  g / 0.00011 lb). Images were taken

of each sample, in which we indicated the locations of prominent discontinuities, crystals, and veins (larger than 10 mm or 0.39 in.; see Figure 2.3). For the LL75 and LL87 sandstone, samples were prepared and tested perpendicular or parallel to bedding to match the field orientation tested by the SH.

Since the NC239 diabase was the most competent rock that we collected, we produced a combination of cylinders (five samples) and prisms (three samples) from this rock type to determine whether the sample's shape had a significant effect on strength results. We could only produce one cylindrical core from the LL85.5 gabbro unit, so we also tested a combination of the two sample shapes for this rock type. Unfortunately, the LL71 mudstone did not provide any viable samples for UCS testing (see Figure 2.4).



**Figure 2.4** Examples of the LL71 mudstone behavior during sample preparation: (a) prominent bedding caused the rock to break apart into sheets of varying thickness; (b) an attempt to core a mudstone rock resulted in failure along the bedding and the disintegration of the sample.

### 2.3.2. Testing Procedure

For UCS testing, we used a heavy-duty load frame suitable for testing high-strength rock cores. Before testing, we cleaned all platens within the testing chamber. After placing the sample in the load frame (Figure 2.5), we loaded it at a continuous rate of 0.000635 cm/s (0.00025 in./s). We selected this loading rate to ensure that the sample would fail within 2 to 15 minutes.

Throughout the testing duration, the testing system recorded load and deformation, and produced a stress-strain diagram graphing the failure process. The UCS was calculated from the

maximum recorded load and the cross-sectional area of the specimen. The failure mode of the sample was noted based on the marked discontinuities and the failure plane angle.



Figure 2.5 Cylindrical rock sample loaded into the UCS testing machine.

#### **CHAPTER 3. RESULTS**

#### 3.1. Schmidt Hammer (SH) Data

At the Alaska locations we took 3,050 SH measurements along seven slopes, and at the Oregon and Washington locations we took 1,750 SH measurements along four slopes. Table 3.1 contains the averages of both the unreduced SH values, and those obtained by applying the ASTM D5873-14 methodology (ASTM International 2014). The results were comparable within the calculated standard deviations. The LL75 rhyodacite unit demonstrated the highest averaged unreduced and reduced R values of all sites, with the L-type and N-type hammers both providing an unreduced value of 56 and a reduced value of 55. The Eddyville (EDE) and Yellow Creek (YC) siltstones had the lowest average R values of 0 and 2, respectively. These siltstones also had the highest gravimetric water contents of 8.18 percent for the EDE and 1.94 percent for the YC. For all sites, applying the ASTM data reduction method lowered the standard deviation of the measurements; however, the reduced average R values did not significantly change and were within  $\pm$  3 of the original averaged R values.

#### 3.2. UCS Testing Results

Of the 11 rock types tested with the SH at the Alaska locations, we prepared samples of seven rock types for strength testing. As mentioned previously, the LL71 mudstone was not viable for UCS testing because of a lack of intact cores or prisms. Additionally, we were not able to test the NC239 / NC241 quartzite before submission of this report because of a breakage within the UCS testing equipment. Table 3.2 contains the UCS results for the seven tested rock types.

To compare results based on sample shape, we tested both cylinders and prisms (five of each shape) of the diabase. Because we were unable to produce ample cylinders of the gabbro, we only tested one cylinder and four prisms of this rock type. The diabase provided average UCS values of 191.4 MPa (27,760.2 psi) and 176.2 MPa (25,555.6 psi) for the cylinder and prism samples, respectively. The gabbro UCS results were 113.9 MPa (16,519.8 psi) for the cylinder core and 156.3 MPa (22,669.4 psi) for the prisms. The LL75 sandstone provided the highest average rock strength of 248.9 MPa (36,099.9 psi). The LL87 sandstone was the weakest rock tested with a UCS of 39.3 MPa (5,704.1 psi).

	No. of		Avg. R, L type		Avg. R, N type		Avg.
Field site	testing	Pock turo	(std. dev.)		(std. dev.)		gravimetric
Field Site	locations	Rock type				ASTM	moisture
	(No. of SS)		All values	ASTM method	All values	method	content (%)
Long Lake (MP71)	10	Mudstone	29 (13.4)	29 (10.4)	31 (14.9)	31 (12.0)	0.66
	10	Rhyodacite	56 (11.5)	55 (8.3)	56 (11.5)	55 (6.4)	0.68
Long Lake (MP75)	10	Sandstone	49 (13.6)	50 (9.0)	52 (12.9)	52 (8.9)	0.89
Long Lake (MP85)	10	Gabbro	51 (14.8)	51 (9.8)	51 (12.6)	51 (7.1)	0.51
	10	Sandstone	32 (13.2)	31 (11.7)	34 (11.1)	34 (8.2)	1.47
Long Lake	2	Mudstone	44 (7.9)	43 (3.0)	44 (6.7)	45 (1.5)	
(MP87)	2	Basal conglomerate	36 (15.8)	36 (16.5)	36 (10.7)	38 (5.6)	
	15 (4)	Quartzite	40 (21.9)	40 (18.2)	37 (21.1)	36 (16.1)	0.30
Nenana Canyon	11 (2)	Diabase	40 (23.2)	42 (17.7)	40 (24.3)	40 (18.3)	0.47
(MP239)	2 (2)	White mica schist	39 (16.6)	36 (6.2)	42 (14.8)	43 (2.4)	0.36
Nenana Canyon							
(MP241)	10 (4)	Quartzite	41 (17.4)	42 (10.6)	42 (17.4)	42 (12.7)	0.14
Hewett Lake	10 (4)	Basalt	53 (13.7)	54 (9.7)	54 (14.8)	55 (8.6)	0.77
Eddyville	12 (4)	Sandstone	37 (12.7)	38 (11.8)	35 (12.5)	35 (11.7)	1.52
	Yellow C	reek					

# **Table 3.1** Summary of SH results and moisture content for all field sites; '---' indicates not tested.

2		0 (0)	0 (0)	1 (3.2)	0 (0)	8.18	
	10 (4)	Sandstone	43 (12.3)	43 (7.4)	41 (12.6)	42 (9.8)	1.14
Siltstone	1	Siltstone	2 (4.7)	0 (0)	2 (5.1)	0 (0)	1.94
Canyonville	11 (4)	Tuff	28 (22.6)	31 (18.2)	28 (22.9)	29 (18.9)	0.47

Field site	Rock type	Core type	Avg. strength (MPa)
11.75	Rhyodacite	Cylinder	227.2
	Sandstone	Prism	248.9
11.95	Cabbro	Cylinder	113.9
LLOJ	Gabbio	Prism	156.3
LL87	Sandstone	Prism	39.3
	Diabase	Cylinder	191.4
NC230	Diabase	Prism	176.2
NC239	White mica schist	Prism	43.2
	Muscovite sericite schist	Prism	42.2

**Table 3.2** Summary of results from the UCS tests.

# CHAPTER 4. SUMMARY AND ADVANTAGES AND DISADVANTAGES OF THE SCHMIDT HAMMER

Through this comprehensive study of multiple field sites, we found the SH to be a convenient and effective device. It is a versatile tool that can be applied in both lab and field settings. In the field, the SH is easy to use and inexpensive to implement because the device is hand-held and light-weight. Taking a rebound measurement is straightforward and does not require extensive training to be done correctly. Results from the SH are immediate and require little preparation. This method is nondestructive and will typically leave the *in situ* rock face or sample intact, unlike other types of strength testing. The SH can be applied to rock types that include major discontinuities, unfavorable bedding, and other limitations that prevent the rock from providing ample samples for other types of strength testing (such as UCS).

Through our literature review, we identified several parameters that can affect SH results, including testing methodology, sample testing conditions, and data reduction. In an attempt to determine the effects that these parameters may have on SH results, we developed a procedure to address each. Depending on the rock type, there can be differences in rebound measurements, depending on testing orientation to bedding or foliation. For example, the increased surface roughness when testing parallel to bedding or foliation may contribute to lower rebound measurements. We expected higher SH measurements orthogonal to bedding and foliation, and lower R values parallel to these discontinuities. The LL75 sandstone R values were measured with the impact perpendicular to bedding, whereas the LL87 sandstone R values were measured parallel to bedding. The average ASTM SH LL75 rebound values were 50 (L- type) and 52 (N-type), while the LL87 R values were lower at 31 (L-type) and 34 (N-type). While these differences may have been due to the orientation of the SH testing, they also may have been due to differences in moisture content and/or inherent differences in rock strength between the two different sandstone units.

Because the SH can be used in a variety of environments, this can have a potential effect on R values. For the purpose of this report, we conducted only field SH measurements directly on the slope face. Field locations have discontinuities that may reduce overall rock strength (e.g., prominent jointing, bedding, foliation, etc.), which can translate into lower SH rebound values. The LL87 sandstone had the lowest results for both the SH and UCS testing. As previously mentioned, this unit had the highest water content and was tested parallel to bedding, both of which may have contributed to the lower values. Generally, the SH results can be correlated to rock strength, where

high SH readings indicate high UCS values, but our results did not yield a perfect correlation. The three strongest rock types from the UCS testing—LL75 rhyodacite, LL75 sandstone, and LL87 gabbro—were also the three rock types that had the highest SH readings. While the rhyodacite had the highest average SH value, it did not have the highest measured UCS. The sandstone unit with the third highest SH value resulted in the highest UCS. SH results will vary across the rock mass as a result of the inherent heterogeneity of rock, but they can vary significantly because of differences in crystalline structure, especially in rocks with varied mineral composition. We observed this in the quartzite and schist of NC239, where rebound values varied significantly based on the presence or absence of large quartz veins prevalent in the unit. Some SH test points within the grid measured higher or lower in accordance with higher or lower visible quartz vs. mica content, and these variations were evident in the increased standard deviation for the schist unit (> 15).

Another potential issue is determining which hammer type to use, especially as there is no definitive guidance on their use for rock strength testing. Several references point to L-type hammers as the preferred type for rock strength testing, most likely because this type was identified in the IRSM standard. Other authors have suggested using the N-type because it gives less scatter and works for a large range of rock strengths. According to Ozbek et al. (2017), N-type rebound values are typically higher than L-type values by ~20 to 25 percent. Our rebound results were closer than anticipated, with minimal deviation from each other ( $\pm$  3). Although the averaged results were similar, the N-Type generally had a lower standard deviation (within  $\pm$  3) than the L-Type for all values averaged. This trend also was present with the application of the ASTM data reduction method.

After data collection, choosing the data reduction methodology can impact results. There are several methods to average SH data, the choice of which largely depends on the goal of the study. If the goal is a representative R value for the competent rock mass, then the ASTM and IRSM methods specify retaining the higher rebound values. In contrast, Amaral et al. (1999) suggested keeping all values, with an emphasis on understanding variance sources. Applying the ASTM data reduction method to our data resulted in a decrease in the standard deviation through the removal of outlier measurements. The ASTM average can be considered a rebound value representative of the competent and intact rock mass, where values affected by discontinuities are removed. When all values are averaged, the standard deviation is higher. For our data, the largest increase occurred for the white mica schist, where the standard deviation for the L-type increased from 6.2 with the ASTM method to 16.6 with all values included.

We suggest considering the following before using the SH:

- Based on our results, the selection of SH type is up to the user. The N-Type is potentially a better candidate for general use because of lower scatter in its results.
- Determine the final goal before using the SH and selecting a testing methodology (i.e., acquiring results representative of the rock mass or the intact rock).
- Before recording any values, identify the rock type and determine potential bedding, foliation, persistent jointing, faults, etc. that can influence results at the testing location.
- Differences in testing environments, for example in the field on *in situ* rock versus in the lab on large samples, may affect results because of the bias of sample selection.
- Select the most applicable data reduction method for the SH results. The method used will change the final averaged rebound results.

Finally, this report is the initial summary of our results. A comprehensive analysis, including the remaining UCS testing, comparison to point load tests and SH tests on lab samples, and the effect of proximity to discontinuities on SH field measurements, will be included in the first author's Master's thesis.

#### **CHAPTER 5. REFERENCES**

- Alaska Department of Transportation and Public Facilities (ADOT&PF), 2020. Alaska DOT&PF Route Centerlines. Fairbanks, Alaska Department of Transportation and Public Facilities. Available from: < <u>https://dot.alaska.gov/stwddes/gis/shapefiles.shtml</u>>
- Alaska Geospatial Council (AGC), 2020. Alaska Coastline Shapefiles. Fairbanks, Alaska Geospatial Office. Available from: < <u>https://gis.data.alaska.gov/search?q=alaska%20boundary</u> >
- Amaral, P.M., Rosa, L.G., Fernandes, J.C., 1999. "Determination of Schmidt rebound hardness consistency in granite." Int. J. Rock Mech. Min. Sci. 36. 833 – 837.
- ASTM International, 2014. Standard Test Method for Determination of Rock Hardness by Rebound Hammer Method, D5873-14: ASTM International, West Conshohocken, PA, 6 p.
- Aydin, A. and Basu, A., 2005. "The Schmidt hammer in rock material characterization." *Engineering Geology*: 81(1), 1-14, <u>https://doi.org/10.1016/j.enggeo.2005.06.006</u>
- Darrow, M. M., Herrman, D. M., Holtan, K, Leshchinsky, B., Olsen, M., Wartman, J., 2022. *The Long-Term Effect of Earthquakes: Using Geospatial Solutions to Evaluate Heightened Rockfall Activity on Critical Lifelines*: PacTrans, Seattle, WA, 74 p.
- Darrow, M. M., Herrman, D. M., Leshchinsky, B., Olsen, M. J., Wartman, J., In Review. A RAI of Data: Generalizing the Data-Driven Rockfall Activity Index (RAI) Based on Long-term Observations of Well- Characterized Slopes: PacTrans, Seattle, WA, 46 p.
- Du, K., Su, R., Tao, M., Yang, C., Momeni, A., Wang, S., 2019. "Specimen shape and crosssection effects on the mechanical properties of rocks under uniaxial compressive stress." *Bulletin of Engineering Geology and the Environment*. 78. 6061-6074.
- Dunham, L., Wartman, J., Olsen, M.J., O'Banion, M.S., Cunningham, K., 2017. "Rockfall Activity Index (RAI): a Lidar-derived, morphology-based hazard assessment system." *Eng. Geo.*: 221, 184-192, doi:10.1016/j.enggeo.2017.03.009
- Durmekova, T., Bednarik, M., Dikejova, P., Adamcova, R., 2021. "Influence of Specimen Size and Shape on the Uniaxial Compressive Strength Values of Rocks." *Environmental Earth Sciences*. https://doi.org/10.21203/rs.3.rs-670782/v1
- Holtan, K., 2021. Assessing Seismic Rockfall Impacts on Mobility in Transportation Corridors. MS Thesis, Oregon State University.
- Hucka, V., 1965. "A rapid method of determining the strength of rocks in situ." International Journal of Rock Mechanics and Mining Sciences and Geomechanics Abstracts. 2. 127-134. https://doi.org/10.1016/0148-9062(65)90009-4.

- ISRM, 1978. "Suggested methods for determining hardness and abrasiveness of rocks." *International Journal of Rock Mechanics and Mining Sciences and Geomechanics Abstracts.* 15. 89 97.
- Liu, X., Shen, J., Liang, L., Han, L., Liu, H., 2011. "Effects of pore pressure on rock strength properties." Yanshilixue Yu Gongcheng Xuebao/Chinese Journal of Rock Mechanics and Engineering. 30. 3457- 3563.
- Oregon Geospatial Enterprise Office (OGEO), 2023a. Oregon Highway Network. Oregon Geospatial Enterprise Office. Available from: < <u>https://www.oregon.gov/geo/pages/sdlibrary.aspx</u> >
- Oregon Geospatial Enterprise Office (OGEO), 2023b. Oregon Area Commissions on Transportation - 2010. Oregon Geospatial Enterprise Office. Available from:<<a href="https://www.oregon.gov/geo/pages/sdlibrary.aspx">https://www.oregon.gov/geo/pages/sdlibrary.aspx</a> >
- Ozbeck, A., Gul, M., Karacan, E., Alca, O., 2017. "Anisotropy effect on strengths of metamorphic rocks." *Journal of Rock Mechanics and Geotechnical Engineering*. 10. 164-175
- Poole, R. and Farmer, I., 1980. "Consistency and repeatability of Schmidt Hammer rebound data during field testing." *International Journal of Rock Mechanics and Mining Sciences and Geomechanics Abstracts.* 17. 167-171. https://doi.org/10.1016/0148-9062(80)91363-7.
- Proceq, 2017. Rock Schmidt Operating Instructions. Proceq. Switzerland.
- Shorey, P.R., Barat, D., Das, M.N., Mukherjee, K.P., Singh, B., 1984. Schmidt hammer rebound data for estimation of large scale in situ coal strength. *Int. J. Rock Mech. Min. Sci.*, Geomech. Abstr. 21, 39 42.
- Wang, M. and Wan, W., 2019. "A new empirical formula for evaluating uniaxial compressive strength using the Schmidt hammer test." *International Journal of Rock Mechanics and Mining Sciences*: 123, 104094, <u>https://doi.org/10.1016/j.ijrmms.2019.104094</u>
- Washington State Department of Transportation Geospatial Open Data Portal. Available from:< https://datawadnr.opendata.arcgis.com/search?groupIds=eee2501342024deaaa41a61c48321d42 >

Washington State Department of Natural Resources (WA DNR), 2023a. WA\_State\_Boundary.

Washington State Department of Natural Resources (WA DNR), 2023b. WSDOT – State Route Line (1:24K) 2012. Washington State Department of Transportation Geospatial Open Data Portal. Available from: < <u>https://gisdata-wsdot.opendata.arcgis.com/</u> >