

Lower Citywide Speed Limits and Design Changes Safer city arterials for all road users

Excessive speeding in cities can be particularly deadly for vulnerable road users, especially on busy arterials with high volumes of vehicle, pedestrian, and bicycle interaction. Only five out of 10 pedestrians will survive a crash with a vehicle traveling at 42 miles per hour (mph).1

Transportation practitioners use a variety of strategies to manage speed, and lowering speed limits citywide is one of those strategies. However, simply lowering the citywide speed limit isn't always enough to slow drivers—a wide travel lane design and unobstructed views on many city arterials encourage speeding by making drivers feel that it is safe to speed.



Source: FHWA based on AAA study

REDESIGNING CITY ARTERIALS

Many cities incorporate countermeasures into street design to reduce vehicle speeds and contribute to a complete streets environment—one that enhances the safety and mobility of all road users. Examples include:

Raised Pedestrian Crosswalks



Source: SDOT, Raised crosswalk, FLKR

Often installed at mid-block crossings, raised pedestrian crosswalks extend across the entire width of the roadway. Pedestrians cross at the same level as the sidewalk, making them more visible to drivers.

Approach ramps cue drivers to slow down, giving them more time to react near pedestrians.

Curb Extensions



Curb extensions reduce the width of the roadway by extending the curb into the parking lane. This shortens pedestrian crossing distances and reduces the time needed to cross the street. Drivers are

encouraged to slow down when approaching intersections and mid-block crossings, making turns, and traveling through intersections.

Lane Reduction



Lane reduction reduces the number of travel lanes on a multilane undivided roadway, which can affect a driver's choice of speed. Also known as a road diet, the extra space can be reallocated to add

dedicated turn and bus lanes and other countermeasures such as pedestrian visibility and crosswalk enhancements.

Lane Narrowing



Lane narrowing using pavement marking techniques reduces the width of the travel lane. It frees up space for traffic calming measures such as widened sidewalks, extended curbs, and chicanes. Also called

a lane diet, this can force slower vehicle traffic, make drivers more aware of surroundings, and give drivers more time to react to pedestrians at intersections and crosswalks.

AAA Foundation for Traffic Safety, Impact Speed and a Pedestrian's Risk of Severe Injury or Death (Washington, DC: 2011).



SPOTLIGHT ON SEATTLE: REDESIGNING A CRASH-PRONE ARTERIAL

After lowering the citywide speed limit from 30 to 25 mph, excessive speeding on Rainier Avenue South was still a challenge. Seattle Department of Transportation employed street design changes to help improve speed limit compliance and road user safety on Rainier Avenue South.

GOALS

- Reduce excessive speeding
- Increase compliance with reduced citywide speed limit
- Reduce number and severity of injuries from collisions

TREATMENTS

- Removed one lane of traffic in each direction
- Added dedicated bus lanes and center turn lanes
- Narrowed travel lanes with curb and sidewalk extensions
- Improved signage for better visibility of lowered speed limit

RESULTS*

- 52% decrease in speeding northbound; 28% decrease southbound
- 15% decrease in collisions overall
- 30% decrease in injury collisions
- 40% decrease in pedestrian and bicycle collisions

^{*} Source: SDOT, Rainier Avenue South Safety Corridor: Rainier Pilot Project Evaluation.





Source: Seattle Department of Transportation

Redesigning Rainier Ave S to be self-enforcing and adding speed management countermeasures has improved compliance with the lowered posted speed limits.

Jame Le, SDOT

77

LEARN MORE

- FHWA's Traffic Calming ePrimer
- <u>USLIMITS2</u>: Set reasonable, safe, and consistent speed limits for specific road segments
- Rainier Avenue Improvement Project

