# Federal Highway Administration University Course on Bicycle and Pedestrian Transportation

**Lesson 18: Bicycle and Pedestrian Connections to Transit** 

**July 2006** 



U.S. Department of Transportation

Federal Highway Administration



SI* (MODERN METRIC) CONVERSION FACTORS  APPROXIMATE CONVERSIONS TO SI UNITS							
		LENGTH					
in ft	inches feet	25.4 0.305	millimeters meters	mm m			
yd	yards	0.914	meters	m			
mi	miles	1.61	kilometers	km			
in <sup>2</sup>	square inches	<b>AREA</b> 645.2	square millimeters	mm <sup>2</sup>			
ft <sup>2</sup>	square feet	0.093	square meters	m <sup>2</sup>			
yd <sup>2</sup>	square yard	0.836	square meters	m²			
ac mi²	acres square miles	0.405 2.59	hectares square kilometers	ha km²			
	equal o minos	VOLUME	equal o momento				
fl oz	fluid ounces	29.57	milliliters	mL			
gal ft <sup>3</sup>	gallons outline foot	3.785	liters	L m³			
yd <sup>3</sup>	cubic feet cubic yards	0.028 0.765	cubic meters cubic meters	m <sup>3</sup>			
,		E: volumes greater than 1000 L shall b					
		MASS					
oz Ib	ounces pounds	28.35 0.454	grams kilograms	g kg			
T	short tons (2000 lb)	0.454	megagrams (or "metric ton")	Mg (or "t")			
	,	TEMPERATURE (exact deg		3 (* * )			
°F	Fahrenheit	5 (F-32)/9	Celsius	°C			
		or (F-32)/1.8					
fc	foot-candles	ILLUMINATION 10.76	lux	lx			
fl	foot-Lamberts	3.426	candela/m²	cd/m <sup>2</sup>			
		FORCE and PRESSURE or S	TRESS				
lbf	poundforce	4.45	newtons	N			
lbf/in <sup>2</sup>	poundforce per square in	nch 6.89	kilopascals	kPa			
APPROXIMATE CONVERSIONS FROM SI UNITS							
Symbol	APPRO When You Know	Multiply By	To Find	Symbol			
-	When You Know	Multiply By LENGTH	To Find				
Symbol		Multiply By		in			
mm	When You Know millimeters meters meters	Multiply By LENGTH 0.039 3.28 1.09	To Find  inches feet yards	in ft yd			
mm m	When You Know millimeters meters	Multiply By LENGTH 0.039 3.28 1.09 0.621	To Find inches feet	in ft			
mm m m km	When You Know millimeters meters meters kilometers	Multiply By  LENGTH  0.039 3.28 1.09 0.621 AREA	To Find  inches feet yards miles	in ft yd mi			
mm m m	When You Know millimeters meters meters	Multiply By LENGTH 0.039 3.28 1.09 0.621	To Find  inches feet yards	in ft yd			
mm m km mm² m²	when You Know  millimeters meters meters kilometers  square millimeters square meters square meters	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195	inches feet yards miles  square inches square feet square yards	in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup>			
mm m km mm² m² m² m² ha	when You Know  millimeters meters meters kilometers square millimeters square meters square meters hectares	Multiply By  LENGTH 0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47	inches feet yards miles square inches square feet square yards acres	in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac			
mm m km mm² m²	when You Know  millimeters meters meters kilometers  square millimeters square meters square meters	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386	inches feet yards miles  square inches square feet square yards	in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup>			
mm m km mm² m² m² m² ha	when You Know  millimeters meters meters kilometers square millimeters square meters square meters hectares	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386  VOLUME 0.034	inches feet yards miles square inches square feet square yards acres	in ft yd mi in <sup>2</sup> ft <sup>2</sup> yd <sup>2</sup> ac			
mm m km mm² m² m² ha km²	when You Know  millimeters meters meters kilometers  square millimeters square meters square meters hectares square kilometers  milliliters liters	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386  VOLUME 0.034 0.254	inches feet yards miles  square inches square feet square yards acres square miles  fluid ounces gallons	in ft yd mi in² ft² yd² ac mi² fl oz gal			
mm m km mm² m² m² ha km² mL L m³	when You Know  millimeters meters meters kilometers  square millimeters square meters square meters hectares square kilometers  milliliters liters cubic meters	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386  VOLUME 0.034 0.264 35.314	inches feet yards miles  square inches square feet square yards acres square miles  fluid ounces gallons cubic feet	in ft yd mi  in² ft² yd² ac mi² fl oz gal ft³			
mm m km mm² m² m² ha km²	when You Know  millimeters meters meters kilometers  square millimeters square meters square meters hectares square kilometers  milliliters liters	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386  VOLUME 0.034 0.254	inches feet yards miles  square inches square feet square yards acres square miles  fluid ounces gallons	in ft yd mi in² ft² yd² ac mi² fl oz gal			
mm m km mm² m² m² ha km² mL L m³	when You Know  millimeters meters meters kilometers  square millimeters square meters square meters hectares square kilometers  milliliters liters cubic meters	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386  VOLUME 0.034 0.264 35.314 1.307	inches feet yards miles  square inches square feet square yards acres square miles  fluid ounces gallons cubic feet	in ft yd mi  in² ft² yd² ac mi² fl oz gal ft³			
mm m km mm² m² m² ha km² mL L m³ m³	when You Know  millimeters meters meters kilometers  square millimeters square meters square meters hectares square kilometers  milliliters liters cubic meters cubic meters grams kilograms	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386  VOLUME 0.034 0.264 35.314 1.307  MASS 0.035 2.202	inches feet yards miles  square inches square feet square yards acres square miles  fluid ounces gallons cubic feet cubic yards  ounces pounds	in ft yd mi  in² ft² yd² ac mi²  fl oz gal ft³ yd³  oz lb			
mm m km km² m² m² ha km² mL L m³ m³	when You Know  millimeters meters meters kilometers  square millimeters square meters square meters square meters hectares square kilometers  milliliters liters cubic meters cubic meters	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386  VOLUME 0.034 0.264 35.314 1.307  MASS 0.035 2.202 on") 1.103	inches feet yards miles  square inches square feet square yards acres square miles  fluid ounces gallons cubic feet cubic yards  ounces pounds short tons (2000 lb)	in ft yd mi in² ft² yd² ac mi² fl oz gal ft³ yd³			
mm m km mm² m² m² ha km² mL L m³ m³	when You Know  millimeters meters meters kilometers  square millimeters square meters square meters hectares square kilometers  milliliters liters cubic meters cubic meters grams kilograms	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386  VOLUME 0.034 0.264 35.314 1.307  MASS 0.035 2.202	inches feet yards miles  square inches square feet square yards acres square miles  fluid ounces gallons cubic feet cubic yards  ounces pounds short tons (2000 lb)	in ft yd mi  in² ft² yd² ac mi²  fl oz gal ft³ yd³  oz lb			
mm m km mm² m² m² m² ha km² mL L m³ m³ g kg Mg (or "t")	when You Know  millimeters meters meters kilometers  square millimeters square meters hectares square kilometers  milliliters liters cubic meters cubic meters grams kilograms megagrams (or "metric to	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386  VOLUME 0.034 0.264 35.314 1.307  MASS 0.035 2.202 on") TEMPERATURE (exact deg	inches feet yards miles  square inches square feet square yards acres square miles  fluid ounces gallons cubic feet cubic yards  ounces pounds short tons (2000 lb)  rees)	in ft yd mi in² ft² yd² ac mi² fl oz gal ft³ yd³ oz lb T			
mm m m km mm² m² m² ha km² mL L m³ m³ m³	when You Know  millimeters meters meters kilometers  square millimeters square meters hectares square kilometers  milliliters liters cubic meters cubic meters grams kilograms megagrams (or "metric to	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386  VOLUME 0.034 0.264 35.314 1.307  MASS 0.035 2.202 on") 1.103  TEMPERATURE (exact deg 1.8C+32 ILLUMINATION 0.0929	inches feet yards miles  square inches square feet square yards acres square miles  fluid ounces gallons cubic feet cubic yards  ounces pounds short tons (2000 lb)  rees) Fahrenheit foot-candles	in ft yd mi  in² ft² yd² ac mi²  fl oz gal ft³ yd³  oz lb T			
mm m km mm² m² m² m² ha km² mL L m³ m³ g kg Mg (or "t")	when You Know  millimeters meters meters kilometers  square millimeters square meters square meters hectares square kilometers  milliliters liters cubic meters cubic meters grams kilograms megagrams (or "metric to Celsius  lux candela/m²	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386  VOLUME 0.034 0.264 35.314 1.307  MASS 0.035 2.202 on") 1.103  TEMPERATURE (exact deg 1.8C+32 ILLUMINATION 0.0929 0.2919	inches feet yards miles  square inches square feet square yards acres square miles  fluid ounces gallons cubic feet cubic yards  ounces pounds short tons (2000 lb)  rees) Fahrenheit  foot-candles foot-Lamberts	in ft yd mi in² ft² yd² ac mi² fl oz gal ft³ yd³  oz lb T			
mm m m km  m km  mm² m² m² m² ha km²  mL L m³ m³ m³  g kg (or "t")  °C  Ix cd/m²	when You Know  millimeters meters meters kilometers  square millimeters square meters hectares square kilometers  milliliters liters cubic meters cubic meters grams kilograms megagrams (or "metric to Celsius  lux candela/m²	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386  VOLUME 0.034 0.264 35.314 1.307  MASS 0.035 2.202 on") 1.103  TEMPERATURE (exact deg 1.8C+32 ILLUMINATION 0.0929 0.2919  FORCE and PRESSURE or S	inches feet yards miles  square inches square feet square yards acres square miles  fluid ounces gallons cubic feet cubic yards  ounces pounds short tons (2000 lb)  rees) Fahrenheit  foot-candles foot-Lamberts  TRESS	in ft yd mi in² ft² yd² ac mi² fl oz gal ft³ yd³  oz lb T			
mm m m km mm² m² m² ha km² mL L m³ m³ m³	when You Know  millimeters meters meters kilometers  square millimeters square meters square meters hectares square kilometers  milliliters liters cubic meters cubic meters grams kilograms megagrams (or "metric to Celsius  lux candela/m²	Multiply By  LENGTH  0.039 3.28 1.09 0.621  AREA 0.0016 10.764 1.195 2.47 0.386  VOLUME 0.034 0.264 35.314 1.307  MASS 0.035 2.202 on") 1.103  TEMPERATURE (exact deg 1.8C+32 ILLUMINATION 0.0929 0.2919	inches feet yards miles  square inches square feet square yards acres square miles  fluid ounces gallons cubic feet cubic yards  ounces pounds short tons (2000 lb)  rees) Fahrenheit  foot-candles foot-Lamberts	in ft yd mi  in² ft² yd² ac mi²  fl oz gal ft³ yd³  oz lb T			

<sup>\*</sup>SI is the symbol for the International System of Units. Appropriate rounding should be made to comply with Section 4 of ASTM E380. (Revised March 2003)

# **Table of Contents**

18.1	Introduction	1
18.2	Interagency Cooperation	2
	Why Link Bicyclists With Transit Services?	
	Bike-on-Bus Programs	
	Bike-on-Rail Programs	
	Example Transit Access Programs	
18.7	Bicycle Parking Facilities at Transit Stations	7
18.8	Bikestation	8
18.9	What Are the Key Elements of Successful Programs?	8
18.10	Student Exercise	9
18.11	References and Additional Resources	9

# List of Figures

Figure 18-1. Photo. The preferred style of bike rack mounts to the front of the bus	. 3
Figure 18-2. Photo. Some transit agencies allow bicyclists to carry their bikes onto buses	. 4
Figure 18-3. Photos. Bicycle stencils on doors of Danish State railways indicate those cars	
where bikes may be brought on the train.	. 5
Figure 18-4. Photo. Lack of adequate bike parking is a common problem at urban subways	. 8

# **LESSON 18:**

# **BICYCLE AND PEDESTRIAN CONNECTIONS TO TRANSIT**

# 18.1 Introduction

Bicycling and walking typically account for one-fourth to one-half of all personal trips in European cities, as well as the vast majority of all public transportation access trips, even in lower density suburban areas. This stands in sharp contrast to the United States, where the share of personal trips made by nonmotorized means fell in recent decades to less than 10 percent, and where automobile park-and-ride accounts for a major share of suburban transit access.<sup>(1)</sup>

In city after city, transit agencies are rediscovering that good bicycle and pedestrian access is a critical component of the success of the transit system. It has been estimated that 53 percent of the American public lives within 3.2 kilometers (km) (2 miles (mi)) of a public transit route. Walking is the most environmentally friendly and low-cost way to get people to and from public transportation. When given sidewalks or traffic-calmed streets to walk along, safe and convenient ways to cross streets, and a comfortable and attractive environment, most people are willing to walk farther to reach public transportation.

In the United States, however, lack of attention to pedestrian needs beyond the bounds of the transit station seems fairly common. The locations of park-and-ride lots are often not amenable to nonmotorized access. One transit agency commented that all of their park-and-ride lots are located near freeways and/or shopping areas where residential housing is quite far away, and no paths or sidewalks are located near the park-and-ride lots.

Some U.S. transit and transportation agencies are, nevertheless, turning a promisingly sharper focus on the larger environment that surrounds and leads to transit stations and bus stops. A variety of facilities and services are being provided to improve the interface between bicycling and transit: bike racks on buses; provisions for the transport of bicycles on light- and heavy-rail transit, commuter rail, and long-distance trains; bike parking at transit stations; design improvements at transit stations (curb cuts, signing, and lighting); links to transit centers (bike lanes, multiuse trails, and widened roadway shoulders); and multipurpose Bikestations<sup>®</sup> which cater to the bicycle commuter.

The U.S. Congress has emphasized the connection of transit with bicycle and pedestrian facilities in Federal transportation legislation by providing several funding sources for bicycle and pedestrian improvements through the Federal Transit Program (FTP), among other programs.

This lesson discusses the history of bicycle and pedestrian access to transit in the United States and provides an overview of how bicycling and walking are being integrated with transit. Case studies from the United States and Europe describe successful projects.

The major sections of this lesson are as follows:

- 18.1 Introduction.
- 18.2 Interagency Cooperation.

- 18.3 Why Link Bicyclists With Transit Services?
- 18.4 Bike-on-Bus Programs.
- 18.5 Bike-on-Rail Programs.
- 18.6 Example Transit Access Programs.
- 18.7 Bicycle Parking Facilities at Transit Stations.
- 18.8 Bikestations.
- 18.9 What Are the Key Elements of Successful Programs?
- 18.10 Student Exercise.
- 18.11 References and Additional Resources.

# 18.2 Interagency Cooperation

While U.S. transit authorities have expended considerable planning and engineering efforts to meet pedestrian needs in the interiors of transit stations, in many cases, little attention has been devoted to either the pedestrian or bicycling environment to and from stations. Poorly developed interjurisdictional and interagency cooperation often impedes consideration of the door-to-door experience of using public transportation. It is not unusual for several different agencies to maintain independent control over the various facilities that are used by someone walking or bicycling to and from a single transit stop.

Unless these agencies agree to cooperate together in assessing, planning, and enhancing nonmotorized transit access, major impediments to pedestrian and bicycle access may persist or grow in severity. Local and State governments with the authority to manage, maintain, and construct pedestrian and bicycle facilities and roads should cooperate with transit agencies and interested citizens in developing action programs to reduce barriers to bicycle and pedestrian access to transit.

# 18.3 Why Link Bicyclists With Transit Services?

Integration enhances travel potential for both modes of travel by offering a number of advantages that each mode alone cannot provide:

- Bike-on-transit service enables bicyclists to travel greater distances and overcome topographical barriers.
- Bike-on-transit services to recreational destinations during off-peak periods can increase overall transit ridership and increase efficient use of capacity.
- Bicycle-to-transit services (trails, on-road bike lanes, and bike parking) enlarge transit's
  catchment area by making it accessible to travelers who are beyond walking distances from
  transit stations.

Integration lowers air pollutant emissions from trips taken on public transit. Outside of central business districts, most commuters using rail transit and park-and-ride lots arrive by auto; typical trip lengths are 3 to 6 km (5 to 10 mi). For an auto trip of 11 km (7 mi), nearly 90 percent of the emissions occur in the first 1.6 km (1 mi), known as the cold-start stage. Either converting transit access trips from auto to bike or converting car commutes to bike-and-ride transit trips can produce significant emission reductions.<sup>(2)</sup>

**Comment [I1]:** Map figure (formerly 18-1) and references removed from text per FHWA instruction on E1 notes.

# 18.4 Bike-on-Bus Programs

Bike-on-bus programs are functionally similar to bike-on-rail programs, but often operate in much lower density corridors than rail transport. By expanding a bus line's access and egress service area, bike-on-bus programs can attract many passengers who would not otherwise be able to use transit for their trip, particularly to reach suburban destinations where transit coverage is often sparse.

There are two means of accommodating bicycles on buses—placing them on front-mounted racks and allowing them inside the bus. Rear-mounted racks were the earliest system, but for operational and safety reasons, preferences have shifted toward front-mounted racks (see figure 18-1).



Figure 18-1. Photo. The preferred style of bike rack mounts to the front of the bus.

When considering bike-on-bus programs, agencies typically cite two main concerns:

**Schedule Adherence**. A 1994 study completed through the Transit Cooperative Research Program (TCRP) shows that most transit agencies are not experiencing problems with schedule delays resulting from accommodating bicyclists; new designs of bike-on-bus racks have minimized dwell times for loading and removal.<sup>(3)</sup>

Safety and Protection of Transit Property. The study has also shown that the impact of bicycle-transit integration has been minimal on the personal safety of bicyclists, operators, and the public, and on transit agency property. Bike racks on the fronts of buses have not proven to interfere with driving. Because of concerns about bicycles aboard crowded trains during rush hours, some commuter rail programs have limited bike-on-train access to off-peak hours.

Most U.S. bike-on-bus services do not require a permit. While some U.S. transit systems accommodate bikes only on designated routes, others, such as Phoenix, AZ, Aspen, CO, and Sacramento, CA, have no route restrictions and have opened their entire system to carrying bicycles (see figure 18-2).

The City of Phoenix, AZ, began a 6-month bike-on-bus demonstration program from March through August 1991 to assess potential use of the service. Bicycle racks were mounted on the front of buses



Figure 18-2. Photo. Some transit agencies allow bicyclists to carry their bikes onto buses.

operating on three routes that were selected based on criteria developed in coordination with the bicycle community. Two-thirds of the \$15,000 program cost came from a grant by the Arizona Department of Environmental Quality (ADEQ). During the demonstration program, 5,500 bicycle trips were taken and ridership steadily increased. At the end of the first month, 153 riders had used the service. By the end of the third month (May), this jumped to 1,109 riders per month; by the end of 6 months, there were 1,404 riders per month. Phoenix Transit reported no safety problems associated with the new service. The service not only attracted increasing numbers of bicyclists, but also attracted to transit people who did not previously use buses. A bike rider survey found that the vast majority (90 percent) of the bus riders used the bike racks for commuting. An evaluation of the demonstration concluded: (2)

From the response received, it would not be a stretch to say that the program was overwhelmingly popular among transit riders and [was] hailed as an excellent idea by bike riders. For bus patrons it is an added option, for bike riders it is an opportunity, and for public transit it is another step toward reducing the number of vehicles traveling on the road.

As a result of the successful demonstration, the Phoenix Transit bike-on-bus program was expanded systemwide in July 1992. By 1997, all 463 buses in the Phoenix system were equipped with front-mounted bike racks, each of which carried two bikes. A survey in 1997 found that there were 2,146 daily users of the bike racks within Phoenix alone (not including use outside of Phoenix).

The success of the Phoenix program quickly caught the attention of other transit agencies and it is now estimated that more than one in five transit buses in the country are equipped with bike racks. In 1993, the Seattle/King County, State of Washington transit agency, Metro, used more than \$900,000 of Congestion Mitigation and Air Quality (CMAQ) funds to equip every one of its 1,200 buses with racks. The agency now boasts more than 40,000 bicycle-carrying passengers every month. The racks were designed and

supplied by a northwestern U.S. firm whose racks now carry more than 250,000 riders each month on systems throughout the country.

The Tompkins Consolidated Area Transit (TCAT) agency in Ithaca, NY, used Surface Transportation Program (STP) funds to install racks on its 42 buses in August 1996. After one year, it was carrying 1,000 bicyclists a month. The agency estimates that, within the city, 1.2 bicycles are carried for every 100 passengers.

In California, the Santa Clara Valley Transportation Authority (SCVTA) has equipped all its buses with bike racks and allows up to two bikes inside each bus, at the driver's discretion, when the racks are full. During off-peak hours, the Sacramento Regional Transit District allows one bike inside each standard length 12.2-meter (m) (40-foot (ft)) bus not equipped with a front rack. (4)

Although most transit agencies offering bike-on-bus services have relied on various devices outside the bus, a few agencies have decided that such hardware is unnecessary and have allowed bicycles inside their buses instead. Westchester County Department of Transportation (WCDOT), located near New York, NY, simply adopted a permissive "welcome aboard" policy toward bicyclists and other potential users, beginning in the late 1970s. The space provided for passengers who use wheelchairs could be used by those traveling with baby carriages, shopping carts, bulky packages, or bicycles. This policy applied only to accessible Advanced Design Buses (ADBs) and only in off-peak periods. Wheelchair users were given priority over bicycles at all times. No problems had been reported with the service.

# 18.5 Bike-on-Rail Programs

Most light and heavy rail systems now provide some level of access to bicyclists and their bicycles (see figure 18-3). In systems with dedicated bike racks inside the rail cars (e.g., Caltrain® and SCVTA in California), the only restrictions relate to capacity and points of access to the train. In systems without dedicated space (e.g., Portland, OR, Washington, DC, and Boston, MA), riders may take bicycles on board except during the morning and evening peak hours and on festival and other major event days.




Figure 18-3. Photos. Bicycle stencils on doors of Danish State railways indicate those cars where bikes may be brought on the train.

The Tri-County Metropolitan Transportation District of Oregon (Tri-Met) light rail system (known as MAX) in Portland, OR, is one of the few systems still requiring riders to obtain a permit before bringing bikes on board. The permit costs \$5 and requires the rider to watch an 8-minute safety and operation video. Like a number of other transit agencies, the Washington [DC] Metropolitan Area Transit Authority (WMATA) eliminated its permit requirement for bringing bicycles on Metro trains. This simplifies travel for bike-transit users and encourages more bike-transit trips (http://www.wmata.com).

Almost 2,000 bicyclists a day bring their bikes on board the 110-km (70-mi) Caltrain passenger rail line between San Francisco, CA, and Silicon Valley. Each train has space for 24 bikes (some trains may have 2 bike cars, for a capacity of 48 bikes), up from just 4 spaces when the program began in 1992. More than half of a recent ridership jump of 7 percent was attributable to bicyclists. The initial \$30,000 investment by San Francisco County, plus another \$30,000 from Caltrain to expand capacity, was repaid in farebox revenue within 6 months. Demand for bicycle spaces is now so great that Caltrain recently started offering two rented bicycle lockers for the price of one in an effort to persuade bicyclists to keep bikes at both ends of their trip rather than bring their bike on board. (4)

# Time Restrictions

In the United States, nearly all bike-on-rail services are restricted to times outside weekday peak hours. The exceptions are the Bay Area Rapid Transit (BART) in San Francisco, CA, and the commuter rail system in Boston, MA, which allows bicycles to be carried during peak hours in the "reverse commute" direction only. Restrictions on most systems prohibit bicycles on rail weekdays before 9 or 9:30 a.m. (some allow bikes before 6 a.m.) and from 3 or 3:30 p.m. to 6:30 p.m. Weekend policies vary, with some systems having no restrictions and some blocking out certain hours when there is substantial shopping, work, or recreational travel. Several European bike-on-rail systems, including Oslo and Amsterdam, have no restrictions on the times when bicycles can be brought on board. Without any restrictions, bicyclists, using their own common sense, tend to avoid bringing bicycles into rail cars during crowded rush hours. SCVTA leads the United States in adopting the most European attitude toward bike-on-rail, allowing two bicycles per car in peak hours, and four per car in off-peak hours.

# Rail Car Design Constraints

Restrictions on the number of bikes permitted on each rail transit system vary. Some systems permit two bicycles per car; others allow bicycles only on the last car of the train, with a maximum of four bicycles per train. Rail transit system restrictions on the number of bicycles permitted are based in part on rail car designs available in the United States, for which bicycle accommodation has not been a consideration. On the Metropolitan Atlanta Rapid Transit Authority (MARTA) system in Atlanta, GA, and on other systems, bicyclists hold their bikes in a foldup seat area near the back door of the rail car.

In California, design of the new California Car rail car, mandated and funded by Proposition 116, requires accommodation of a reasonable number of bicycles carried on board by passengers for both intercity and commuter applications. The California Car is a bilevel car that superficially resembles Amtrak's® Superliner®, but with significant design differences, including bicycle storage on the lower level of the car. This new rail car, for use on State-sponsored Amtrak and local commuter rail services, is a promising new development in the United States. Its specifications could be adapted by other rail agencies to enhance bicycle-rail linkage.

# 18.6 Example Transit Access Programs

The City of Charlotte, NC, began a project in 1981 to encourage walking and bicycle access to bus transit along its heavily traveled Central Avenue Corridor, which contains seven intersections at a level of

service (LOS) of E or F during the peak hours. To help address bicycle access needs, bicycle racks and lockers were installed at key bus stops. Pedestrian access was improved by installing 114 pedestrian signals and 115 pushbuttons at key intersections, and sidewalks were constructed with curb-cut ramps.

In July 1996, the Maryland Transit Administration (MTA) initiated a statewide inventory of access for bicycles and pedestrians at 111 existing and planned light, heavy, and commuter rail stations throughout the State. The goal was to identify the availability and condition of roadways and facilities at or near rail stations to determine what improvements would be needed to accommodate, in a safe and effective manner, pedestrians and bicyclists. The inventory was funded with \$160,000 of Federal Transit Administration (FTA) State planning and research program money and \$40,000 of State matching funds. Data were collected within a 3-km (2-mi) radius for bicycles and a 1-km (0.6-mi) radius for pedestrians on a wide range of items including:

- Availability of bicycle racks and lockers.
- Condition and availability of sidewalks, crossings, and bicycle access surrounding stations.
- Traffic conditions such as traffic volumes and speed.
- Lane widths, surface conditions, parking, and bridges.
- Traffic mix and related considerations.

The information was used to target improvements by the Maryland Department of Transportation (including MTA) and local governments and to generate a greater understanding of the importance of adequate access to public transportation. (4)

# 18.7 Bicycle Parking Facilities at Transit Stations

Cities and transit authorities across the country are beginning to recognize the crucial role of secure bicycle parking at transit stations in promoting increased bicycle access to transit (see figure 18-4). A number of the Nation's commuter rail and rail transit systems are investing in bicycle parking, but many lack a more comprehensive strategy that looks at the environment beyond the station. Frequently, the quality of the parking provided is inadequate, leaving most bicycles vulnerable to theft and vandalism. The majority of suburban bus transit systems, which could expand service area and ridership through bicycle-transit interface, appear to pay little, if any, attention to bicycle parking facilities at bus stops.



Figure 18-4. Photo. Lack of adequate bike parking is a common problem at urban subways.

There is wide variation in the use of bicycle racks and lockers at rail stations and transit systems. Two crucial factors appear to be the degree to which the environment leading to the station is bicycle-friendly and the quality of the bicycle parking provided. In areas where separate bicycle paths or bike lanes on streets have been implemented, facilitating connection to rail or bus services, the ease and safety of access by bicycle is greatly enhanced. Access to many stations, however, passes through streets where little or no thought has been given to bicycle safety, which curtails the extent of this access. The degree to which a transit agency actively promotes its bicycle parking facilities, and more broadly, promotes the environmental and social benefits of bicycle access versus auto access, directly impacts the use of bicycle lockers and racks.

# 18.8 Bikestation

Bikestations provide another innovative method of integrating bicycles with transit and supporting bicycle transportation in general. The Bikestation concept originated in Europe and Japan and essentially is a holistic approach to providing everything the bicyclist needs in one location. A typical Bikestation can include secure indoor bike parking, a repair shop, bike sales and rentals, car sharing services, changing rooms, route and transit information, and a variety of other support services. The first Bikestation in the U.S. opened in Long Beach, CA. A number of other cities throughout the country have either already built Bikestations or are in the process of planning new Bikestations, including Seattle, WA, Palo Alto, CA, and Washington, DC. Individual Bikestations are typically developed by franchises (either nonprofit or for profit) and are membership-based.

# 18.9 What Are the Key Elements of Successful Programs?

# Demonstration Projects

Many successful programs began with a limited demonstration phase and then expanded to a broader, or even systemwide, operation. Demonstration projects tend to focus on identifying and solving specific technical and operational aspects of the service and usually lead to wider program implementation.

# **Advisory Committees**

Such a committee should include nonagency organizations and individuals who have experience in bicycle advocacy in their community, an interest in bicycle-transit programs, knowledge of user needs and constituency characteristics, and some expertise in bicycle and/or transit issues.

# Marketing and Promotion

A bike-transit program must vigorously market and promote in order to be effective: a brochure describing the agency's program, a telephone number for information, and drawings or photographs of equipment to help users understand operating procedures.

Tri-Met in Portland, OR, distributed 4,000 brochures directly to the local bicycle advocacy group's membership. In Philadelphia, PA, the Southeastern Pennsylvania Transportation Authority (SEPTA) prepared a pamphlet highlighting eight scenic and cultural destinations for bicycle touring that were accessible by its local rail systems. Bike-to-Work Days and bicycle fairs or offers of free test rides have also proven effective in promoting new programs.

### 18.10 Student Exercise

### Exercise A

Choose a local transit station (or individual transit stop) and determine the potential catchment area. Design a program for increasing bicycle and pedestrian access to the transit station, including both design improvements and education/promotion efforts. For physical improvements, include both the immediate vicinity and the connections to origins that lie in the catchment area.

# Exercise B

Choose a nearby transit stop or park-and-ride station and ride a bike or walk to it. Document the problems along the way, as well as those you experience when you arrive at the station/stop. Given your knowledge of the community, what would it take to get people to bicycle and walk to this site?

### 18.11 References and Additional Resources

The references for this lesson are:

- "Case Study No. 17: Bicycle and Pedestrian Policies and Programs in Asia, Australia, and New Zealand," *National Bicycling and Walking Study*, Publication No. FHWA-PD-93-016, Federal Highway Administration, Washington, DC, 1993.
- "Case Study No. 9: Linking Bicycle/Pedestrian Facilities With Transit," *National Bicycling and Walking Study*, Publication No. FHWA-PD-93-012, Federal Highway Administration, Washington, DC, 1992.
- 3. *Integration of Bicycles and Transit, TCRP Synthesis 4*, Transit Cooperative Research Program (TCRP), Transportation Research Board, National Research Council, Washington, DC, 1994, available online at http://gulliver.trb.org/publications/tcrp/tsyn04.pdf.
- 4. *Bicycles and Transit: A Partnership that Works*, Federal Transit Administration and Federal Highway Administration, Washington, DC, 1999.

# Additional resources for this lesson include:

• "The Economic and Social Benefits of Off-Road Bicycle and Pedestrian Facilities," National Bicycle and Pedestrian Clearinghouse Technical Assistance Series, No. 1, Federal Highway Administration, Washington, DC, 1995, available online at <a href="http://www.imba.com/resources/science/econsoc\_benefits.html">http://www.imba.com/resources/science/econsoc\_benefits.html</a>