

CT-82-100-120LR

FAA WJH Technical Center



00092661

~~GENERAL AVIATION ADMINISTRATION~~

MAR 22 Rec'd

TECHNICAL CENTER LIBRARY
ATLANTIC CITY, N.J. 08405

FAA TECHNICAL CENTER LETTER REPORT

SERIAL DATA REFORMATTER EQUIPMENT DESCRIPTION

by

Edward F. Mancus

December 1982

**U. S. DEPARTMENT OF TRANSPORTATION
FEDERAL AVIATION ADMINISTRATION
TECHNICAL CENTER
Atlantic City Airport, N.J. 08405**

TABLE OF CONTENTS

PURPOSE	1
INTRODUCTION	1
RELATED DOCUMENTS	2
DESCRIPTION OF EQUIPMENT	2
GENERAL DESCRIPTION	2
SERIAL DATA REFORMATTING CHANNELS	3
CHANNEL REFORMATTING SOFTWARE	3
SIMULATION & DIAGNOSTIC MODULE	5
SDM DIAGNOSTIC SOFTWARE	6
SDM SCENARIO SOFTWARE	9
SUMMARY	9
APPENDIX A	BASELINE FORMATS FOR THE MODE S/ARTS IIIA INTERFACE TESTS
APPENDIX B	DETAILED LOGIC SCHEMATICS FOR THE SERIAL DATA REFORMATTER EQUIPMENT
APPENDIX C	PROGRAM LISTING FOR REFORMATTER CHANNELS
APPENDIX D	PROGRAM LISTING FOR SIMULATION AND DIAGNOSTIC MODULE
APPENDIX E	EQUIPMENT INSTALLATION AND OPERATION

LIST OF ILLUSTRATIONS

FIGURE		PAGE
1	Serial Data Reformatter Equipment Functional Block Diagram	2A
2	Reformatter Equipment Front Elevation	2B
3	Serial Data Reformatter Channel Block Diagram	3A
4	Functional Flowchart for Input Service Routine	4A - .
5	Functional Flowchart for Output Service Routine	4B
6	Functional Flowchart for Data Reformatting Routine	4C
7	Flowchart for Beacon Report Reformatting Routine	5A
8	Mode S & CD-2/ASR-9 Beacon Report Formats	5B
9	Mode S CPME & CD-2/ASR-9 Beacon Report Formats	5C
10	Mode S BCN Strobe & CD-2/ASR-9 BCN RTQC Message Formats	5D
11	Flowchart for Search Report Reformatting Routine	5E
12	Mode S & CD-2/ASR-9 Search Report Formats	5F
13	Mode S Synch Message and CD-2/ASR-9 Search RTQC Message Formats	5G
14	Flowchart for Status Message Output Routine	5H
15	Block Diagram of Simulation and Diagnostic Module	5I

LIST OF TABLES

TABLE		PAGE
1	Data Transmit Table #1	7
2	Data Lookup Table	7
3	Data Transmit Table #2	7

PURPOSE.

The intent of this document is to provide a functional description of the serial data reformatter equipment, and to enumerate its capabilities and uses.

INTRODUCTION.

The Federal Aviation Administration (FAA) has, since 1979, been engaged in the test and evaluation (T&E) of three sensors built by Texas Instruments, Inc. To date, Mode S beacon and search radar baseline tracking capabilities have been established. Limited data has been collected, however, on the performance of other systems that will eventually utilize Mode S surveillance data when Mode S is implemented. It was decided that a test effort was required to investigate a prototype interface between the Mode S sensor and the automated radar terminal system (ARTS IIIA) utilizing the Mode S surveillance data to establish tracking performance of the ARTS IIIA. The ARTS IIIA system was selected since it will be one of the primary users of Mode S surveillance data.

Mode S integration with the ARTS IIIA will be implemented in the field in two phases. In the initial phase, modifications to the ARTS IIIA operational software will be minimal. The ARTS IIIA will receive scan-to-scan uncorrelated reports from the Mode S sensor and perform all tracking functions. In the second phase, hardware and software enhancements will be developed to allow the ARTS IIIA to take advantage of the more accurate sensor data and the discrete addressing functions derived from the Mode S. The ARTS IIIA will also receive track data from the Mode S while retaining its own track files to maintain ground speed and position prediction information on aircraft.

The T&E effort scheduled to begin January 1983 will focus on evaluating the initial interface between the Mode S site and the ARTS IIIA system for the first implementation phase. To accomplish this it was determined that a special piece of test equipment was necessary to satisfy the surveillance interface requirements set forth in this effort. Although the 'Formatting and Dissemination' function of the Mode S operational software could be modified to meet these requirements it would take a substantial programming effort to do so. In addition, it was desirable to have greater flexibility to modify the formatting and dissemination routines quickly if it became necessary. The serial data reformatter equipment was designed and fabricated for this reason.

The serial data reformatter equipment modifies the current surveillance interface between the Mode S sensor and the terminal automation test facility (TATF)/ARTS IIIA system. This new interface is similar to an interface that is planned during the initial Mode S implementation phase. The Mode S surveillance data will be reformatted similar to common digitizer (CD-2) format, modified for use by terminal facilities. This format will be referred to as the CD-2/Air Surveillance Radar (ASR-9) format within this document. Two real time quality control targets (RTQC's), one beacon and one search,

will be disseminated each scan at predetermined positions. In addition, status messages will be disseminated at random intervals to the ARTS IIIA to demonstrate system software recognition.

RELATED DOCUMENTS.

- a. DABS/ATC Surveillance and Communications Message Formats,
FAA-ER-80-14, April 1980.
- b. Mode S/ARTS IIIA Interface Testing Project Plan,
CT-82-100-119LR.

DESCRIPTION OF EQUIPMENT.

The following paragraphs provide a functional description of the serial data reformatter equipment.

GENERAL DESCRIPTION. The serial data reformatter equipment is a dual channel serial data reformatter with self diagnostic capability. It was designed and built by personnel of the FAA Technical Center to support Mode S/ARTS IIIA system integration tests. In general, the serial data reformatter equipment will receive and send serial data over a standard EIA-RS-232C or MIL-STD-188C interface. Programs resident in firmware enables the reformatter equipment to accept serial data formatted, as specified, in report No. FAA-RD-80-14 and reformat the data as described in appendix A prior to retransmission. A modular block diagram of the reformatter equipment is shown on figure 1. Detailed logic schematics for each module is provided in appendix B.

The reformatter equipment is physically housed in a chassis which mounts in a standard 19-inch rack. The chassis includes a ten unit card cage, D.C. power supplies, and a muffin fan for cooling. As shown in figure 2 the front panel is divided into three principle sections. Two sections labeled channel 1 and channel 2 are basically identical. Each section has an input connector and an output connector compatible with the existing 25-pin cinch connectors of the sensor and modems. Four identical connecting cables, 10 foot in length, are provided to simplify the installation of the equipment between the sensor's two surveillance output ports and the digital side of two modems. Each channel has two line indicators, one indicating the presents of the modem clock and the other indicating activity on the data line. Also included is an 8-bit light emitter diode (LED) display for on-line monitoring of each channel's status and operation. The third functional section enables an operator to run off-line diagnostic and simulation routines. This section consists of an 8-bit LED display, 16 address switches, an address mode control switch, system reset button, and the system on/off power switch. A detailed description of the unit's operation is given in appendix E.




FIGURE 1. SERIAL DATA REFORMATTER EQUIPMENT MODULAR BLOCK DIAGRAM 2A




FIGURE 2. REFORMATTER EQUIPMENT
FRONT VIEW

SERIAL DATA REFORMATTING CHANNELS. The serial data reformatter equipment consists of two independent and identical serial data reformatting channels. Each channel is made up of two modules referred to as the 'processing' module and the 'input/output' (I/O) module. Each module is fabricated on its own logic card. Referring to figure 3, the functional blocks of the processing module are the microprocessor unit, 4K of erasable programmable read only memory (EPROM), 1K of random access memory (RAM), and interrupt handling control logic (not shown on the figure). The functional blocks of the I/O module are the serial input and serial output shift registers, parity checker, parity generator, and two peripheral interface adapters for servicing data transfers between the processing module and the shift registers. The channel performance monitor, an 8-bit LED display, is located on the front panel of the reformatter.

The I/O module provides the interface link between the serial data input stream and the processing module, and between the processing module and the serial data output stream. It receives a clock from a MODEM and uses the clock as the basic timing source for receiving and transmitting data. Mode S data is received serially by a serial-to-parallel shift register. The data is shifted through the register in one bit steps every modem clock period. An input service request (input interrupt) is generated for each modem clock period and sent to the processing module for service. An output service request is generated for each 13-modem clock interval and sent to the processing module for service as well. Reformatted data is loaded into a parallel-to-serial shift register and is shifted out at the same modem clock rate.

The processing module performs all the tasks necessary to convert the Mode S surveillance output port to one compatible with the ARTS IIIA surveillance input port. The processing module initially intercepts and stores all Mode S surveillance data in RAM. After a complete message is received the processing module determines whether the message will be purged or reformatted. In addition, it is tasked to output a simulated status message at random intervals, approximately one per scan averaged over a long period of time. The channel performance monitor provides the following information when the channel operating software is running.

- D0 - Channel synchronized to Mode S data stream
- D1 - Incorrect Mode S message detected
- D2 - Reformatted Mode S data being disseminated
- D3 - Mode S message parity error
- D4 - No Mode S messages detected
- D5 - Beacon/Search RTGC toggle - on for beacon/off for search
- D6 - Software interrupt detected
- D7 - Currently unused

CHANNEL REFORMATTING SOFTWARE. The channel reformatting software consists of the following three major routines:
Input Service Routine (ISR)
Output Service Routine (OSR)




FIGURE 3. SERIAL DATA REFORMATTER CHANNEL BLOCK DIAGRAM

Data Reformatting Routine (DRR)

1. Input Service Routine - The principle functions of the ISR is to synchronize to the input data stream, detect and store all incoming messages, and notify the DRR that a complete message is available for processing. This routine is executed each time an input service request is received from the I/O module. Listings for this routine along with the following two routines is provided in appendix C.

A flowchart of the ISR is presented in figure 4. During initial start up, the ISR examines the input data stream, each modem clock interval in search of an idle character. When an idle character is detected, a flag is set indicating that the ISR is synchronized to the input data stream and a bit counter is initialized to zero. The bit counter is incremented for each input service request until a count of 13 is reached, indicating that a new frame has shifted into the input shift register. The bit counter is set back to zero to repeat the sequence for the next frame to be received. At this time the ISR examines the frame to determine if it is another idle character or a message header. If the frame is an idle character no further action is taken. If the frame is a message header, the ISR presets the frame counter equal to the number of frames contained in the message. An idle character is stored in the input data buffer prior to the message header and the frame counter is decremented. The frame counter is decremented for each succeeding frame stored until it reaches zero, indicating a complete message is stored in the input data buffer. At this time, a sequence-complete flag is raised signaling the DRR that a complete message is available for processing.

2. Output Service Routine - The primary function of the OSR is to output reformatted data or output idle characters when no data is available to the ARTS IIIA. The OSR is executed each time an output service request is received from the I/O module.

A flowchart for the OSR is presented in figure 5. When the OSR receives an output service request it first determines if data is available in the output buffer. If the buffer contains data the next available frame is loaded into the output shift register and shifted out. If the output buffer is empty an idle character is loaded into the output shift register.

3. Data Reformatting Routine - The DRR contains all the routines necessary to transform the Mode S surveillance output port to one acceptable to the ARTS IIIA surveillance input port. In addition, this routine initializes both reformatting channels when power is first switched on and each time the system is reset. The basic flow of the DRR is shown in figure 6. The DRR contains the follows four specific interface conversion routines:

- Beacon Report Reformatting Routine (BRRR)
- Search Report Reformatting Routine (SRRR)
- Weather Message Purge Routine (WMPR)
- Status Message Output Routine (SMOR)




FIGURE 4. FUNCTIONAL Flowchart for INPUT SERVICE ROUTINE





FIGURE 5. FUNCTIONAL FLOWCHART FOR OUTPUT SERVICE REQUEST



ROUTINES

- BEACON REPORT REFORMATTING ROUTINE
- SEARCH REPORT REFORMATTING ROUTINE
- WEATHER MESSAGE PURGE ROUTINE
- STATUS MESSAGE OUTPUT ROUTINE

FIGURE 6. FUNCTIONAL FLOWCHART OF DATA REFORMATTING ROUTINE.

a. The BRRR performs two specific functions: reformats Mode S air traffic control radar beacon system (ATCRBS) reports and the ATCRBS calibration and performance monitoring equipment (CPME) report into regular CD-2/ASR-9 formatted beacon reports; and outputs a pre-defined beacon RTGC report when a special purpose beacon strobe message is received from the Mode S sensor. A functional flowchart of the BRRR is shown in figure 7. Figures 8, 9, and 10 show the format of the regular Mode S ATCRBS beacon report, ATCRBS CPME report, and beacon strobe, respectively, along with their corresponding formats after BRRR reformatting.

The Mode S formatting and dissemination function will reformat Mode S beacon reports to ATCRBS reports prior to dissemination. This is required to obtain the discrete code of Mode S transponder-equipped aircraft. Also the Mode S sensor will output a special beacon strobe message to the reformatter equipment. The BRRR will recognize this message as a signal to immediately output a beacon RTGC message.

b. The SRRR performs two specific functions; reformats Mode S search reports to CD-2/ASR-9 formatted search reports, and outputs a canned search RTGC report when a azimuth synchronization message is received. A functional flowchart of the SRRR is shown in figure 11. Figure 12 shows the general output format of the Mode S search message along with the corresponding CD-2/ASR-9 format after SRRR reformatting. Figure 13 shows the azimuth synchronization message along with the CD-2/ASR-9 formatted Search RTGC message after SRRR processing.

c. The WMPR purges all weather messages loaded into the input data buffer.

d. The purpose of the SMOR is to load a simulated status message in the output buffer for transmission. Status messages are disseminated randomly at an approximate rate of one per scan averaged over a period of 10 minutes or longer. The SMOR is executed each time a Mode S surveillance message is successfully reformatted.

A functional flowchart for the SMOR is presented in figure 14. Referring to figure 14, each time the SMOR is executed a 15-bit maximum sequence counter is updated. The content of this counter is then compared to an upper and lower threshold. If the count falls between the two thresholds the routine will output a status message. The thresholds are set to allow one status message to be transmitted for every 128 surveillance messages.

SIMULATION AND DIAGNOSTIC MODULE (SDM). The purpose of the SDM is to assist in debugging the serial data reformatter equipment during fabrication and later as a verification tool prior to each test. This module can verify the operational status of each reformatter channel without external test equipment. Also the integrity of the SDM can be verified in a self diagnostic mode. The functional blocks of the SDM, figure 15, are similar to those of the reformatting channels.




FIGURE 7. FLOWCHART FOR BEACON REPORT REFORMATTING ROUTINE

BIT	12	11	10	9	8	7	6	5	4	3	2	1	0
FRM	0	1	1	0	X	X	X	X	X	X	1	0	X
IN													ODD
1	TEST MESSAGE IDENT 3/A C IDNT R/R 7700 7600 FAA RDR												PRTY
OUT													ODD
	TEST MESSAGE IDENT 3/A C IDNT R/R 7700 7600 FAA AF												PRTY
=====													
IN	MSB = 128 NM.												ODD
2	----- RANGE -----												PRTY
OUT	MSB = 32 NM. LSB = 1/64 NM.												ODD
	----- RANGE -----												PRTY
=====													
IN	LSB = 1/128 NM; MSB = 180												ODD
3	<-- RG --> <----- AZIMUTH ----->												PRTY
OUT	MSB = 180 LSB = .088												ODD
	----- AZIMUTH -----												PRTY
=====													
IN	LSB = .044 X X X X												ODD
4	<----- AZ -----> CONF TRAN FTF MODE; <----- TIS ----->												PRTY
OUT	0 0 0 0 0 0 X X X X 0 0												ODD
	1 1/2 1/4 1/8 R/L MTI												PRTY
	AIMS S S DISC M2 M3/A <----- TIS -----> FLAG FLAG												PRTY
=====													
IN													ODD
5	----- MODE 3/A -----												PRTY
OUT													ODD
	----- MODE 3/A -----												PRTY
=====													
IN													ODD
6	----- SFN -----												PRTY
OUT	0000 (OCT)												ODD
	----- MODE 2 -----												PRTY
=====													
IN													ODD
7	----- MODE C -----												PRTY
OUT													ODD
	----- MODE C -----												PRTY

FIGURE 8. MODE S ATRCBS BCN REPORT AND CD-2/ASR-9 BCN REPORT FORMATS

\ BIT	12	11	10	9	8	7	6	5	4	3	2	1	0	
FRM \														
IN	1	1	1	0	X	X	X	X	X	X	1	0	ODD	
1	TEST	MESSAGE	IDENT	3/A	C	IDNT	R/R	7700	7600	FAA	RDR	PRTY		
OUT	0	1	1	0	X	X	X	X	X	X	1	1	ODD	
	TEST	MESSAGE	IDENT	3/A	C	IDNT	R/R	7700	7600	FAA	AF	PRTY		
=====														
IN	MSB = 129 NM.												ODD	
2	----- RANGE -----												PRTY	
OUT	MSB = 32 NM.						LSB = 1/64 NM.						ODD	
	----- RANGE -----												PRTY	
=====														
IN	LSB = 1/128 NM			MSB = 180									ODD	
3	----- RG -----			----- AZIMUTH -----										PRTY
OUT	MSB = 190									LSB = .088				ODD
	----- AZIMUTH -----												PRTY	
=====														
IN	LSB = .044			0	0	0	0	X	X	X	X			ODD
4	----- AZ -----			CONF	TRAN	FTF	MODE	----- TIS -----						PRTY
OUT	0	0	0	0	0	0	X	X	X	X	0	0	ODD	
	AIMS	S	S	DISC	M2	M3/A	----- TIS -----				FLAG	FLAG	PRTY	
=====														
IN	1	1	1	0	1	0	1	0	1	1	1	0	ODD	
5	----- MODE 3/A -----												PRTY	
OUT	7256 (OCT)												ODD	
	----- MODE 3/A -----												PRTY	
=====														
IN													ODD	
6	----- SFN -----												PRTY	
OUT	0000 (OCT)												ODD	
	----- MODE 2 -----												PRTY	
=====														
IN													ODD	
7	----- MODE C -----												PRTY	
OUT													ODD	
	----- MODE C -----												PRTY	

FIGURE 9. MODE S ATRBS CPME REPORT AND CD-2/ASR-9 BCN REPORT FORMATS

BIT	12	11	10	9	8	7	6	5	4	3	2	1	0
FRM													
IN	1	1	1	0	1	0	0	0	0	0	1	0	ODD
1	TEST MESSAGE IDENT 3/A C IDNT R/R 7700 7600 FAA RDR PRTY												
OUT	1	1	1	0	1	0	0	0	0	0	1	1	ODD
	TEST MESSAGE IDENT 3/A C IDNT R/R 7700 7600 FAA AF PRTY												
IN	0	0	1	1	1	0	0	0	0	0	0	0	ODD
2	56 NAUTICAL MILES												
OUT	RANGE												
	1	1	1	0	0	0	0	0	0	0	0	0	ODD
	56 NAUTICAL MILES												
IN	0	0	0	1	0	0	0	0	0	0	0	0	ODD
3	RG AZIMUTH												
OUT	180 DEGREES												
IN	0	0	0	0	0	0	0	0	X	X	X	X	ODD
4	LSB = .044 CODE RELAY 1 1/2 1/4 1/8												
OUT	AZ CONF TRAN FTF MODE TIS												
IN	0	0	0	0	0	0	X	X	X	X	1	0	ODD
5	7777 (OCT)												
OUT	MODE 3/A												
IN	0	0	0	0	0	0	0	0	0	0	0	0	ODD
6	0000 (OCT)												
OUT	MODE 2												
IN	0	0	0	0	0	0	0	0	0	0	0	0	ODD
7	0000 (OCT)												
OUT	MODE C												

FIGURE 10. MODE S BCN STROBE MESSAGE AND CD-2/ASR-9 BCN RTQC MESSAGE FORMATS




FIGURE 11. FLOWCHART FOR SEARCH REPORT REFORMATTING ROUTINE

BIT	12	11	10	9	8	7	6	5	4	3	2	1	0
FRM													
IN	0	1	1	0	0	0	0	0	0	0	1	1	ODD
1	TEST MESSAGE IDENT			S	S	S	S	S	S	FAA	RDR	PRTY	
OUT	0	0	0	1	1	0	1	1	0	0	1	1	ODD
	TEST			SEARCH HEADER						FAA	AF	PRTY	
IN	MSB = 128 NM.												ODD
2	RANGE												PRTY
OUT	MSB = 32 NM.						LSB = 1/64 NM.						ODD
	RANGE												PRTY
IN	LSB = 1/128 NM; MSB = 180												ODD
3	RG			AZIMUTH									PRTY
OUT	MSB = 180						LSB = .088						ODD
	AZIMUTH												PRTY
IN	LSB = .044			0	0	X	X	X	X	X	X	X	ODD
4	AZ			AIMS	S	TIME-IN-STORAGE						PRTY	
OUT	0	0	0	X	X	X	X	X	X	0	0	ODD	
	AIMS	S	FLAG	GT	CONF	TIS			S	FLAG	PRTY		
IN	DOPPLER #1												ODD
5	DOPPLER #1						DOPPLER #2						PRTY
OUT	IDLE												EVEN
IN	SFN												ODD
6	SFN												PRTY
OUT	IDLE												EVEN
IN	X	X	X	X	X	X			0	1/0	1	0	ODD
7	GT	CONF				FTF	GF	S					PRTY
OUT	IDLE												EVEN

FIGURE 12. MODE S SEARCH REPORT AND CD-2/ASR-9 SEARCH REPORT FORMATS

\ BIT	12	11	10	9	8	7	6	5	4	3	2	1	0
FRM \													
IN	0	1	1	0	0	0	0	0	0	1	1		ODD
1	MESSAGE IDENT				S	S	S	S	S	S	FAA	RDR	PRTY
OUT	1	0	0	1	0	0	1	0	0	0	1	1	ODD
	TEST: <----- SEARCH RTGC HEADER ----->										FAA	AF	PRTY
IN	1	1	1	1	1	1	1	1	1	1	1	1	ODD
2	MSB = 128 NM.												
	<----- RANGE ----->												
OUT	1	1	1	0	0	0	0	0	0	0	0	0	ODD
	MSB = 32 NM.						LSB = 1/64 NM.						
	<----- RANGE ----->												
IN	1	1	1	0	0	0	0	0	0	0	0	0	ODD
3	LSB = 1/128 NM			MSB = 180 DEGREES									
	<-- RG -->			<----- AZIMUTH ----->									
OUT	0	0	0	0	0	0	0	0	0	0	0	0	ODD
	<----- AZIMUTH ----->												
IN					0	0	X	X	X	X	X	X	ODD
4	LSB = .044			AZ			AIMS			S			
	<----- AZ ----->			AIMS			S			<----- TIME-IN-STORAGE ----->			
OUT	0	0	0	0	0	0	X	X	X	X	0	0	ODD
	<----- RUN LENGTH ----->						1 1/2; 1/4 1/8			S S			
IN													ODD
5	<----- DOPPLER #1 ----->						<----- DOPPLER #2 ----->						
OUT	<----- IDLE ----->												
IN													ODD
6	<----- SFN ----->												
OUT	<----- IDLE ----->												
IN									0	0	0	0	ODD
7	QT	<----- CONF ----->				FTF	GF	S	S	S	S		
OUT	<----- IDLE ----->												

FIGURE 13. MODE S SYNCH MESSAGE AND CD-2/ASR-9 SEARCH RTGC MESSAGE FORMATS




FIGURE 14. FLOWCHART FOR STATUS MESSAGE OUTPUT ROUTINE




FIGURE 15. FUNCTIONAL BLOCK DIAGRAM OF THE SIMULATION AND DIAGNOSTIC MODULE

The operator interacts with this module through 16 address switches and an address mode select switch located on the front panel. The operator can select either the normal mode, the by-pass mode, or the test mode of operation. In the normal mode the channels are configured to accept external clock signals from the modems and receive external data from the Mode S via the front panel connectors. In the by-pass mode the channels are logically removed to allow Mode S surveillance data to pass to the modems unmodified. In the test mode both channels receive simulated modem clock and simulated Mode S surveillance data from the SDM and transmit reformatted surveillance data back to the SDM. The SDM and channel input and output lines are automatically configured for the appropriate test routine selected. When each test routine is completed the equipment automatically reconfigures back to the normal mode.

The serial data reformatter can generate target scenarios providing a fourth mode of operation. The target scenario is resident in PROMs which replace the SDM PROMs housing the diagnostic routines. The SDM transmits reports to the channels defined by the target scenario. These reports are in the format specified in report No. FAA-RD-80-14. The target reports are reformatted by the channels and then appropriately disseminated.

SDM DIAGNOSTIC SOFTWARE. Six diagnostic and simulation programs currently make up the test package for the serial data reformatter equipment. The six test programs are as follows:

- Continuous Message Dissemination (CMD)
- Status Dissemination Check (SDC)
- SDM Verification Routine (SVR)
- Channel #1 Verification Routine (CVR-1)
- Channel #2 Verification Routine (CVR-2)
- Verification Routine Check (VRC)

All six programs are similar in operating principle. Each program transmits a predetermined data set either to a channel or back to the SDM, and receives returning data. The data received is then compared to a data set that is expected. Program listings for the SDM are provided in appendix D.

Each program builds a transmit file from two available transmit data sets. Each transmit set is divided into eight blocks, each block contains eight frames. A Mode S surveillance message succeeded by an idle character is stored in each block except for the first block which has all idle characters. Table 1 shows the seven messages in the order they appear in transmit data set 1. Table 2 shows the reformatted message types that correspond to table 1. This table is referred to as the lookup data set and consists of seven blocks.

Transmit data set 2 contains similar messages to those of transmit data set 1. However each message in this set either has incorrect parity, an improper header, or different message content. Table 3 lists the messages along with their changes in the order in which they appear in the transmit set. This set is used only by VRC.

Table 1. Transmit Data Set #1

Block No.	Mode S Message Type
1	Idle Characters
2	ATCRBS CPME Report
3	Special Beacon Strobe Message
4	First Regular Beacon Report
5	First Regular Search Report
6	Azimuth Synchronization Message
7	Second Regular Search Report
8	Second Regular Beacon Report

Table 2. Lookup Data Set

Block No.	CD-2/ASR-9 Message Type
1	Regular Beacon Report
2	Beacon RTQC Report
3	First Regular Beacon Report
4	First Regular Search Report
5	Search RTQC Report
6	Second Regular Search Report
7	Second Regular Beacon Report

Table 3. Transmit Data Set #2

Block No.	Mode S Message Type
1	Idles preceding Weather Message
2	ATCRBS CPME Report/Frame 4 bad parity
3	Special Beacon Strobe Message/Diff. time-in-storage
4	First Regular Beacon Report/Frame 2 bad parity
5	First Regular Search Report/Diff. Azimuth
6	Azimuth Synchronization Message/Diff. time-in-storage
7	Second Regular Search Report/Header incorrect
8	Second Regular Beacon Report/Diff. range & 3/A code

1. Continuous Message Dissemination - The purpose of this test routine was to primarily assist in debugging system hardware and software. When executed the CMD continuously transmits a single message to both channels and to itself. Each message transmitted is separated by an idle character. The particular message is selected from transmit data set 1 via address switches 5, 6, and 7. This high repetition mode enables the use of an oscilloscope to quickly probe hardware problems or the use of a logic analyzer for software debugging.

2. Status Dissemination Check - The purpose of the SDC was initially to verify the operation of a software implemented 15-bit maximum sequence generator. It is also used to verify the upper and lower threshold settings which determine the rate status messages are generated by each channel. The SDC accomplishes this by continuously transmitting the first regular Mode S search message to channel #1 and monitoring its output. While the SDC is running the number of messages being reformatted or the number of status messages being received can be monitored on the SDM LED display. The information displayed is selected via address switches 5, 6, and 7. The routine automatically terminates when one complete sequence by the maximum sequence generator is detected. The number of reformatted messages counted represents the maximum sequence count and the ratio of the number of status messages counted to the number of reformatted messages counted represents the status dissemination rate.

3. SDM Verification Routine - The purpose of the SVR test is to verify the operational status of the SDM. The routine accomplishes this by transmitting the first 2 blocks of transmit data set 1 through the parallel-to-serial register and immediately receiving the data back through the serial-to-parallel register. The operational integrity of the SDM is verified by comparing the data transmitted with the data received. For this test both data sets should be identical.

4. Channel #1 Verification Routine - The purpose of CVR-1 is to verify the operational status of channel #1. The routine accomplishes this by transmitting the data in transmit data set 1 to channel #1 and storing the reformatted data returned from channel #1 in RAM. The stored data is then compared to data in the lookup data set. The routine will provide general information based on the results of the comparison. The information provided, such as, which message or messages were formatted incorrectly or were not received, is stored in a system status file resident in RAM.

5. Channel #2 Verification Routine - The CVR-2 verifies the operational status of Channel #2 by performing the same functions as CVR-1.

6. Verification Routine Check - The purpose of VRC is to verify the integrity of the fault detection routines of the channel verification programs. This program is basically the same as the channel verification programs except that one message from transmit set 2 replaces its corresponding message in transmit set 1 when the transmit file is built. The particular fault message is selected via

the address switches 5, 6, and 7. The fault messages are designed for two reasons. The first reason is to exercise various routines in channel software, such as, detecting messages with incorrect parity, purging weather messages, and resynchronizing to the input data stream after receiving an illegal message. The second reason is to exercise various fault determining routines of the verification programs, such as, identifying missing messages or identifying incorrectly formatted messages.

SDM SCENARIO SOFTWARE. One target scenario routine is currently available. The purpose of this scenario routine is to assist in debugging ARTS IIIA software by providing a known surveillance input to the ARTS IIIA. While this routine is running the serial data reformatter equipment disseminates two real time quality control reports each scan, thereby simulating a scan rate of 4.7 seconds. This routine generates surveillance reports in a pattern of two rings of targets. Each ring contains 16 target reports equally separated in azimuth. One ring consists of beacon reports at a range of 45 nautical miles. The second ring consists of search reports at a range of 40 nautical miles. The operator has the option of disseminating the beacon reports and/or, the search reports via address switches 1 and 2, respectively.

SUMMARY.

The purpose for the serial data reformatter equipment is to support the test and evaluation of a prototype interface to be used with the implementation of the Mode S. In general, the reformatter consists of two serial reformatting channels which are connected between the two Mode S surveillance input/output ports and the digital side of two modems using four connecting cables which are provided. Beacon and search reports outputted by the Mode S are reformatted to the CD-2/ASR-9 format and then disseminated to the ARTS IIIA. A beacon RTQC report or a search RTQC report is generated each time a special beacon strobe message or an azimuth syncn message is received, respectively. These messages will be used by the ARTS IIIA to maintain azimuth synchronization as well as to check Mode S validity. In addition, status messages are randomly disseminated to the ARTS IIIA to demonstrate that the ARTS IIIA can receive and recognize such messages. The reformatter also contains a diagnostic package to aid in isolating internal hardware and software faults.

APPENDIX A

BASELINE FORMATS
FOR THE
MODE S/ARTS IIIA
INTERFACE TESTS

May 18, 1982
REVISION-1

BIT CNT :	12 :	11 :	10 :	9 :	8 :	7 :	6 :	5 :	4 :	3 :	2 :	1 :	0 :		
FLD CNT :	:	:	:	:	:	:	:	:	:	:	1 :	1 :	:		
1 :	TEST :	1 :	1 :	MODE :	MODE :	MODE :	IDENT :	RADAR :	7700 :	7600 :	FAA :	AF :	PRTY :		
:	:	:	:	2 :	3/A :	C :	:	REINF :	:	:	:	:	:		
:	1 :	2 :	3 :	4 :	5 :	6 :	7 :	8 :	9 :	10 :	11 :	12 :	13 :	MSG BIT NO.	
2 :	MSB :	:	:	:	:	:	:	:	:	:	:	LSB :	:		
:	32 :	16 :	8 :	4 :	2 :	1 :	1/2 :	1/4 :	1/8 :	1/16 :	1/32 :	1/64 :	PRTY :		
:	nmi :	:	:	:	:	:	:	:	:	:	:	nmi :	:		
:	:	:	:	RANGE (12)				:	:	:	:	:	:	:	
:	14 :	15 :	16 :	17 :	18 :	19 :	20 :	21 :	22 :	23 :	24 :	25 :	26 :	MSG BIT NO.	
3 :	MSB :	:	:	:	:	:	:	:	:	:	:	LSB :	:		
:	2048 :	1024 :	512 :	256 :	128 :	64 :	32 :	16 :	8 :	4 :	2 :	1 :	PRTY :		
:	ACP :	:	:	:	:	:	:	:	:	:	:	ACP :	:		
:	:	:	:	AZIMUTH (12)				:	:	:	:	:	:	:	
:	27 :	28 :	29 :	30 :	31 :	32 :	33 :	34 :	34 :	34 :	37 :	38 :	39 :	MSG BIT NO.	
4 :	AIMS :	MSB :	LSB :	:	:	:	MSB :	:	:	:	LSB :	:	:		
:	PRES- :	:	:	DIS- :	MODE :	MODE :	1 :	1/2 :	1/4 :	1/8 :	R/L :	MTI :	PRTY :		
:	ENT :	:	:	CRETE :	2 "X" :	3/A "X" :	SEC :	:	:	SEC :	FLAG :	FLAG :	:		
:	:	AIMS CODE (2) :	:	:	:	:	TIME IN STORAGE (4) :	:	:	:	:	:	:		
:	40 :	41 :	42 :	43 :	44 :	45 :	46 :	47 :	48 :	49 :	50 :	51 :	52 :	MSG BIT NO.	

A-2

Beacon Target Message Format (Part 1)

May 14, 1982

BIT CNT :	12	:	11	:	10	:	9	:	8	:	7	:	6	:	5	:	4	:	3	:	2	:	1	:	0	:		
FLD CNT :	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:		
5	:	A4	:	A2	:	A1	:	B4	:	B2	:	B1	:	C4	:	C2	:	C1	:	D4	:	D2	:	D1	:	PRTY	:	
	:		:		:		:		:		:		:		:		:		:		:		:		:		:	
	:		:		:		:		:		:		:		:		:		:		:		:		:		:	
	:	53	:	54	:	55	:	56	:	57	:	58	:	59	:	60	:	61	:	62	:	63	:	64	:	65	:	MSG BIT NO.
6	:	D4	:	C1	:	A1	:	C2	:	A2	:	C4	:	A4	:	B1	:	D1	:	B2	:	D2	:	B4	:	PRTY	:	
	:		:		:		:		:		:		:		:		:		:		:		:		:		:	
	:		:		:		:		:		:		:		:		:		:		:		:		:		:	
	:	66	:	67	:	68	:	69	:	70	:	71	:	72	:	73	:	74	:	75	:	76	:	77	:	78	:	MSG BIT NO.
7	:	SIGN	:		:		:		:		:		:		:		:		:		:		:		:		:	
	:	0=+	:	102400	:	51200	:	25600	:	12800	:	6400	:	3200	:	1600	:	800	:	400	:	200	:	100	:	PRTY	:	
	:	1=-	:		:		:		:		:		:		:		:		:		:		:		:		:	
	:		:		:		:		:		:		:		:		:		:		:		:		:		:	
	:		:		:		:		:		:		:		:		:		:		:		:		:		:	
	:	79	:	80	:	81	:	82	:	83	:	84	:	85	:	86	:	87	:	88	:	89	:	90	:	91	:	MSG BIT NO.

A-3

Beacon Target Message Format (Part 2)

May 18, 1982
REVISION-1

BIT CNT :	12	11	10	9	8	7	6	5	4	3	2	1	0	:
FLD CNT :	:	:	:	0	:	:	:	0	0	0	1	1	:	:
1	1	1	1	MODE	MODE	MODE	IDENT	RADAR	7700	7600	FAA	AF	PRTY	:
:	:	:	:	2	3/A	C	:	REINF	:	:	:	:	:	:
:	1	2	3	4	5	6	7	8	9	10	11	12	13	MSG BIT NO.
2	MSB	16	8	4	2	1	1/2	1/4	1/8	1/16	1/32	1/64	PRTY	:
:	nmi	:	:	RANGE (12)				:	:	:	:	nmi	:	:
:	14	15	16	17	18	19	20	21	22	23	24	25	26	MSG BIT NO.
3	MSB	1024	512	256	128	64	32	16	8	4	2	1	PRTY	:
:	ACP	:	:	AZIMUTH (12)				:	:	:	:	ACP	:	:
:	27	28	29	30	31	32	33	34	34	34	37	38	39	MSG BIT NO.
4	MSB	32	16	8	4	2	1	1/2	1/4	1/8	R/L	MTI	PRTY	:
:	ACP	:	:	BEACON RUNLENGTH REPORTING (6)		TIME IN STORAGE (4)		:	:	SEC	FLAG	FLAG	:	:
:	40	41	42	43	44	45	46	47	48	49	50	51	52	MSG BIT NO.

4-4

Beacon RTQC Message Format (Part 1)

May 14, 1982

BIT CNT :	12 :	11 :	10 :	9 :	8 :	7 :	6 :	5 :	4 :	3 :	2 :	1 :	0 :
FLD CNT :	:	:	:	:	:	:	:	:	:	:	:	:	:
5 :	A4 :	A2 :	A1 :	B4 :	B2 :	B1 :	C4 :	C2 :	C1 :	D4 :	D2 :	D1 :	PRTY :
:	:	:	:	MODE 3/A CODE (12)				:	:	:	:	:	:
:	53 :	54 :	55 :	56 :	57 :	58 :	59 :	60 :	61 :	62 :	63 :	64 :	65 :
:	:	:	:	:	:	:	:	:	:	:	:	:	MSG BIT NO.
6 :	D4 :	C1 :	A1 :	C2 :	A2 :	C4 :	A4 :	B1 :	D1 :	B2 :	D2 :	B4 :	PRTY :
:	:	:	:	MODE 2 CODE (12)				:	:	:	:	:	:
:	66 :	67 :	68 :	69 :	70 :	71 :	72 :	73 :	74 :	75 :	76 :	77 :	78 :
:	:	:	:	:	:	:	:	:	:	:	:	:	MSG BIT NO.
7 :	SIGN :	:	:	:	:	:	:	:	:	:	:	:	:
:	0=+ :	102400 :	51200 :	25600 :	12800 :	6400 :	3200 :	1600 :	800 :	400 :	200 :	100 :	PRTY :
:	1=- :	:	:	MODE C ALTITUDE (11)				:	:	:	:	:	:
:	79 :	80 :	81 :	82 :	83 :	84 :	85 :	86 :	87 :	88 :	89 :	90 :	91 :
:	:	:	:	:	:	:	:	:	:	:	:	:	MSG BIT NO.

Beacon RTQC Message Format (Part 2)

A-5

May 18, 1982
REVISION-1

BIT CNT :	12 :	11 :	10 :	9 :	8 :	7 :	6 :	5 :	4 :	3 :	2 :	1 :	0 :	
FLD CNT :	:	:	:	:	:	:	:	:	:	:	1 :	1 :	:	
1 :	TEST :	0 :	0 :	1 :	1 :	0 :	1 :	1 :	0 :	0 :	FAA :	AF :	PRTY :	
:	:	:	:	:	:	:	:	:	:	:	:	:	:	
:	1 :	2 :	3 :	4 :	5 :	6 :	7 :	8 :	9 :	10 :	11# :	12# :	13 :	
:	:	:	:	:	:	:	:	:	:	:	:	:	MSG BIT NO.	
2 :	MSB :	32 :	16 :	8 :	4 :	2 :	1 :	1/2 :	1/4 :	1/8 :	1/16 :	1/32 :	1/64 :	
:	nmi :	:	:	:	:	:	:	:	:	:	:	:	PRTY :	
:	:	:	:	:	:	:	:	:	:	:	:	:	:	
:	:	:	:	R A N G E (12)								:	:	:
:	14 :	15 :	16 :	17 :	18 :	19 :	20 :	21 :	22 :	23 :	24 :	25 :	26 :	
:	:	:	:	:	:	:	:	:	:	:	:	:	MSG BIT NO.	
3 :	MSB :	2048 :	1024 :	512 :	256 :	128 :	64 :	32 :	16 :	8 :	4 :	2 :	1 :	
:	ACP :	:	:	:	:	:	:	:	:	:	:	:	PRTY :	
:	:	:	:	:	:	:	:	:	:	:	:	:	:	
:	:	:	:	A Z I M U T H (12)								:	:	:
:	27 :	28 :	29 :	30 :	31 :	32 :	33 :	34 :	34 :	34 :	37 :	38 :	39 :	
:	:	:	:	:	:	:	:	:	:	:	:	:	MSG BIT NO.	
:	0 :	0 :	:	:	:	:	:	:	:	:	:	0 :	:	
4 :	AIMS :	MSB :	RADAR:	QUAL~ :	MSB :	LSB :	MSB :	:	:	:	LSB :	:	:	
:	PRES- :	AIMS :	INDI- :	ITY :	:	:	1 :	1/2 :	1/4 :	1/8 :	0 :	MTI :	PRTY :	
:	ENT :	CODE :	CATOR:	BIT :	:	:	SEC :	:	:	Sec :	:	FLAG :	:	
:	:	:	:	:	:	:	:	:	:	:	:	:	:	
:	:	:	:	:	CONFIDENCE(2):				TIME IN STORAGE (4)				:	:
:	40 :	41 :	42# :	43 :	44 :	45 :	46 :	47 :	48 :	49 :	50 :	51 :	52 :	
:	:	:	:	:	:	:	:	:	:	:	:	:	MSG BIT NO.	

Search Message Format

A-6

May 18, 1982
REVISION-1

BIT CNT : 12 : 11 : 10 : 9 : 8 : 7 : 6 : 5 : 4 : 3 : 2 : 1 : 0 :

FLD CNT	12	11	10	9	8	7	6	5	4	3	2	1	0	
1	1	0	0	1	0	0	1	0	0	0	FAA	AF	PRTY	
	1	2	3	4	5	6	7	8	9	10	11	12	13	MSG BIT NO.
2	MSB 32 nmi	16	8	4	2	1	1/2	1/4	1/8	1/16	1/32	1/64 nmi	PRTY	
	RANGE (12)													
	14	15	16	17	18	19	20	21	22	23	24	25	26	MSG BIT NO.
3	MSB 2048 ACP	1024	512	256	128	64	32	16	8	4	2	1 ACP	PRTY	
	AZIMUTH (12)													
	27	28	29	30	31	32	33	34	34	34	37	38	39	MSG BIT NO.
4	MSB 256 ACP	128	64	32	16	8	1	1/2	1/4	1/8	0	0	PRTY	
	RUN LENGTH (6)						TIME IN STORAGE (4)							
	40	41	42	43	44	45	46	47	48	49	50	51	52	MSG BIT NO.

Search RTQC Message Format

A-7

May 18, 1982
REVISION-1

BIT CNT : 12 : 11 : 10 : 9 : 8 : 7 : 6 : 5 : 4 : 3 : 2 : 1 : 0 :

FLD CNT	12	11	10	9	8	7	6	5	4	3	2	1	0	
1	TEST	0	0	0	1	1	0	0	0	0	FAA	AF	PRTY	
	1	2	3	4	5	6	7	8	9	10	11	12	13	MSG BIT NO.
	0	0	0	0	0	0	0	0	0	0	0	0		
2													PRTY	
	14	15	16	17	18	19	20	21	22	23	24	25	26	MSG BIT NO.
	0	0	0	0	0	0	0	0	0	0	0	0		
3													PRTY	
	27	28	29	30	31	32	33	34	34	34	37	38	39	MSG BIT NO.
	0	0	0	0	0	0	0	0	0	0	0	0		
4													PRTY	
	40	41	42	43	44	45	46	47	48	49	50	51	52	MSG BIT NO.

Status Message Format

8-A


May 14, 1982





BIT CNT :	12	:	11	:	10	:	9	:	8	:	7	:	6	:	5	:	4	:	3	:	2	:	1	:	0	:
FLD CNT :	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:	:
0	0	:	0	:	0	:	1	:	1	:	1	:	1	:	1	:	1	:	1	:	1	:	1	:	1	:
:	1	:	2	:	3	:	4	:	5	:	6	:	7	:	8	:	9	:	10	:	11	:	12	:	13	MSG BIT NO.

Idle Message Format

APPENDIX B


DETAILED LOGIC SCHEMATICS
FOR THE
SERIAL DATA REFORMATTER EQUIPMENT






I/O PERIPHERAL CARD #1

NOTE: 3KΩ PULL-UP
RESISTOR ON ALL
THREE CONTROL SIGNALS.









I/O PERIPHERAL CARD # 1

B-4





I/O PERIPHERAL CARD #1







NOTE: 3K Ω PULL-UP
RESISTOR ON ALL
THREE CONTROL SIGNALS.







I/O PERIPHERAL, CARD #2









SIMULATION CARD



SIMULATION CARD



FRONT PANEL



CARD CAGE BACKPLANE

APPENDIX C

PROGRAM LISTING FOR
REFORMATTING CHANNELS

M68SAM IS THE PROPERTY OF MOTOROLA SPD, INC.
COPYRIGHT 1974 TO 1975 BY MOTOROLA INC

MOTOROLA M6800 CROSS ASSEMBLER, RELEASE 1.2

```

00001          NAM      MODE      S/ARTS IIIA INTERFACING
00002          *****
00003          *                               9-07-82
00004          *                               TAPE1 P100/18496
00005          *      HARDWARE DEFINITION      USER.EFM.MT01
00006          *
00007          *
00008          *      RAM      0000 - 03FF
00009          *
00010          *      PIA0     5800 - 5803
00011          *
00012          *      PIA1     5804 - 5807
00013          *
00014          *      DISPLAY  5808          SYSTEM MONITOR
00015          *
00016          *      PROM     C000 - CFFF      MEMORY ALLOCATION
00017          *
00018          *                               OUTPUT INTERRUPT ROUTINE      C800 - C8FF
00019          *                               INPUT INTERRUPT ROUTINE      C900 - C9FF
00020          *                               MAIN PROGRAM                  CA00 - CFF7
00021          *                               INTERRUPT VECTORS            CFF8 - CFFF
00022          *
00023          *
00024          *****
00025          *****      RAM DATA BUFFERS      *****
00026          *****
00027          ORG      0
00028          0000 006B      INBUF RMB      $6B      INPUT DATA BUFFER
00029          0068 006B      OUTBUF RMB     $6B      OUTPUT DATA BUFFER
00030          *****
00031          *****      RAM DATA BUFFER POINTERS *****
00032          *****
00033          00D0 0000      WIN      FDB      0      INPUT BUFFER WRITE POINTER
00034          00D2 0000      RIN      FDB      0      INPUT BUFFER READ POINTER
00035          00D4 0000      WOT      FDB      0      OUTPUT BUFFER WRITE POINTER
00036          00D6 0000      ROT      FDB      0      OUTPUT BUFFER READ POINTER
00037          00D8 0000      RNG      FDB      0      RANDOM NO. GEN. SHIFT REGISTER
00038          *****
00039          *****      BUFFER FIXED BOUNDARIES *****
00040          *****
00041          0000      BEGIN EQU      INBUF      INPUT BUFFER LOWER BOUNDARY
00042          006B      ENDIN EQU     INBUF+104    INPUT BUFFER UPPER BOUNDARY
00043          0068      BEGOT EQU     OUTBUF      OUTPUT BUFFER LOWER BOUNDARY
00044          00D0      ENDOT EQU     OUTBUF+104  OUTPUT BUFFER UPPER BOUNDARY
00045          *****
00046          *****      BUFFER ADJUSTABLE BOUNDARIES *****
00047          *****

```

C-2

```

00048 00DA 00      DENDIN FCB  0      INPUT BUF. ADJ. UPPER BOUNDARY
00049 00DB 00      DENDOT FCB  0      OUTPUT BUF. ADJ. UPPER BOUNDARY
00050      *****
00051      *****  CONSTANTS  *****
00052      *****
00053      001F      IDLE0 EQU  $1F      UPPER BYTE OF IDLE CHARACTER
00054      00FB      IDLE1 EQU  $FB      LOWER BYTE OF IDLE CHARACTER
00055      00FF      RTQC0 EQU  $FF      UPPER BYTE OF TRIGGER 3/A CODE
00056      00F0      RTQC1 EQU  $F0      LOWER BYTE OF TRIGGER 3/A CODE
00057      000C      STAT0 EQU  $0C      UPPER BYTE OF STATUS HEADER
00058      0030      STAT1 EQU  $30      LOWER BYTE OF STATUS HEADER
00059      0001      WTHX0 EQU  $01      UPPER BYTE OF WEATHER HEADER
00060      0030      WTHXL EQU  $30      LOWER BYTE OF WEATHER HEADER (LIGHT)
00061      0050      WTHXH EQU  $50      LOWER BYTE OF WEATHER HEADER (HEAVY)
00062      003E      THRS1 EQU  $3E      UPPER BYTE OF DISSEMINATION THRESHOLD
00063      00DF      THRS2 EQU  $DF      LOWER BYTE OF DISSEMINATION THRESHOLD
00064      *****
00065      *****  TEMPERARY STORAGE  *****
00066      *****
00067 00DC 0001      TEMP RMB  1
00068 00DB 0002      SCRATCH RMB  2
00069      *****
00070      *****  FLAGS AND COUNTERS  *****
00071      *****
00072 00DF 00      BITCNT FCB  0      BIT COUNT OF FRAME
00073 00E0 00      WRDCNT FCB  0      NO. OF FRAMES PER MESSAGE
00074 00E1 00      MESCNT FCB  0      RESET PARITY ERROR TIME OUT
00075 00E2 00      SEQFLG FCB  0      SEQUENCE IN PROCESS
00076 00E3 00      SEQCOM FCB  0      SEQUENCE COMPLETE
00077 00E4 00      LOCKUP FCB  0      SYNCHRONIZED TO INPUT DATA STREAM
00078 00E5 00      STATUS FCB  0      SURVEILLANCE CHANNEL STATUS FLAGS
00079 00E6 00      EXCLOR FCB  0      OUTPUT OF SOFTWARE EXCLUSIVE-OR
00080      *****
00081      *****  PIA ADDRESSES  *****
00082      *****
00083      5800      PIAPA0 EQU  $5800
00084      5801      PIACA0 EQU  $5801
00085      5802      PIAPB0 EQU  $5802
00086      5803      PIACB0 EQU  $5803
00087      5804      PIAPA1 EQU  $5804
00088      5805      PIACA1 EQU  $5805
00089      5806      PIAPB1 EQU  $5806
00090      5807      PIACB1 EQU  $5807
00091      *****
00092      *****  SYSTEM MONITOR  *****
00093      *****
00094      5808      SYSMON EQU  $5808
00095      *****
00096      *
00097      *
00098      *  SYSTEM STATUS AND ERRORS
00099      *

```

```

00048 00DA 00 DENDIN FCB 0 INPUT BUF. ADJ. UPPER BOUNDARY
00049 00DB 00 DENDOT FCB 0 OUTPUT BUF. ADJ. UPPER BOUNDARY
00050 *****
00051 ***** CONSTANTS *****
00052 *****
00053 001F IDLE0 EQU $1F UPPER BYTE OF IDLE CHARACTER
00054 00F8 IDLE1 EQU $F8 LOWER BYTE OF IDLE CHARACTER
00055 00FF RTQC0 EQU $FF UPPER BYTE OF TRIGGER 3/A CODE
00056 00F0 RTQC1 EQU $F0 LOWER BYTE OF TRIGGER 3/A CODE
00057 000C STAT0 EQU $0C UPPER BYTE OF STATUS HEADER
00058 0030 STAT1 EQU $30 LOWER BYTE OF STATUS HEADER
00059 0001 WTHX0 EQU $01 UPPER BYTE OF WEATHER HEADER
00060 0030 WTHXL EQU $30 LOWER BYTE OF WEATHER HEADER (LIGHT)
00061 0050 WTHXH EQU $50 LOWER BYTE OF WEATHER HEADER (HEAVY)
00062 003E THR81 EQU $3E UPPER BYTE OF DISSEMINATION THRESHOLD
00063 00DF THR82 EQU $DF LOWER BYTE OF DISSEMINATION THRESHOLD
00064 *****
00065 ***** TEMPERARY STORAGE *****
00066 *****
00067 00DC 0001 TEMP RMB 1
00068 00DD 0002 SCRATCH RMB 2
00069 *****
00070 ***** FLAGS AND COUNTERS *****
00071 *****
00072 00DF 00 BITCNT FCB 0 BIT COUNT OF FRAME
00073 00E0 00 WRDCNT FCB 0 NO. OF FRAMES PER MESSAGE
00074 00E1 00 MESCNT FCB 0 RESET PARITY ERROR TIME OUT
00075 00E2 00 SEQFLG FCB 0 SEQUENCE IN PROCESS
00076 00E3 00 SEQCOM FCB 0 SEQUENCE COMPLETE
00077 00E4 00 LOCKUP FCB 0 SYNCHRONIZED TO INPUT DATA STREAM
00078 00E5 00 STATUS FCB 0 SURVEILLANCE CHANNEL STATUS FLAGS
00079 00E6 00 EXCLOR FCB 0 OUTPUT OF SOFTWARE EXCLUSIVE-OR
00080 *****
00081 ***** PIA ADDRESSES *****
00082 *****
00083 5800 PIAPA0 EQU $5800
00084 5801 PIACA0 EQU $5801
00085 5802 PIAPB0 EQU $5802
00086 5803 PIACB0 EQU $5803
00087 5804 PIAPA1 EQU $5804
00088 5805 PIACA1 EQU $5805
00089 5806 PIAPB1 EQU $5806
00090 5807 PIACB1 EQU $5807
00091 *****
00092 ***** SYSTEM MONITOR *****
00093 *****
00094 5808 SYSHON EQU $5808
00095 *****
00096 *
00097 *
00098 * SYSTEM STATUS AND ERRORS
00099 *

```

```

00100      * D7  CURRENTLY UNUSED!
00101      * D6  SOFTWARE INTERRUPT ERROR (SWI)
00102      * D5  BEACON/SEARCH RTQC MESSAGE GENERATED (MAIN)
00103      * D4  NO IDLE CHARACTER FOUND - REINITIALIZE PROGRAM (MAIN)
00104      * D3  PARITY ERROR (MAIN)
00105      * D2  REFORMATTED DATA BEING TRANSMITTED (NMI)
00106      * D1  UNKNOWN MESSAGE FOUND (IRQ)
00107      * D0  SYSTEM SYNCHRONIZED TO INPUT DATA STREAM (IRQ)
00108      *
00109      *
00110      *****
00111      ***** INTERRUPT VECTORS *****
00112      *****
00113 CFF8      ORG  $CFF8
00114 CFF8 C900  FDB  IRQ      INPUT INTERRUPT
00115 CFFA C9EF  FDB  SWI      SOFTWARE INTERRUPT (NOT USED)
00116 CFFC C800  FDB  NMI      OUTPUT INTERRUPT
00117 CFFE CA00  FDB  INIT     POWER UP INTERRUPT
00118      *****
00119      ***** OUTPUT INTERRUPT ROUTINE *****
00120      *****
00121 C800      ORG  $C800
00122 C800 96 D7  NMI  LDA A  ROT+1  END OF OUTPUT BUFFER?
00123 C802 8B 01      ADD A  #1      IF NOT, TEST FOR DATA AVAILABLE.
00124 C804 91 DB      CMP A  DENDOT
00125 C806 23 09      BLS  B2
00126 C808 86 D0      LDA A  #DENDOT  IF YES, SET THE ADJUSTABLE UPPER
00127 C80A 97 DB      STA A  DENDOT  BOUNDARY TO MAXIMUM AND OUTPUT
00128 C80C 86 68      LDA A  #BEGOT  READ POINTER TO BEGINNING OF BUFFER.
00129 C80E 97 D7      STA A  ROT+1
00130 C810 4C      INC A
00131 C811 4A      B2  DEC A
00132 C812 91 D5      CMP A  #NOT+1  OUTPUT BUFFER EMPTY? IF YES,
00133 C814 27 1D      BEQ  B1      GENERATE AN IDLE CHARACTER.
00134 C816 DE D6      LDX  ROT      IF NOT, OUTPUT NEXT FRAME
00135 C818 8B 02      ADD A  #2      AND UPDATE OUTPUT READ POINTER.
00136 C81A 97 D7      STA A  ROT+1
00137 C81C A6 00      LDA A  0,X
00138 C81E B7 5802     STA A  PIAPB0
00139 C821 A6 01      LDA A  1,X
00140 C823 B7 5806     STA A  PIAPB1
00141 C826 96 E5      LDA A  STATUS  SET 'REFORMATTED DATA' FLAG.
00142 C828 8A 04      ORA A  #200000100
00143 C82A 97 E5      STA A  STATUS
00144 C82C B6 5802     LDA A  PIAPB0  CLEAR OUTPUT INTERRUPT FLAG.
00145 C82F B6 5806     LDA A  PIAPB1
00146 C832 3B      RTI
00147 C833 86 1F      B1  LDA A  #IDLE0  OUTPUT IDLE CHARACTER.
00148 C835 B7 5802     STA A  PIAPB0
00149 C838 86 F8      LDA A  #IDLE1
00150 C83A B7 5806     STA A  PIAPB1
00151 C83D B6 5802     LDA A  PIAPB0  CLEAR OUTPUT INTERRUPT FLAG.

```

```

00152 C840 B6 5806      LDA A  PIAPB1
00153 C843 96 E5      LDA A  STATUS      CLEAR 'REFORMATTED DATA' FLAG.
00154 C845 84 FB      AND A  #X11111011
00155 C847 97 E5      STA A  STATUS
00156 C849 3B          RTI
00157
00158                  *****
00159                  ***** INPUT INTERRUPT ROUTINE *****
00160 C900              ORG    #C900
00161 C900 96 E4      IRQ    LDA A  LOCKUP      INTERFACE SYNCHRONIZED TO INPUT
00162 C902 26 1B      BNE    A1          DATA STREAM? IF YES, TEST FOR
00163                  *                                NEXT AVAILABLE FRAME.
00164 C904 B6 5800      LDA A  PIAPAO      CLEAR INPUT INTERRUPT FLAG.
00165 C907 F6 5804      LDA B  PIAPA1      ATTEMPT TO SYNCHRONIZE INTERFACE TO
00166 C90A 81 1F      CMP A  #IDLE0      INPUT DATA STREAM BY LOCKING ON AN
00167 C90C 26 10      BNE    A2          IDLE CHARACTER. IF NO IDLE IS DE-
00168 C90E C1 FB      CMP B  #IDLE1      TECTED WAIT FOR NEXT INTERRUPT AND
00169 C910 26 0C      BNE    A2          TRY AGAIN.
00170 C912 7C 00E4      INC    LOCKUP      WHEN AN IDLE CHARACTER IS DETECTED
00171 C915 7F 00DF      CLR    BITCNT      SET THE LOCKUP FLAG AND INITIALIZE
00172 C918 96 E5      LDA A  STATUS      THE DATA BIT COUNTER. ALSO, SET THE
00173 C91A 8A 01      ORA A  #X00000001 'SYNCHRONIZED TO DATA STREAM' FLAG.
00174 C91C 97 E5      STA A  STATUS
00175 C91E 3B          RTI
00176 C91F 7C 00DF      A2    INC    BITCNT      IS THE NEXT FRAME READY? IF NOT,
00177 C922 96 DF      A1    LDA A  BITCNT      WAIT FOR THE NEXT INTERRUPT AND TEST
00178 C924 81 0D      CMP A  #13         AGAIN. IF YES, RESET BIT COUNTER
00179 C926 27 07      BEQ   A11         FOR NEXT FRAME.
00180 C928 B6 5800      LDA A  PIAPAO
00181 C92B B6 5804      LDA A  PIAPA1      CLEAR INPUT INTERRUPT FLAG.
00182 C92E 3B          RTI
00183 C92F 7F 00DF      A11  CLR    BITCNT
00184 C932 96 E2      LDA A  SEQFLG      NEW MESSAGE? IF YES,
00185 C934 27 1E      BEQ   A3          DETERMINE MESSAGE TYPE.
00186 C936 DE D0      LDX   WIN          STORE FRAME IN INPUT BUFFER.
00187 C938 B6 5800      LDA A  PIAPAO
00188 C93B F6 5804      LDA B  PIAPA1      INPUT INTERRUPT FLAG CLEARED.
00189 C93E A7 00      STA A  0,X
00190 C940 E7 01      STA B  1,X
00191 C942 96 D1      LDA A  WIN+1       UPDATE INPUT BUFFER
00192 C944 8B 02      ADD A  #2          WRITE POINTER.
00193 C946 97 D1      STA A  WIN+1
00194 C948 7A 00E0      A6    DEC    WRDCNT      DECREMENT FRAME COUNTER. THE
00195 C94B 26 D1      BNE   A2          COMPLETE MESSAGE IS STORED IF THE
00196                  *                                FRAME COUNT IS ZERO.
00197 C94D 7C 00E3      INC    SEQCOM      WHEN THE COMPLETE MESSAGE IS STORED,
00198 C950 7F 00E2      CLR    SEQFLG      SET THE 'SEQUENCE COMPLETE' FLAG AND
00199 C953 3B          RTI                CLEAR THE 'SEQUENCE IN PROCESS' FLAG.
00200 C954 B6 5800      A3    LDA A  PIAPAO
00201 C957 F6 5804      LDA B  PIAPA1      INPUT INTERRUPT FLAG CLEARED.
00202 C95A 97 DC      STA A  TEMP        IS THIS MESSAGE A SURVEILLANCE
00203 C95C 84 70      AND A  ##70        REPORT? IF NOT, GO TO A4 AND TEST

```

```

00204 C95E 81 60      CMP A  #160      FOR POSSIBLE WEATHER MESSAGE.
00205 C960 26 35      BNE   A4
00206 C962 96 E5      LDA A  STATUS   A SURVEILLANCE MESSAGE WAS CORRECTLY
00207 C964 84 FD      AND A  #X11111101 DETECTED. CLEAR 'UNDEFINED MESSAGE'
00208 C966 97 E5      STA A  STATUS   FLAG.
00209 C968 96 D1      LDA A  WIN+1    DETERMINE IF THE COMPLETE MESSAGE
00210 C96A 8B 10      ADD A  #16      PLUS AN IDLE CHARACTER CAN BE STORED
00211 C96C 81 68      CMP A  #ENDIN   IN THE INPUT BUFFER WITHOUT EXCEED-
00212 C96E 23 08      BLS   A5        ING THE INPUT BUFFER MAXIMUM UPPER
00213 C970 96 D1      LDA A  WIN+1    BOUNDARY. IF UPPER BOUNDARY IS
00214 C972 97 DA      STA A  DENDIN   EXCEEDED UPDATE THE ADJUSTABLE INPUT
00215 C974 86 00      LDA A  #BEGIN   BUFFER UPPER BOUNDARY AND SET WRITE
00216 C976 97 D1      STA A  WIN+1    POINTER TO BEGINNING OF INPUT BUFFER.
00217 C978 7C 00E2 A5 INC  SEQFIG    SET 'SEQUENCE IN PROCESS' FLAG
00218 C97B DE D0      LDX   WIN       INITIALIZE THE WORD COUNTER TO
00219 C97D 86 07      LDA A  #7        SEVEN.
00220 C97F 97 E0      STA A  WRDCNT
00221 C981 86 1F      LDA A  #IDLE0   LOAD AN IDLE CHARACTER
00222 C983 A7 00      STA A  0,X      IN THE INPUT BUFFER.
00223 C985 86 F8      LDA A  #IDLE1
00224 C987 A7 01      STA A  1,X
00225 C989 96 DC      LDA A  TEMP     LOAD THE FIRST FRAME OF THE MESSAGE
00226 C98B A7 02      STA A  2,X     IN THE INPUT BUFFER.
00227 C98D E7 03      STA B  3,X
00228 C98F 96 D1      LDA A  WIN+1    UPDATE INPUT BUFFER
00229 C991 8B 04      ADD A  #4       WRITE POINTER.
00230 C993 97 D1      STA A  WIN+1
00231 C995 20 B1      BRA   A6
00232 C997 96 DC      LDA A  TEMP     IS THIS MESSAGE A WEATHER REPORT?
00233 C999 91 01      CMP A  WTHX0   IF NOT, GO TO 74 AND TEST FOR
00234 C99B 26 3E      BNE   A7        POSSIBLE IDLE CHARACTER.
00235 C99D D1 30      CMP B  WTHXL
00236 C99F 27 04      BEQ   A12
00237 C9A1 D1 50      CMP B  WTHXH
00238 C9A3 26 3E      BNE   A9
00239 C9A5 96 E5      LDA A  STATUS   A WEATHER MESSAGE WAS CORRECTLY
00240 C9A7 84 FD      AND A  #X11111101 DETECTED. CLEAR 'UNDEFINED MESSAGE'
00241 C9A9 97 E5      STA A  STATUS   FLAG.
00242 C9AB 96 D1      LDA A  WIN+1    DETERMINE IF THE COMPLETE MESSAGE
00243 C9AD 8B 0A      ADD A  #10      PLUS AN IDLE CHARACTER CAN BE STORED
00244 C9AF 81 68      CMP A  #ENDIN   IN THE INPUT BUFFER WITHOUT EXCEED-
00245 C9B1 23 08      BLS   A8        ING THE INPUT BUFFER MAXIMUM UPPER
00246 C9B3 96 D1      LDA A  WIN+1    BOUNDARY. IF UPPER BOUNDARY IS
00247 C9B5 97 DA      STA A  DENDIN   EXCEEDED UPDATE THE ADJUSTABLE INPUT
00248 C9B7 86 00      LDA A  #BEGIN   BUFFER UPPER BOUNDARY AND SET WRITE
00249 C9B9 97 D1      STA A  WIN+1    POINTER TO BEGINNING OF INPUT BUFFER
00250 C9BB 7C 00E2 A8 INC  SEQFIG    SET 'SEQUENCE IN PROCESS' FLAG.
00251 C9BE DE D0      LDX   WIN       INITIALIZE THE FRAME
00252 C9C0 86 04      LDA A  #4       COUNTER TO 4.
00253 C9C2 97 E0      STA A  WRDCNT
00254 C9C4 86 1F      LDA A  #IDLE0   LOAD AN IDLE CHARACTER
00255 C9C6 A7 00      STA A  0,X     IN THE INPUT BUFFER.

```

```

00256 C9C8 86 F8      LDA A #IDLE1
00257 C9CA A7 01      STA A 1,X
00258 C9CC 96 DC      LDA A TEMP          LOAD THE FIRST FRAME OF THE MESSAGE
00259 C9CE A7 02      STA A 2,X          IN THE INPUT BUFFER.
00260 C9D0 E7 03      STA B 3,X
00261 C9D2 96 D1      LDA A WIN+1        UPDATE INPUT BUFFER
00262 C9D4 8B 04      ADD A #4          WRITE POINTER.
00263 C9D6 97 D1      STA A WIN+1
00264 C9D8 7E C948    JMP A6
00265 C9DB 81 1F A7    CMP A #IDLE0      IS THIS MESSAGE AN IDLE CHARACTER?
00266 C9DD 26 04      BNE A9           IF YES, RETURN FROM INTERRUPT.
00267 C9DF C1 FB      CMP B #IDLE1
00268 C9E1 27 0B      BEQ A10
00269 C9E3 7F 00E4 A9  CLR LOCKUP        IF NO, RESYNCHRONIZE INTERFACE TO
00270 C9E6 96 E5      LDA A STATUS      INPUT DATA STREAM. ALSO, SET THE
00271 C9E8 8A 02      ORA A #X0000010   'UNDEFINED MESSAGE' FLAG AND CLEAR
00272 C9EA 84 FE      AND A #X11111110 THE 'SYNCHRONIZED TO DATA STREAM'
00273 C9EC 97 E5      STA A STATUS      FLAG.
00274 C9EE 3B A10     RTI
00275 *****
00276 ***** SWI INTERRUPT *****
00277 *****
00278 C9EF 96 E5 SWI LDA A STATUS SET 'SWI ERROR' FLAG.
00279 C9F1 8A 40 ORA A #X01000000
00280 C9F3 97 E5 STA A STATUS
00281 C9F5 3B RTI
00282 *****
00283 ***** INITIALIZATION (START UP ONLY) *****
00284 *****
00285 CA00 ORG #CA00
00286 CA00 8E 03FF INIT LDS #03FF INITIALIZE STACK POINTER.
00287 CA03 86 2F LDA A #2F SET UP THE A-SIDE OF PIA'S
00288 CA05 B7 5801 STA A PIACA0 AS INPUT.
00289 CA08 B7 5805 STA A PIACA1
00290 CA0B 73 5802 COM PIAPB0 SET UP THE B-SITE OF PIA'S
00291 CA0E 73 5806 COM PIAPB1 AS OUTPUT.
00292 CA11 86 27 LDA A #27
00293 CA13 B7 5803 STA A PIACB0
00294 CA16 B7 5807 STA A PIACB1
00295 CA19 0F INITA1 SEI DISABLE INPUT INTERRUPTS.
00296 CA1A 86 00 LDA A #00 INITIALIZE INPUT BUFFER
00297 CA1C 97 D2 STA A RIN BOUNDARIES AND POINTERS.
00298 CA1E 97 D3 STA A RIN+1
00299 CA20 97 D0 STA A WIN
00300 CA22 97 D1 STA A WIN+1
00301 CA24 97 DF STA A BITCNT
00302 CA26 97 E0 STA A WRDCNT
00303 CA28 97 E1 STA A MESCNT
00304 CA2A 97 E2 STA A SEQFLG
00305 CA2C 97 E3 STA A SEQCOM
00306 CA2E 97 E4 STA A LOCKUP
00307 CA30 97 D6 STA A ROT

```

```

00308 CA32 97 D4      STA A WOT
00309 CA34 97 D9      STA A RNG+1      INIT RANDOM NO. GEN.
00310 CA36 43        COM A
00311 CA37 97 E6      STA A EXCLOR
00312 CA39 86 3F      LDA A #03F
00313 CA3B 97 DB      STA A RNG
00314 CA3D 86 68      LDA A #104
00315 CA3F 97 DA      STA A DENDIN
00316 CA41 97 D7      STA A ROT+1
00317 CA43 97 D5      STA A WOT+1
00318 CA45 86 D0      LDA A #208
00319 CA47 97 DB      STA A DENDOT
00320 CA49 86 10      LDA A #Z00010000
00321 CA4B 97 E5      STA A STATUS    SET 'NO IDLE' FLAG.
00322 CA4D 0E        CLI              ENABLE INPUT INTERRUPTS.
00323                *****
00324                ***** MAIN PROGRAM *****
00325                *****
00326 CA4E 96 E5      START LDA A STATUS    DISPLAY CURRENT STATUS.
00327 CA50 87 5B08    STA A BYSMON
00328 CA53 96 E3      LDA A SEQCOM    LOOP UNTIL A COMPLETE MESSAGE IS
00329 CA55 27 F7      BEQ START       AVAILABLE FOR PROCESSING.
00330 CA57 96 D3      LDA A RIN+1     TEST FOR ADJUSTABLE END OF INPUT
00331 CA59 8B 01      ADD A #1        BUFFER.
00332 CA5B 91 DA      CMP A DENDIN
00333 CA5D 23 08      BLB STRTA1
00334 CA5F 86 68      LDA A #ENDIN   IF ADJ. END OF INPUT BUFFER IS FOUND
00335 CA61 97 DA      STA A DENDIN   IF YES, SET THE ADJUSTABLE UPPER
00336 CA63 86 00      LDA A #BEGIN   BOUNDARY TO MAXIMUM AND INPUT READ
00337 CA65 97 D3      STA A RIN+1    POINTER TO BEGINNING OF BUFFER.
00338 CA67 DE D2      STRTA1 LDX RIN    FIND IDLE CHARACTER PRECEDING
00339 CA69 A6 00      LDA A 0,X      EACH MESSAGE. IF NOT FOUND THE
00340 CA6B E6 01      LDA B 1,X      BUFFER POINTERS ARE ASSUMED
00341 CA6D 81 1F      CMP A #IDLE0   INCORRECT AND PROGRAM REINITIALIZA-
00342 CA6F 26 AB      BNE INITA1     TION SHOULD BE PERFORMED.
00343 CA71 C1 F8      CMP B #IDLE1
00344 CA73 26 A4      BNE INITA1
00345 CA75 96 E5      LDA A STATUS   CLEAR 'NO IDLE' FLAG.
00346 CA77 84 EF      AND A #X11101111
00347 CA79 97 E5      STA A STATUS
00348 CA7B A6 02      LDA A 2,X      TEST UPPER BYTE OF FRAME FOR TARGET
00349 CA7D 84 70      AND A #070     MESSAGE I.D. IF FOUND DETERMINE
00350 CA7F 81 60      CMP A #060     ATRCBS OR SEARCH. IF NOT, GO TO
00351 CA81 27 03      BEQ STRTA2     'WXA1' FOR WEATHER MESSAGE.
00352 CA83 7E CBB5    JHP WXA1
00353 CA86 A6 03      STRTA2 LDA A 3,X
00354 CA88 48        ASL A          CHECK FOR CORRECT PARITY.
00355 CA89 24 03      BCC SRCH12
00356 CA8B 7E CBA3    JHP SRCHA4
00357 CA8E 84 10      SRCH12 AND A #010   TEST BIT 12 TO DETERMINE IF REPORT
00358 CA90 26 03      BNE SRCH       IS ATRCBS OR SEARCH. IF ATRCBS GO
00359 CA92 7E CBBE    JMP BCN       TO 'BCN', OTHERWISE CONTINUE.

```

```

00360          ***** SEARCH MESSAGE *****
00361 CA95 96 D5 SRCH LDA A WOT+1 TEST TO SEE IF A COMPLETE SEARCH
00362 CA97 8B 0A      ADD A #10 MESSAGE PLUS IDLE CHARACTER CAN BE
00363 CA99 81 D0      CMP A #ENDOT STORED IN THE OUTPUT BUFFER WITHOUT
00364 CA9B 23 08      BLS SRCHA1 EXCEEDING THE UPPER BOUNDARY. IF
00365 CA9D 96 D5      LDA A WOT+1 THE BOUNDARY IS EXCEEDED, UPDATE THE
00366 CA9F 97 DB      STA A DENDOT ADJUSTABLE UPPER BOUNDARY AND SET
00367 CAA1 86 68      LDA A #BEGOT THE OUTPUT WRITE POINTER TO
00368 CAA3 97 D5      STA A WOT+1 BEGINNING OF BUFFER.
00369          ***** SEARCH MESSAGE REFORMATTING ROUTINE *****
00370 CAA5 DE D4 SRCHA1 LDX WOT REFORMAT FIRST FRAME.
00371 CAA7 86 1B      LDA A #01B
00372 CAA9 C6 30      LDA B #030
00373 CAAB A7 00      STA A 0,X
00374 CAAD E7 01      STA B 1,X FIRST FRAME REFORMATTED.
00375 CAAF DE D2      LDX RIN REFORMAT NEXT FRAME.
00376 CAB1 A6 06      LDA A 6,X \R\R\R\A\A\A\A\A\ ACC 'A'
00377 CAB3 44        LSR A
00378 CAB4 44        LSR A
00379 CAB5 44        LSR A
00380 CAB6 44        LSR A \O\O\O\O\R\R\R\R\A\ ACC 'A'
00381 CAB7 E6 05      LDA B 5,X \P\R'R'R\R\R\O\O\O\O\ ACC 'B'
00382 CAB9 58        ASL B \R'R'R'R\R\R\O\O\O\O\ ACC 'B' C\P\
00383 CABA 24 03      BCC SRCHA7 CHECK FOR CORRECT PARITY.
00384 CABC 7E CBA3   JMP SRCHA4
00385          *****
00386          *
00387          * TEST FOR VIDEO RECONSTITUTOR SYNCHRONIZATION MESSAGE.
00388          * THE RANGE FIELD OF THIS MESSAGE IS SET TO MAXIMUM (ALL
00389          * ONE'S). THE 'CARRY' WILL BE SET AFTER ADDING ONE TO THE
00390          * LSB OF THE RANGE FIELD ONLY IF THE RANGE FIELD WAS SET
00391          * TO MAXIMUM RANGE.
00392          *
00393          *****
00394 CABF 1B SRCHA7 ABA \R'R'R'R\R\R\R\R\R\A\ ACC 'A' LO BYTE
00395 CAC0 8B 02      ADD A #2 ADD 1/128 NMI. TO RANGE FIELD.
00396 CAC2 E6 04      LDA B 4,X \R'R'R'R\R\R\R\R\R\A\ ACC 'B' HI BYTE
00397 CAC4 C9 00      ADC B #0 ACC B + ZERO + CARRY --> ACC B
00398 CAC6 24 50      BCC SRCHA2
00399          *****
00400          *
00401          * THE FOLLOWING ROUTINE WILL LOAD A SIMULATED SEARCH RTQC
00402          * MESSAGE IN THE OUTPUT BUFFER EACH TIME A SYNCH MESSAGE
00403          * IS RECEIVED.
00404          *
00405          *****
00406 CACB DE D4      LDX WOT
00407 CACA 86 92      LDA A #092 SEARCH RTQC HEADER.
00408 CACL C6 30      LDA B #030
00409 CACE A7 00      STA A 0,X
00410 CAD0 E7 01      STA B 1,X FIRST FRAME LOADED.
00411 CAD2 86 E0      LDA A #0E0 RANGE = 56 NAUTICAL MILES.

```

C-10

```

00412 CAD4 5F          CLR B
00413 CAD5 A7 02      STA A 2,X
00414 CAD7 E7 03      STA B 3,X          SECOND FRAME LOADED.
00415 CAD9 E7 04      STA B 4,X          AZIMUTH = 0 DEGREES.
00416 CADB E7 05      STA B 5,X          THIRD FRAME LOADED.
00417 CADD DE D2      LDX RIN
00418 CADF A6 07      LDA A 7,X
00419 CAE1 48          ASL A
00420 CAE2 24 03      BCC SRCHA8
00421 CAE4 7E CBA3    JMP SRCHA4
00422 CAE7 A6 0B      SRCHA8 LDA A 11,X
00423 CAE9 48          ASL A
00424 CAEA 24 03      BCC SRCHA9
00425 CAEC 7E CBA3    JMP SRCHA4
00426 CAEF A6 0D      SRCHA9 LDA A 13,X
00427 CAF1 48          ASL A
00428 CAF2 24 03      BCC SRCH10
00429 CAF4 7E CBA3    JMP SRCHA4
00430 CAF7 A6 0F      SRCH10 LDA A 15,X
00431 CAF9 48          ASL A
00432 CAFA 24 03      BCC SRCH11
00433 CAFC 7E CBA3    JMP SRCHA4
00434 CAFF A6 09      SRCH11 LDA A 9,X
00435 CB01 48          ASL A
00436 CB02 24 03      BCC SRCH13
00437 CB04 7E CBA3    JMP SRCHA4
00438 CB07 48          SRCH13 ASL A
00439 CB08 48          ASL A
00440 CB09 DE D4      LDX WOT
00441 CB0B E7 06      STA B 6,X
00442 CB0D A7 07      STA A 7,X
00443 CB0F 96 E5      LDA A STATUS
00444 CB11 84 DF      AND A #X11011111
00445 CB13 97 E5      STA A STATUS
00446 CB15 7E CBB5    JMP SRCHA5
00447 CB18 5B          SRCHA2 ASL B
00448 CB19 48          ASL A
00449 CB1A C9 00      ADC B #0
00450 CB1C 5B          ASL B
00451 CB1D 48          ASL A
00452 CB1E C9 00      ADC B #0
00453 CB20 84 F0      AND A #F0
00454 CB22 DE D4      LDX WOT
00455 CB24 E7 02      STA B 2,X
00456 CB26 A7 03      STA A 3,X
00457 CB28 DE D2      LDX RIN
00458 CB2A A6 06      LDA A 6,X
00459 CB2C E6 07      LDA B 7,X
00460 CB2E 5B          ASL B
00461 CB2F 25 72      BCS SRCHA4
00462 CB31 48          ASL A
00463 CB32 48          ASL A

```

CHECK FRAMES 3 THRU 7
FOR CORRECT PARITY.

```

\T\T\0\0\0\0\0\0\ ACC 'A'
TRANSFER 'TIS' OF SYNCH MESSAGE
TO SEARCH RTQC MESSAGE.
FORTH FRAME LOADED.

```

```

\R\R\R\R\R\R\R\R\0\ ACC 'B'
\R\R\R\R\R\R\R\R\A\0\ ACC 'A' C\R\
\R\R\R\R\R\R\R\R\ ACC 'B'
\R\R\R\R\R\R\R\R\0\ ACC 'B'
\R\R\R\R\R\R\R\R\A\0\0\ ACC 'A' C\R\
\R\R\R\R\R\R\R\R\R\ ACC 'B' HI BYTE
\R\R\R\R\R\0\0\0\0\0\ ACC 'A' LO BYTE

```

SECOND FRAME REFORMATTED.
REFORMAT NEXT FRAME.

```

\R\R\R\R\A\A\A\A\A\ ACC 'A'
\P\A\A\A\A\0\0\0\0\ ACC 'B'
\A\A\A\A\0\0\0\0\0\ ACC 'B' C\P\

```

CHECK FOR CORRECT PARITY.

```

00464 CB33 48      ASL A          \A\A\A\A\A\0\0\0\  ACC 'A'
00465 CB34 54      LSR B
00466 CB35 54      LSR B
00467 CB36 54      LSR B
00468 CB37 54      LSR B
00469 CB38 56      ROR B          \0\0\0\0\A\A\A\A\  ACC 'B'
00470 CB39 D7 DD   STA B SCRATCH \0\0\0\0\0\A\A\A\  ACC 'B' C\A\
00471 CB3B 56      ROR B          \A'\0\0\0\0\0\A\A\  ACC 'B' C\A\
00472 CB3C D7 DE   STA B SCRATCH+1 FREE UP ACC 'B'
00473 CB3E 9B DD   ADD A SCRATCH \A\A\A\A\A\A\A\A\  ACC 'A'
00474 CB40 E6 08   LDA B 8,X      \A\A\A\A\A\H\0\T\T\  ACC 'B'
00475 CB42 54      LSR B          \0\A\A\A\A\H\0\T\  ACC 'B'
00476 CB43 C4 78   AND B #97B     \0\A\A\A\A\0\0\0\  ACC 'B'
00477 CB45 DB DE   ADD B SCRATCH+1 \A'\A\A\A\A\X\A\A\  ACC 'B'
00478 CB47 C4 F0   AND B #9F0     \A'\A\A\A\0\0\0\0\  ACC 'B' LO BYTE
00479 CB49 DE D4   LDX WOT
00480 CB4B A7 04   STA A 4,X
00481 CB4D E7 05   STA B 5,X
00482 CB4F DE D2   LDX RIN
00483 CB51 E6 0B   LDA B 11,X
00484 CB53 58      ASL B
00485 CB54 25 4D   BCS SRCHA4
00486 CB56 E6 0D   LDA B 13,X
00487 CB58 58      ASL B
00488 CB59 25 48   BCS SRCHA4
00489 CB5B E6 0F   LDA B 15,X
00490 CB5D 58      ASL B
00491 CB5E 25 43   BCS SRCHA4
00492 CB60 E6 0E   LDA B 14,X
00493 CB62 17      TBA
00494 CB63 84 0C   AND A #90C     \0\0\0\0\C\C\0\0\  ACC 'A'
00495 CB65 C4 C0   AND B #9C0     \0\0\0\0\0\0\0\0\  ACC 'B'
00496 CB67 27 02   BEQ SRCHA6     SET 'D' = 1 IF 'DT' > 0.
00497 CB69 8A 10   ORA A #910     \0\0\0\1\C\C\0\0\  ACC 'B'
00498 CB6B 97 DD   STA A SCRATCH SRCHA6 FREE UP ACC 'A'.
00499 CB6D A6 09   LDA A 9,X      \P\T\T\T\T\0\0\0\  ACC 'A'
00500 CB6F 48      ASL A          \T\T\T\T\0\0\0\0\  ACC 'A'
00501 CB70 25 31   BCS SRCHA4     CHECK FOR CORRECT PARITY.
00502 CB72 84 F0   AND A #9F0     \T\T\T\T\0\0\0\0\  ACC 'A'
00503 CB74 0C      CLC
00504 CB75 49      ROL A          \T\T\T\0\0\0\0\0\  ACC 'A' C\T\
00505 CB76 49      ROL A          \T\T\0\0\0\0\0\T\  ACC 'A' C\T\
00506 CB77 16      TAB
00507 CB78 C4 C0   AND B #9C0     \T\T\0\0\0\0\0\0\  ACC 'B' LO BYTE
00508 CB7A 49      ROL A          \T\0\0\0\0\0\T\T\  ACC 'A' C\T\
00509 CB7B 84 03   AND A #903     \0\0\0\0\0\0\T\T\  ACC 'A'
00510 CB7D 9B DD   ADD A SCRATCH \0\0\0\0\C\C\T\T\  ACC 'A' HI BYTE
00511 CB7F DE D4   LDX WOT
00512 CB81 A7 06   STA A 6,X
00513 CB83 E7 07   STA B 7,X
00514 CB85 86 1F   SRCHA5 LDA A #IDLE0 LAST FRAME REFORMATTED,
00515 CB87 C6 F8   LDA B #IDLE1 ATTACH AN IDLE CHARACTER
                                AT THE END OF THE MESSAGE.

```

```

00516 CBB9 A7 0B      STA A 8,X
00517 CBB8 E7 09      STA B 9,X
00518 CBB8 96 D5      LDA A WOT+1      UPDATE OUTPUT BUFFER
00519 CBBF 8B 0A      ADD A #10        WRITE POINTER.
00520 CB91 97 D5      STA A WOT+1
00521 CB93 96 E1      LDA A MESCNT     RESET THE 'PARITY ERROR' FLAG AFTER
00522 CB95 8B 01      ADD A #1         256 CONSECUTIVE PARITY ERROR FREE
00523 CB97 97 E1      STA A MESCNT     INPUT MESSAGES HAVE BEEN FOUND.
00524 CB99 24 11      BCC SKIPAS
00525 CB9B 96 E5      LDA A STATUS
00526 CB9D 84 F7      AND A #X11110111
00527 CB9F 97 E5      STA A STATUS     CLEAR 'PARITY ERROR' FLAG.
00528 CBA1 20 09      BRA SKIPAS
00529 CBA3 96 E5      SRCHA4 LDA A STATUS
00530 CBA5 8A 08      ORA A #X00001000
00531 CBA7 97 E5      STA A STATUS     SET 'PARITY ERROR' FLAG.
00532 CBA9 7F 00E1    CLR MESCNT       CLEAR MESSAGE COUNT.
00533 CBAC 96 D3      SKIPAS LDA A RIN+1  UPDATE INPUT BUFFER
00534 CBAE 8B 10      ADD A #16        READ POINTER.
00535 CBB0 97 D3      STA A RIN+1
00536 CBB2 7E CD26    JMP RGA
00537                ***** WEATHER MESSAGE *****
00538 CBB5 96 D3      WXA1 LDA A RIN+1  PURGE THIS MESSAGE BY UPDATING
00539 CBB7 8B 0A      ADD A #10        INPUT BUFFER READ POINTER.
00540 CBB9 97 D3      STA A RIN+1
00541 CBBB 7E CD78    JMP FINISH
00542                ***** BEACON MESSAGE *****
00543 CBBE 96 D5      BCN LDA A WOT+1  TEST TO SEE IF A COMPLETE BEACON
00544 CBC0 8B 10      ADD A #16        MESSAGE PLUS AN IDLE CHARACTER CAN
00545 CBC2 81 D0      CMP A #ENDOT     BE STORED IN THE OUTPUT BUFFER WITH-
00546 CBC4 23 08      BLS BCNA1        OUT EXCEEDING THE UPPER BOUNDARY.
00547 CBC6 96 D5      LDA A WOT+1      IF EXCEEDED, UPDATE THE ADJUSTABLE
00548 CBC8 97 DB      STA A DENDOT     UPPER BOUNDARY AND SET THE OUTPUT
00549 CBCA 86 68      LDA A #BEGOT    WRITE POINTER TO BEGINNING OF
00550 CBCC 97 D5      STA A WOT+1     BUFFER.
00551                ***** BEACON MESSAGE REFORMATTING ROUTINE *****
00552 CBCE A6 02      BCNA1 LDA A 2,X
00553 CBD0 48          ASL A            BEACON TEST FLAG SET? IF YES,
00554 CBD1 25 03      BCS BCNA12      DETERMINE WHETHER MESSAGE IS A CPME
00555 CBD3 7E CC5F    JMP BCNA2        MESSAGE OR AN RTQC TRIGGER.
00556 CBD6 E6 0A      BCNA12 LDA B 10,X RTQC TRIGGER MESSAGE? IF YES,
00557 CBD8 C1 FF      CMP B #RTQC0    DISSEMINATE A SIMULATED BEACON RTQC
00558 CBDA 27 03      BEQ BCNA14      MESSAGE, OTHERWISE REFORMAT CPME
00559 CBDC 7E CC5F    JMP BCNA2        MESSAGE TO A REGULAR ATRCBS BEACON
00560 CBDF E6 0B      BCNA14 LDA B 11,X MESSAGE.
00561 CBE1 58          ASL B
00562 CBE2 24 03      BCC BCNA13
00563 CBE4 7E CD17    JMP BCNA3
00564 CBE7 C1 F0      BCNA13 CMP B #RTQC1
00565 CBE9 26 74      BNE BCNA2
00566                *****
00567                *

```

```

00568      * THE FOLLOWING ROUTINE WILL LOAD A SIMULATED BEACON RTQC
00569      * MESSAGE IN THE OUTPUT BUFFER EACH TIME AN RTQC TRIGGER
00570      * MESSAGE IS RECEIVED.
00571      *
00572      *
00573 CBEB DE D4      LDX      WOT
00574 CBED 86 E8      LDA A    #8EB      RTQC HEADER
00575 CBEF C6 30      LDA B    #630
00576 CBF1 A7 00      STA A    0,X
00577 CBF3 E7 01      STA B    1,X      FIRST FRAME LOADED.
00578 CBF5 86 E0      LDA A    #8E0      RANGE = 56 NAUTICAL MILES.
00579 CBF7 5F        CLR B
00580 CBF8 A7 02      STA A    2,X
00581 CBFA E7 03      STA B    3,X      SECOND FRAME LOADED.
00582 CBFC 86 80      LDA A    #880      AZIMUTH =180 DEGREES.
00583 CBFE A7 04      STA A    4,X
00584 CC00 E7 05      STA B    5,X      THIRD FRAME LOADED.
00585 CC02 DE D2      LDX      RIN
00586 CC04 A6 05      LDA A    5,X
00587 CC06 48        ASL A
00588 CC07 24 03      BCC      BCNA5
00589 CC09 7E CD17    JMP      BCNA3
00590 CC0C A6 07      BCNA5   LDA A    7,X
00591 CC0E 48        ASL A
00592 CC0F 24 03      BCC      BCNA6
00593 CC11 7E CD17    JMP      BCNA3
00594 CC14 A6 0B      BCNA6   LDA A    11,X
00595 CC16 48        ASL A
00596 CC17 24 03      BCC      BCNA7
00597 CC19 7E CD17    JMP      BCNA3
00598 CC1C A6 0D      BCNA7   LDA A    13,X
00599 CC1E 48        ASL A
00600 CC1F 24 03      BCC      BCNA8
00601 CC21 7E CD17    JMP      BCNA3
00602 CC24 A6 0F      BCNA8   LDA A    15,X
00603 CC26 48        ASL A
00604 CC27 24 03      BCC      BCNA9
00605 CC29 7E CD17    JMP      BCNA3
00606 CC2C A6 09      BCNA9   LDA A    9,X      CHECK FRAMES 2 THRU 7
00607 CC2E 48        ASL A      FOR CORRECT PARITY.
00608 CC2F 24 03      BCC      BCNA10
00609 CC31 7E CD17    JMP      BCNA3
00610 CC34 16        BCNA10  TAB
00611 CC35 0C        CLC
00612 CC36 49        ROL A
00613 CC37 49        ROL A
00614 CC38 49        ROL A
00615 CC39 84 03      AND A    #803      \0\0\0\0\0\0\0\T\ ACC 'A' HI BYTE
00616 CC3B 58        ASL B
00617 CC3C 58        ASL B
00618 CC3D CA 20      ORA B    #820      \T\T\0\0\0\0\0\0\ ACC 'B'
00619 CC3F DE D4      LDX      WOT      SET RUN LENGTH FLAG TO 1.  LO BYTE

```

```

00620 CC41 A7 06      STA A 6,X
00621 CC43 E7 07      STA B 7,X      FORTH FRAME LOADED.
00622 CC45 B6 FF      LDA A 00FF
00623 CC47 C6 F0      LDA B 00F0
00624 CC49 A7 08      STA A 8,X      MODE 3/A = 7777 (OCT).
00625 CC4B E7 09      STA B 9,X      FIFTH FRAME LOADED.
00626 CC4D 4F         CLR A
00627 CC4E A7 0A      STA A 10,X     MODE 2 = 0000 (OCT).
00628 CC50 A7 0B      STA A 11,X
00629 CC52 A7 0C      STA A 12,X     MODE C = 0000 (OCT).
00630 CC54 A7 0D      STA A 13,X     SIXTH AND SEVENTH FRAMES LOADED.
00631 CC56 D6 E5      LDA B STATUS
00632 CC58 CA 20      ORA B 0X00100000
00633 CC5A D7 E5      STA B STATUS   SET 'RTQC' FLAG.
00634 CC5C 7E CCF9    JMP BCNA4
00635 CC5F 44         BCNA2 LSR A      REFORMAT FIRST FRAME.
00636 CC60 E6 03      LDA B 3,X
00637 CC62 58         ASL B
00638 CC63 DE D4      LDX WOT
00639 CC65 A7 00      STA A 0,X
00640 CC67 CA 10      ORA B 0010     SET AF FLAG TO 1.
00641 CC69 E7 01      STA B 1,X     FIRST FRAME REFORMATTED.
00642 CC6B DE D2      LDX RIN       REFORMAT NEXT FRAME.
00643 CC6D A6 06      LDA A 6,X     \R\R\R\A\A\A\A\A\ ACC 'A'
00644 CC6F 44         LSR A
00645 CC70 44         LSR A
00646 CC71 44         LSR A
00647 CC72 44         LSR A
00648 CC73 E6 05      LDA B 5,X     \0\0\0\0\R\R\R\R\A\ ACC 'A'
00649 CC75 58         ASL B         \P\R'R'R\R\R\R\0\0\0\ ACC 'B'
00650 CC76 24 03      BCC BCNA11    \R'R'R'R\R\R\0\0\0\ ACC 'B' C\P\
00651 CC78 7E CD17    JMP BCNA3     CHECK FOR CORRECT PARITY.
00652 CC7B 1B         BCNA11 ABA     \R'R'R'R\R\R\R\R\R\R\A\ ACC 'A' LO BYTE
00653 CC7C 8B 02      ADD A 02      ADD 1/128 NMI. TO RANGE FIELD.
00654 CC7E E6 04      LDA B 4,X     \R'R'R'R\R\R\R\R\R\R\ ACC 'B' HI BYTE
00655 CC80 C9 00      ADC B 00      ACC B + ZERO + CARRY --> ACC B
00656 CC82 58         ASL B         \R'R'R'R\R\R\R\R\R\0\ ACC 'B'
00657 CC83 48         ASL A         \R'R'R'R\R\R\R\R\A\0\ ACC 'A' C\R'\
00658 CC84 C9 00      ADC B 00      \R'R'R'R\R\R\R\R\R\R\ ACC 'B'
00659 CC86 58         ASL B         \R'R'R'R\R\R\R\R'R\0\ ACC 'B'
00660 CC87 48         ASL A         \R'R'R'R\R\R\A\0\0\ ACC 'A' C\R'\
00661 CC88 C9 00      ADC B 00      \R'R'R'R\R\R\R\R'R\R\ ACC 'B' HI BYTE
00662 CC8A 84 F0      AND A 00F0    \R'R'R'R\R\0\0\0\0\ ACC 'A' LO BYTE
00663 CC8C DE D4      LDX WOT
00664 CC8E E7 02      STA B 2,X
00665 CC90 A7 03      STA A 3,X     SECOND FRAME REFORMATTED.
00666 CC92 DE D2      LDX RIN       REFORMAT NEXT FRAME.
00667 CC94 A6 06      LDA A 6,X     \R\R\R\A\A\A\A\A\ ACC 'A'
00668 CC96 E6 07      LDA B 7,X     \P\A\A\A\A'\0\0\0\0\ ACC 'B'
00669 CC98 58         ASL B         \A\A\A\A'\0\0\0\0\ ACC 'B' C\P\
00670 CC99 25 7C      BCS BCNA3     CHECK FOR CORRECT PARITY.
00671 CC9B 48         ASL A

```

00672	CC9C	48	ASL A			
00673	CC9D	48	ASL A	\A\A\A\A\A\0\0\0\	ACC 'A'	
00674	CC9E	54	LSR B			
00675	CC9F	54	LSR B			
00676	CCA0	54	LSR B			
00677	CCA1	54	LSR B	\0\0\0\0\A\A\A\A\	ACC 'B'	
00678	CCA2	56	ROR B	\0\0\0\0\0\A\A\A\	ACC 'B' C\A\	
00679	CCA3	D7 DD	STA B	SCRATCH		
00680	CCA5	56	ROR B	\A'\0\0\0\0\0\A\A\	ACC 'B'	
00681	CCA6	D7 DE	STA B	SCRATCH+1	FREE UP ACC 'B'	
00682	CCA8	9B DD	ADD A	SCRATCH	\A\A\A\A\A\A\A\A\	ACC 'A'
00683	CCA A	E6 08	LDA B	8,X	\A\A\A\A\X\X\X\X\	ACC 'B'
00684	CCAC	54	LSR B	\0\A\A\A\A\X\X\X\	ACC 'B'	
00685	CCAD	C4 F8	AND B	##FB	\0\A\A\A\A\0\0\0\	ACC 'B'
00686	CCAF	DB DE	ADD B	SCRATCH+1	\A'\A\A\A\A\X\A\A\	ACC 'B'
00687	CCB1	C4 F0	AND B	##F0	\A'\A\A\A\0\0\0\0\	ACC 'B'
00688	CCB3	DE D4	LDX	WOT		
00689	CCB5	A7 04	STA A	4,X		
00690	CCB7	E7 05	STA B	5,X	THIRD FRAME REFORMATTED.	
00691	CCB9	DE D2	LDX	RIN	REFORMAT NEXT FRAME.	
00692	CCBB	E6 09	LDA B	9,X		
00693	CCBD	58	ASL B			
00694	CCBE	25 57	BCS	BCNA3	CHECK FOR CORRECT PARITY.	
00695	CCC0	C4 F0	AND B	##F0	SAVE 'TIS' ONLY.	
00696	CCC2	17	TBA	\T\T\T\T\0\0\0\0\	ACC 'A' AND 'B'	
00697	CCC3	0C	CLC			
00698	CCC4	49	ROL A			
00699	CCC5	49	ROL A			
00700	CCC6	49	ROL A	\T\0\0\0\0\0\T\T\	ACC 'A'	
00701	CCC7	84 03	AND A	##03	\0\0\0\0\0\0\T\T\	ACC 'A' HI BYTE
00702	CCC9	58	ASL B			
00703	CCCA	58	ASL B	\T\T\0\0\0\0\0\0\	ACC 'B' LO BYTE	
00704	CCCB	DE D4	LDX	WOT		
00705	CCCD	A7 06	STA A	6,X		
00706	CCCF	E7 07	STA B	7,X	FORTH FRAME REFORMATTED.	
00707	CCD1	DE D2	LDX	RIN	REFORMAT NEXT FRAME.	
00708	CCD3	A6 0A	LDA A	10,X		
00709	CCD5	E6 0B	LDA B	11,X		
00710	CCD7	58	ASL B			
00711	CCD8	25 3D	BCS	BCNA3	CHECK FOR CORRECT PARITY.	
00712	CCDA	DE D4	LDX	WOT		
00713	CCDC	A7 08	STA A	8,X		
00714	CCDE	E7 09	STA B	9,X	FIFTH FRAME REFORMATTED.	
00715	CCE0	4F	CLR A		SIXTH FRAME ALL ZEROES.	
00716	CCE1	A7 0A	STA A	10,X		
00717	CCE3	A7 0B	STA A	11,X	SIXTH FRAME REFORMATTED.	
00718	CCE5	DE D2	LDX	RIN	REFORMAT LAST FRAME.	
00719	CCE7	A6 0E	LDA A	14,X		
00720	CCE9	E6 0D	LDA B	13,X	CHECK PARITY OF FRAMES 5 AND 6.	
00721	CCEB	58	ASL B			
00722	CCEC	25 29	BCS	BCNA3		
00723	CCEE	E6 0F	LDA B	15,X		

```

00724 CCF0 58          ASL B
00725 CCF1 25 24      BCB BCNA3
00726 CCF3 DE D4      LDX WOT
00727 CCF5 A7 0C      STA A 12,X
00728 CCF7 E7 0D      STA B 13,X      LAST FRAME REFORMATTED.
00729 CCF9 86 1F      BCNA4 LDA A #IDLE0  ATTACH AN IDLE CHARACTER
00730 CCFB C6 F8      LDA B #IDLE1    AT THE END OF THE MESSAGE.
00731 CCFD A7 0E      STA A 14,X
00732 CCFE E7 0F      STA B 15,X
00733 CD01 96 D5      LDA A WOT+1     UPDATE OUTPUT BUFFER
00734 CD03 8B 10      ADD A #16       READ POINTER.
00735 CD05 97 D5      STA A WOT+1
00736 CD07 96 E1      LDA A MESCNT    RESET THE 'PARITY ERROR' FLAG AFTER
00737 CD09 8B 01      ADD A #1        256 CONSECUTIVE PARITY ERROR FREE
00738 CD0B 97 E1      STA A MESCNT    INPUT MESSAGES HAVE BEEN FOUND.
00739 CD0D 24 11      BCC SKIPAB
00740 CD0F 96 E5      LDA A STATUS
00741 CD11 84 F7      AND A #X11110111
00742 CD13 97 E5      STA A STATUS    CLEAR 'PARITY ERROR' FLAG.
00743 CD15 20 09      BRA SKIPAB
00744 CD17 96 E5      BCNA3 LDA A STATUS
00745 CD19 8A 08      ORA A #X00001000
00746 CD1B 97 E5      STA A STATUS    SET 'PARITY ERROR' FLAG.
00747 CD1D 7F 00E1    CLR MESCNT
00748 CD20 96 D3      SKIPAB LDA A RIN+1  UPDATE INPUT BUFFER
00749 CD22 8B 10      ADD A #16       READ POINTER.
00750 CD24 97 D3      STA A RIN+1
00751                ***** RANDOM NUMBER GENERATOR *****
00752 CD26 96 D8      RNGA  LDA A RNG     \0\0\N\N\N\N\N\N\N\ ACC 'A'
00753 CD28 D6 E6      LDA B EXCLOR
00754 CD2A 27 02      BEQ  RNGA1
00755 CD2C 8A 40      ORA A #40       \0\1\N\N\N\N\N\N\N\ ACC 'A'
00756 CD2E D6 D9      RNGA1 LDA B RNG+1   \N\N\N\N\N\N\N\N\N\ ACC 'B'
00757 CD30 44      LSR A           \0\0\X\N\N\N\N\N\N\ ACC 'A' C\N\
00758 CD31 56      ROR B           \N\N\N\N\N\N\N\N\N\ ACC 'B' C\N\
00759 CD32 97 D8      STA A RNG
00760 CD34 D7 D9      STA B RNG+1
00761                *****
00762                *
00763                * THE FOLLOWING ROUTINE SIMULATES THE OUTPUT OF AN
00764                * EXCLUSIVE-OR LOGIC GATE WITH THE FIRST AND LAST BIT OF A
00765                * 15 BIT SHIFT REGISTER USED AS INPUT. THE OUTPUT STATE OF
00766                * THE GATE IS STORED FOR THE NEXT UPDATE OF THE SOFTWARE
00767                * IMPLEMENTED RANDOM NUMBER GENERATOR.
00768                *
00769                *****
00770 CD36 24 03      BCC  RNGA2     LAST 'RNG' BIT SET?
00771 CD38 73 00E6    COM  EXCLOR
00772 CD3B 81 3E      RNGA2 CMP A #THRS1  DISSEMINATE A SIMULATED STATUS
00773 CD3D 26 39      BNE  FINISH    MESSAGE WHEN THE COUNT OF THE
00774 CD3F C1 DF      CMP B #THRS2   'RNG' SATISFIES THE THRESHOLD
00775 CD41 23 35      BLS  FINISH    CONDITIONS.

```

```

00776          ***** STATUS MESSAGE (SIMULATED) *****
00777 CD43 96 D5  RNGA3 LDA A WOT+1  TEST TO SEE IF A COMPLETE STATUS
00778 CD45 88 0A          ADD A #10  MESSAGE PLUS A IDLE CHARACTER CAN BE
00779 CD47 81 D0          CMP A #ENDOT  STORED IN THE OUTPUT BUFFER WITHOUT
00780 CD49 23 08          BLS  RNGA4  EXCEEDING THE UPPER BOUNDARY. IF
00781 CD4B 96 D5          LDA A WOT+1  THE BOUNDARY IS EXCEEDED, UPDATE THE
00782 CD4D 97 D8          STA A DENDOT  ADJUSTABLE UPPER BOUNDARY AND SET
00783 CD4F 86 68          LDA A #BEGOT  THE OUTPUT WRITE POINTER TO
00784 CD51 97 D5          STA A WOT+1  BEGINNING OF BUFFER.
00785          ***** STATUS MESSAGE GENERATION ROUTINE *****
00786 CD53 DE D4  RNGA4 LDX  WOT
00787 CD55 86 0C          LDA A #STATO  STATUS MESSAGE 'ID'.
00788 CD57 C6 30          LDA B #STAT1
00789 CD59 A7 00          STA A 0,X
00790 CD5B E7 01          STA B 1,X
00791 CD5D 4F          CLR A
00792 CD5E A7 02          STA A 2,X  MESSAGE FIELDS SET TO ALL ZEROS.
00793 CD60 A7 03          STA A 3,X
00794 CD62 A7 04          STA A 4,X
00795 CD64 A7 05          STA A 5,X
00796 CD66 A7 06          STA A 6,X
00797 CD68 A7 07          STA A 7,X
00798 CD6A 86 1F          LDA A #IDLE0  ATTACH AN IDLE CHARACTER
00799 CD6C C6 F8          LDA B #IDLE1  AT THE END OF THE MESSAGE.
00800 CD6E A7 08          STA A 8,X
00801 CD70 E7 09          STA B 9,X
00802 CD72 96 D5          LDA A WOT+1  UPDATE OUTPUT BUFFER
00803 CD74 88 0A          ADD A #10  WRITE POINTER.
00804 CD76 97 D5          STA A WOT+1
00805 CD78 7A 00E3 FINISH DEC  SEQCOM
00806 CD7B 7E CA4E          JMP  START
00807          END
    
```

SYMBOL TABLE

INBUF	0000	OUTBUF	0068	WIN	00D0	RIN	00D2	WOT	00D4	ROT	00D6	RNG	00D8	BEGIN	00D0	ENDIN	0068
BEGOT	0068	ENDOT	00D0	DENDIN	00DA	DENDOT	00DB	IDLE0	001F	IDLE1	00FB	RTQC0	00FF	RTQC1	00F0	STATO	000C
STAT1	0030	WTHX0	0001	WTHXL	0030	WTHXH	0050	THRS1	003E	THRS2	00DF	TEMP	00DC	SCRCH	00DD	BITCNT	00DF
WRDCNT	00E0	MESCNT	00E1	SEQFLB	00E2	SEQCOM	00E3	LOCKUP	00E4	STATUS	00E5	EXCLOR	00E6	PIAPA0	5800	PIACA0	5801
PIAPB0	5802	PIACB0	5803	PIAPA1	5804	PIACA1	5805	PIAPB1	5806	PIACB1	5807	SYSMON	5808	NMI	C800	B2	CB11
B1	C833	IRQ	C900	A2	C91E	A1	C91F	A11	C92F	A6	C94B	A3	C954	A5	C978	A4	C997
A12	C9A5	A8	C9BB	A7	C9DB	A9	C9E3	A10	C9EE	SWI	C9EF	INIT	CA00	INITA1	CA19	START	CA4E
STRTA1	CA67	STRTA2	CAB6	SRCH12	CABE	SRCH	CA95	SRCHA1	CAA5	SRCHA7	CABF	SRCHA8	CAE7	SRCHA9	CAEF	SRCH10	CAF7
SRCH11	CAFF	SRCH13	CB07	SRCHA2	CB18	SRCHA6	CB6B	SRCHA5	CB85	SRCHA4	CBA3	SKIPAS	CBAC	WXA1	CBB5	BCN	CBBE
BCNA1	CBCE	BCNA12	CBDE	BCNA14	CBDF	BCNA13	CBE7	BCNA5	CC0C	BCNA6	CC14	BCNA7	CC1C	BCNA8	CC24	BCNA9	CC2C
BCNA10	CC34	BCNA2	CC5F	BCNA11	CC7B	BCNA4	CCF9	BCNA3	CD17	SKIPAB	CD20	RNGA	CD26	RNGA1	CD2E	RNGA2	CD3B
RNGA3	CD43	RNGA4	CD53	FINISH	CD78												

C-18

APPENDIX D

PROGRAM LISTING FOR
SIMULATION AND DIAGNOSTIC MODULE

M68SAM IS THE PROPERTY OF MOTOROLA SPD, INC.
COPYRIGHT 1974 TO 1978 BY MOTOROLA INC

MOTOROLA M6800 CROSS ASSEMBLER, RELEASE 1.2

```

00001          NAM      CODE      STARTS IIIA INTERFACE SIMULATOR
00002          *****
00003          *                                     9-8-87 (11-17-82)
00004          *                                     USER:EFM.SIMU3
00005          *   HARDWARE DEFINITION                                     TAPE: P-71/27610
00006          *
00007          *   RAM      0000 - 03FF
00008          *
00009          *   PIA0     5800 - 5903
00010          *   PIA1     5804 - 5907
00011          *
00012          *   PIA2     5808 - 580B
00013          *
00014          *   DISPLAY      580C
00015          *
00016          *   ROM1     C000 - C3FF
00017          *   ROM2     C400 - C7FF
00018          *   ROM3     C800 - CBFF
00019          *   ROM4     CC00 - CFFF
00020          *
00021          *
00022          *****
00023          ***** RAM DATA BUFFERS *****
00024          *****
00025          0000          ORG          $0000
00026          0000 0020  BUFDA RMB          $20          SIMU. RECV. BUFFER
00027          0020 00B4  BUFSC1 RMB         $B4          SURV. CHANNEL#1 DATA RECV BUFFER.
00028          00D4 00B4  BUFSC2 RMB         $B4          SURV. CHANNEL#2 DATA RECV BUFFER.
00029          0198 0008  STATUS RMB         $08          STATUS FILE.
00030          0190 0003  ERRORS RMB         $03          ERROR FILE.
00031          01F3 0006  TEMP RMB          $06          SCRATCH PAD MEMORY.
00032          0199 0003  SCRTCH RMB         $03          ACCUMULATOR DATA SAVE FILE.
00033          019C 0080  TBLTXR RMB         $80          TRANSHIT FILE.
00034          *****
00035          ***** RAM BUFFER BOUNDARIES *****
00036          *****
00037          0000  BUFDA EQU          BUFDA          BEGINNING OF SIMU RECV BUFFER.
00038          001F  BUFDA EQU          BUFDA+31        END OF SIMU RECV BUFFER.
00039          0020  BUFSC1 EQU          BUFSC1         BEGINNING OF CHANNEL 1 RECV BUFFER.
00040          00D3  BUFSC1 EQU          BUFSC1+179      END OF CHANNEL 1 RECV BUFFER.
00041          00D4  BUFSC2 EQU          BUFSC2         BEGINNING OF CHANNEL 2 RECV BUFFER.
00042          0197  BUFSC2 EQU          BUFSC2+179      END OF CHANNEL 2 RECV BUFFER.
00043          019C  TBLTXR EQU          TBLTXR         BEGINNING OF TRANSHIT FILE.
00044          021B  TBLTXR EQU          TBLTXR+127      END OF TRANSHIT FILE.
00045          *****
00046          ***** FLAGS, COUNTERS AND BOUNDARY POINTERS *****
00047          *****

```

D-2

1

```

00048 021C 00      LOCKUP FCB      0
00049 021D 00      TIMEOUT FCB    0
00050 021E 00      DATFLG FCB    0
00051 021F 00      TIMFLG FCB    0
00052 0220 00      RCVFLG FCB    0
00053 0221 00      TXCOMP FCB    0
00054 0222 00      TXFLAG FCB    0
00055 0223 00      SEQFLG FCB    0
00056 0224 00      EOB   FCB    0
00057 0225 00      OFFSET FCB    0
00058 0226 00      BITCHT FCB    0
00059 0227 00      FRMCNT FCB    0
00060 0228 00      STACNT FCB    0
00061 0229 00      IDLCNT FCB    0
00062 022A 00      DEL1  FCB    0
00063 022B 00      DEL2  FCB    0
00064 022C 00      DEL3  FCB    0
00065 022D 00      DATMSG FCB    $00,$00,$00  DATA MESSAGE COUNTER.
      022E 00
      022F 00
00066 0230 00      STAMSG FCB    $00,$00  STATUS MESSAGE COUNTER.
      0231 00
00067 0232 0000    RNG   FDB    0          RANDOM NO. GEN. SHIFT REGISTER.
00068 0234 00      EXCLDR FCB    0
00069 0235 0000    ENDIN FDB    0
00070 0237 0000    ENDOT FDB    0
00071 0239 0000    ENDUP FDB    0
00072 023B 0000    BTXPTR FDB    0
00073
00074
00075
*****
00076 023D 0000    RIN   FDB    0          INPUT BUFFER READ POINTER.
00077 023F 0000    WIN   FDB    0          INPUT BUFFER WRITE POINTER.
00078 0241 0000    ROT   FDB    0          TRANSMIT TABLE DUMP POINTER.
00079 0243 0000    LKFPTR FDB    0        LOOKUP TABLE READ POINTER.
00080
*****
00081
*****
00082
*****
00083 CFFB          ORG   $CFFB
00084 CFFB CDCE          FDB   IRQ          INPUT INTERRUPT
00085 CFFA CE13          FDB   SWI          SOFTWARE INTERRUPT (NOT USED)
00086 CFFC CDD0          FDB   NMI          OUTPUT INTERRUPT
00087 CFFE C400          FDB   INIT         POWER UP INTERRUPT
00088
*****
00089
*****
00090
*****
00091
*
00092
* THE TRANSMIT TABLE CONTAINS SURVEILLANCE MESSAGES THAT WILL
00093
* EXERCISE THE SURVEILLANCE CHANNEL REFORMATTING SOFTWARE.
00094
*
00095
*****
00096 C000          ORG   $C000

```

```

00097 C000 1F      TBLTXD FCB   $1F,$FB,$1F,$FB,$1F,$FB,$1F,$FB   IDLES
      C001 FB
      C002 1F
      C003 FB
      C004 1F
      C005 FB
      C006 1F
      C007 FB
00098 C008 1F      FCB     $1F,$FB,$1F,$FB,$1F,$FB,$1F,$FB
      C009 FB
      C00A 1F
      C00B FB
      C00C 1F
      C00D FB
      C00E 1F
      C00F FB
00099 C010 EC      FCB     $EC,$28,$01,$50,$7D,$70,$E0,$18   CPME
      C011 28
      C012 01
      C013 50
      C014 7D
      C015 70
      C016 E0
      C017 18
00100 C018 EA      FCB     $EA,$EB,$03,$40,$00,$08,$1F,$FB
      C019 EB
      C01A 03
      C01B 40
      C01C 00
      C01D 08
      C01E 1F
      C01F FB
00101 C020 EB      FCB     $EB,$20,$38,$00,$10,$00,$00,$10   BCN TRIG
      C021 20
      C022 38
      C023 00
      C024 10
      C025 00
      C026 00
      C027 10
00102 C028 FF      FCB     $FF,$FB,$00,$08,$00,$08,$1F,$FB
      C029 FB
      C02A 00
      C02B 08
      C02C 00
      C02D 08
      C02E 1F
      C02F FB
00103 C030 6D      FCB     $6D,$28,$24,$08,$6C,$20,$10,$00   BCN#1
      C031 28
      C032 24
      C033 08

```

C034 6C
 C035 20
 C036 10
 C037 00
 00104 C038 49 FCB \$19,\$28,\$01,\$00,\$06,\$40,\$1F,\$FB
 C039 28
 C03A 01
 C03B 00
 C03C 06
 C03D 40
 C03E 1F
 C03F FB
 00105 C040 60 FCB \$60,\$38,\$10,\$D8,\$D2,\$FB,\$E0,\$28 SRCH#1
 C041 38
 C042 10
 C043 D8
 C044 D2
 C045 FB
 C046 B0
 C047 28
 00106 C048 00 FCB \$00,\$70,\$04,\$30,\$04,\$28,\$1F,\$FB
 C049 70
 C04A 04
 C04B 30
 C04C 04
 C04D 28
 C04E 1F
 C04F FB
 00107 C050 60 FCB \$60,\$38,\$FF,\$FB,\$E0,\$00,\$00,\$10 SYNCH
 C051 38
 C052 FF
 C053 FB
 C054 E0
 C055 00
 C056 00
 C057 10
 00108 C058 00 FCB \$00,\$0E,\$00,\$08,\$00,\$08,\$1F,\$FB
 C059 08
 C05A 00
 C05B 08
 C05C 00
 C05D 08
 C05E 1F
 C05F FB
 00109 C060 60 FCB \$60,\$38,\$05,\$98,\$ED,\$D0,\$10,\$00 SRCH#2
 C061 38
 C062 05
 C063 98
 C064 ED
 C065 D0
 C066 10
 C067 00

```

00110 C068 0C          FCB  $0C,$40,$03,$38,$BC,$28,$1F,$FB
      C069 40
      C06A 03
      C06B 38
      C06C BC
      C06D 28
      C06E 1F
      C06F FB
00111 C070 6C          FCB  $6C,$20,$20,$E8,$4A,$18,$60,$10  BCN#2
      C071 20
      C072 20
      C073 E8
      C074 4A
      C075 18
      C076 60
      C077 10
00112 C078 78          FCB  $78,$98,$02,$28,$07,$30,$1F
      C079 98
      C07A 02
      C07B 28
      C07C 07
      C07D 30
      C07E 1F
00113 C07F FB          TX1END FCB  $FB
00114 C080 1F          FCB  $1F,$FB,$1F,$F8,$1F,$F8,$01,$50  WX
      C081 FB
      C082 1F
      C083 FB
      C084 1F
      C085 FB
      C086 01
      C087 50
00115 C088 10          FCB  $10,$00,$10,$00,$20,$00,$1F,$FB
      C089 00
      C08A 10
      C08B 00
      C08C 20
      C08D 00
      C08E 1F
      C08F FB
00116 C090 EC          FCB  $EC,$28,$01,$50,$7D,$70,$F0,$08  CPME/FRAME 4
      C091 28
      C092 01
      C093 50
      C094 7D
      C095 70
      C096 E0
      C097 08
00117 C098 EA          FCB  $EA,$E8,$03,$40,$00,$08,$1F,$FB  BAD PARITY
      C099 E8
      C09A 03
      C09B 40

```

	C09C	00			
	C09D	09			
	C09E	1F			
	C09F	FB			
00118	COA0	EC	FCB	\$EC,\$2B,\$E0,\$00,\$R0,\$00,\$00,\$20	BCN TRIG/
	COA1	29			
	COA2	E0			
	COA3	00			
	COA4	80			
	COA5	00			
	COA6	00			
	COA7	20			
00119	COA8	FF	FCB	\$FF,\$FB,\$00,\$0B,\$00,\$0B,\$1F,\$FB	TIS = 1/4
	COA9	FB			
	COAA	00			
	COAB	0B			
	COAC	00			
	COAD	0B			
	COAE	1F			
	COAF	FB			
00120	COB0	6D	FCB	\$6D,\$2B,\$24,\$2B,\$6C,\$20,\$10,\$00	BCN#1/FRAME 2
	COB1	2B			
	COB2	24			
	COB3	2B			
	COB4	6C			
	COB5	20			
	COB6	10			
	COB7	00			
00121	COB8	49	FCB	\$49,\$2B,\$01,\$00,\$06,\$40,\$1F,\$FB	BAD PARITY
	COB9	2B			
	COBA	01			
	COBB	00			
	COBC	06			
	COBD	40			
	COBE	1F			
	COBF	FB			
00122	COC0	60	FCB	\$60,\$3B,\$10,\$D8,\$D2,\$CB,\$B0,\$2B	SRCH#1/DIFF.
	COC1	3B			
	COC2	10			
	COC3	D8			
	COC4	D2			
	COC5	CB			
	COC6	B0			
	COC7	2B			
00123	COC8	00	FCB	\$00,\$70,\$04,\$30,\$04,\$2B,\$1F,\$FB	AZIMUTH
	COC9	70			
	COCA	04			
	COCB	30			
	COCC	04			
	COCD	2B			
	COCE	1F			
	COCF	FB			

```

00124 COD0 60          FCB  $60,$38,$FF,$F8,$E0,$00,$00,$20  SYNCH/DIFF.
      COD1 38
      COD2 FF
      COD3 F8
      COD4 E0
      COD5 00
      COD6 00
      COD7 20
00125 COD8 00          FCB  $00,$08,$00,$08,$00,$08,$1F,$F8  TIS = 1/4
      COD9 08
      CODA 00
      CODB 08
      CODC 00
      CODD 08
      CODE 1F
      CODF F8
00126 COE0 48          FCB  $48,$38,$05,$9B,$ED,$D0,$10,$00  SRCH#2/HEADER
      COE1 38
      COE2 05
      COE3 9B
      COE4 ED
      COE5 D0
      COE6 10
      COE7 00
00127 COE8 0C          FCB  $0C,$40,$03,$38,$BC,$2B,$1F,$F8  INCORRECT
      COE9 40
      COEA 03
      COEB 38
      COEC BC
      COED 2B
      COEE 1F
      COEF F8
00128 COF0 6C          FCB  $6C,$20,$10,$EB,$1A,$18,$60,$10  BCN#2/DIFF.
      COF1 20
      COF2 10
      COF3 EB
      COF4 4A
      COF5 1B
      COF6 60
      COF7 10
00129 COF8 74          FCB  $74,$9B,$02,$2B,$07,$30,$1F  RG AND 3/A
      COF9 9B
      COFA 02
      COFB 2B
      COFC 07
      COFD 30
      COFE 1F
00130 COFF FB          FCB  $FB
00131
00132
00133
00134 C100 6C          TBLK FCB  $60,$38,$05,$4B,$EB,$F8,$00,$40  BCN

```

```

*****
***** DATA LOOK-UP TABLE *****
*****
TBLK FCB  $60,$38,$05,$4B,$EB,$F8,$00,$40  BCN

```

D-8

	C101	38			
	C102	05			
	C103	68			
	C104	EB			
	C105	F8			
	C106	00			
	C107	40			
00135	C108	EA	FCB	\$EA,\$E8,\$00,\$08,\$00,\$08,\$1F,\$F8	
	C109	E8			
	C10A	00			
	C10B	08			
	C10C	00			
	C10D	08			
	C10E	1F			
	C10F	F8			
00136	C110	EB	FCB	\$E8,\$38,\$E0,\$00,\$80,\$00,\$00,\$68	BCN RTQC
	C111	38			
	C112	E0			
	C113	00			
	C114	80			
	C115	00			
	C116	00			
	C117	68			
00137	C118	FF	FCB	\$FF,\$F8,\$00,\$08,\$00,\$08,\$1F,\$F8	
	C119	F8			
	C11A	00			
	C11B	08			
	C11C	00			
	C11D	08			
	C11E	1F			
	C11F	F8			
00138	C120	6D	FCB	\$6D,\$30,\$90,\$20,\$61,\$00,\$00,\$08	BCN#1
	C121	30			
	C122	90			
	C123	20			
	C124	61			
	C125	00			
	C126	00			
	C127	08			
00139	C128	49	FCB	\$49,\$28,\$60,\$08,\$06,\$40,\$1F,\$F8	
	C129	28			
	C12A	00			
	C12B	08			
	C12C	06			
	C12D	40			
	C12E	1F			
	C12F	F8			
00140	C130	18	FCB	\$18,\$38,\$43,\$78,\$97,\$D8,\$04,\$88	SRCH#1
	C131	38			
	C132	43			
	C133	78			
	C134	97			

```

C135 D8
C136 04
C137 88
00141 C138 1F          FCB    $1F,$FB,$1F,$FB,$1F,$FB,$1F,$FB
      C139 FB
      C13A 1F
      C13B FB
      C13C 1F
      C13D FB
      C13E 1F
      C13F FB
00142 C140 92          FCB    $92,$30,$E0,$00,$00,$08,$00,$40    SRCH RTDC
      C141 30
      C142 E0
      C143 00
      C144 00
      C145 08
      C146 00
      C147 40
00143 C148 1F          FCB    $1F,$FB,$1F,$FB,$1F,$FB,$1F,$FB
      C149 FB
      C14A 1F
      C14B FB
      C14C 1F
      C14D FB
      C14E 1F
      C14F FB
00144 C150 18          FCB    $18,$38,$16,$88,$6E,$88,$1C,$00    SRCH#2
      C151 38
      C152 16
      C153 88
      C154 6E
      C155 88
      C156 1C
      C157 00
00145 C158 1F          FCB    $1F,$FB,$1E,$FB,$1F,$FB,$1F,$FB
      C159 FB
      C15A 1F
      C15B FB
      C15C 1F
      C15D FB
      C15E 1F
      C15F FB
00146 C160 6C          FCB    $6C,$38,$83,$90,$50,$80,$00,$40    BCN#2
      C161 38
      C162 83
      C163 90
      C164 50
      C165 80
      C166 00
      C167 40
00147 C168 78          FCB    $78,$98,$00,$08,$07,$30,$1F

```

C169 98
 C16A 00
 C16B 08
 C16C 07
 C16D 30
 C16E 1F
 00148 C16F FB
 00149
 00150
 00151
 00152 C170 01
 C171 02
 C172 04
 C173 08
 C174 10
 C175 20
 C176 40
 C177 80

LKPENU FCB \$FB

 ***** MESSAGE TYPE LOOK-UP TABLE *****

 TBLMSG FCB \$01,\$02,\$04,\$08,\$10,\$20,\$40,\$80

00153
 00154
 00155
 00156 000C
 00157 0038
 00158 001F
 00159 00FB
 00160
 00161
 00162
 00163 5800
 00164 5801
 00165 5802
 00166 5803
 00167 5804
 00168 5805
 00169 5806
 00170 5807
 00171 5808
 00172 5809
 00173 580A
 00174 580B
 00175
 00176
 00177
 00178 580C
 00179
 00180
 00181
 00182
 00183
 00184
 00185
 00186

 ***** CONSTANTS *****

 STAT0 EQU \$0C UPPER BYTE OF STATUS HEADER.
 STAT1 EQU \$38 LOWER BYTE OF STATUS HEADER.
 IDLE0 EQU \$1F UPPER BYTE OF IDLE CHARACTER.
 IDLE1 EQU \$FB LOWER BYTE OF IDLE CHARACTER.

 ***** FIA ADDRESSES *****

 PIAPA0 EQU \$5800
 PIACA0 EQU \$5801
 PIAPB0 EQU \$5802
 PIACB0 EQU \$5803
 PIAPA1 EQU \$5804
 PIACA1 EQU \$5805
 PIAPB1 EQU \$5806
 PIACB1 EQU \$5807
 PIAPA2 EQU \$5808
 PIACA2 EQU \$5809
 PIAPB2 EQU \$580A
 PIACB2 EQU \$580B

 ***** SYSTEM DISPLAY MONITOR *****

 SYSMON EQU \$580C

 *
 *
 * CONTROL REGISTER
 *
 * SDH MODULE CONFIGURATION CONTROL FIELD
 * 07 06 \ OPERATING MODE DESCRIPTION
 *

D-11

```

00187 *           0  0  \ LOOP BACK SIMULATED OUTPUT
00188 *           0  1  \ RECV. CHANNEL #1 OUTPUT
00189 *           1  0  \ RECV. CHANNEL #2 OUTPUT
00190 *           1  1  \ SPARE!
00191 *
00192 *
00193 *           CHANNEL #2 CONFIGURATION CONTROL FIELD
00194 *           C5  C4  C3  \ OPERATING MODE  \ DESCRIPTION
00195 *           -----
00196 *           0  0  0  \ SIMULATION      \ RECV. SC & SD / TX. SC & RD
00197 *           0  0  1  \ BY-PASS        \ RECV. - - / TX. MC & MD
00198 *           0  1  0  \ SCENARIO/ON LINE \ RECV. SC & SD / TX. MC & RD
00199 *           0  1  1  \ SCENARIO/IDLES  \ RECV. SC - / TX. MC & RD
00200 *           1  0  0  \ SPARE!         \
00201 *           1  0  1  \ SPARE!         \
00202 *           1  1  0  \ SPARE!         \
00203 *           1  1  1  \ OPERATIONAL    \ RECV. MC & MD / TX. MC & RD
00204 *
00205 *

```

```

00206 *           CHANNEL #1 CONFIGURATION CONTROL FIELD
00207 *           C2  C1  C0  \ OPERATING MODE  \ DESCRIPTION
00208 *           -----
00209 *           0  0  0  \ SIMULATION      \ RECV. SC & SD / TX. SC & RD
00210 *           0  0  1  \ BY-PASS        \ RECV. - - / TX. MC & MD
00211 *           0  1  0  \ SCENARIO/ON LINE \ RECV. SC & SD / TX. MC & RD
00212 *           0  1  1  \ SCENARIO/IDLES  \ RECV. SC - / TX. MC & RD
00213 *           1  0  0  \ SPARE!         \
00214 *           1  0  1  \ SPARE!         \
00215 *           1  1  0  \ SPARE!         \
00216 *           1  1  1  \ OPERATIONAL    \ RECV. MC & MD / TX. MC & RD
00217 *

```

```

NOTES:
* SC = SIMU. CLOCK   MC = MODEM CLOCK   RD = REFORMATTED DATA
* SD = SIMU. DATA  ND = MODE S DATA   - = OFF

```

```

*****
***** INITIALIZATION (START UP ONLY) *****
*****

```

```

00225 C400      ORG      #C400
00226 C400 0F      INIT   SEI          DISABLE INPUT INTERRUPTS.
00227 C401 8E 03FF  LDS      #3FF      INITIALIZE STACK POINTER.
00228 C404 86 2F   LDA  A   #2F      SET UP THE A-SIDE OF FIA'S
00229 C406 B7 5801 STA  A   PIACA0   AS INPUT.
00230 C409 B7 5805 STA  A   PIACA1
00231 C40C B7 5809 STA  A   PIACA2
00232 C40F 73 5802 COM   FIAFB0     SET UP THE B-SIDE OF FIA'S
00233 C412 73 5806 COM   FIAFB1     AS OUTPUT.
00234 C415 73 580A COM   FIAFB2
00235 C418 86 27   LDA  A   #27
00236 C41A B7 5803 STA  A   FIACB0
00237 C41D B7 5807 STA  A   FIACB1
00238 C420 B7 580B STA  A   FIACB2

```

D-12

```

00239 C423 B6 FF      LDA A  #FF      INITIALIZE CONTROL REGISTER
00240 C425 B7 580A    STA A  FIAPB2   FOR OPERATIONAL MODE.
00241 C428 4F        CLR A
00242 C429 B7 0220    STA A  RCVFLG   DISABLE DATA RECORDING.
00243 C42C B7 0222    STA A  TXFLAG   DISABLE DATA TRANSMISSION.
00244 C42F B7 0188    STA A  STATUS   INITIALIZE STATUS FILE.
00245 C432 B7 0189    STA A  STATUS+1
00246 C435 B7 018A    STA A  STATUS+2
00247 C438 B7 018B    STA A  STATUS+3
00248 C43B B7 018C    STA A  STATUS+4
00249 C43E B7 018D    STA A  STATUS+5
00250 C441 B7 018E    STA A  STATUS+6
00251 C444 B7 018F    STA A  STATUS+7
00252 C447 B7 580C    STA A  SYSDM    CLEAR DISPLAY.
00253 C44A CE 0000    LDX  #0000     ***** MEMORY TEST *****
00254 C44D B6 55      LDA A  #55      LOAD RAM INPUT BUFFERS WITH
00255 C44F B7 019B    STA A  SCRTCH+2 DATA CHECKER BOARD PATTERN.
00256 C452 C6 AA      LDA B  #AA
00257 C454 B6 019B    LDA A  SCRTCH+2 INIT1
00258 C457 A7 00      STA A  0,X
00259 C459 E7 01      STA B  1,X
00260 C45B 08        INX
00261 C45C 08        INX
00262 C45D FF 0199    STX  SCRTCH
00263 C460 B6 0199    LDA A  SCRTCH
00264 C463 27 EF      BEQ  INIT1
00265 C465 B6 019A    LDA A  SCRTCH+1
00266 C468 91 B6     CMP A  #B6
00267 C46A 23 EB     BLS  INIT1
00268 *****
00269 ***** MAIN PROGRAM *****
00270 *****
00271 *
00272 * THE MAIN PROGRAM SAMPLES THE LOWER EIGHT
00273 * ADDRESS SWITCHES FOR INSTRUCTIONS.
00274 *
00275 *
00276 * ***** MENU *****
00277 *
00278 * S7 EXECUTE CHANNEL 2 SURVEILLANCE TEST ROUTINE
00279 * WHEN SWITCH "S7" IS SET TO 1.
00280 * S6 EXECUTE CHANNEL 1 SURVEILLANCE TEST ROUTINE
00281 * WHEN SWITCH "S6" IS SET TO 1.
00282 * S5 EXECUTE SELF TEST ROUTINE WHEN SWITCH "S5" IS SET TO 1.
00283 * S4 EXECUTE STATUS RANDOM NUMBER GENERATOR VERIFICATION
00284 * ROUTINE WHEN SWITCH "S4" IS SET TO 1.
00285 * S3 DISSEMINATE DATA AS LONG AS SWITCH "S3" IS SET TO 1.
00286 * S2 EXECUTE CHANNEL 1 SURVEILLANCE TEST ROUTINE USING
00287 * THE TRANSMIT FILE WHEN SWITCH "S2" IS SET TO 1.
00288 * S1 EXECUTE DIAGNOSTICS WHEN SWITCH "S1" IS SET TO 1.
00289 * SET UP BOTH SURV. CHANNELS FOR NORMAL OPERATION WHEN
00290 * SWITCH "S1" IS SET TO 0.

```

```

00291      * S0   EXECUTE MAIN PROGRAM WHEN SWITCH 'S0' IS SET TO 1.
00292      *
00293      *
00294      *****
00295 C46C BD CCE0 LOOP1 JSR   DELAY   WAIT 2 SECONDS.
00296 C46F B6 0188 LOOP2 LDA  A   STATUS
00297 C472 B7 580C      STA  A   SYSMON  DISPLAY UNIT STATUS FOR
00298 C475 27 03      BEQ   CONT  2 SECONDS IF UNIT FAILS IN
00299 C477 BD CCE0      JSR   DELAY   ANY SELECTED TEST.
00300 C47A B6 5808 CONT  LDA  A   PIAPA2  GET MENU!
00301 C47D 44          LSR  A   EXECUTE MAIN ROUTINE IF
00302 C47E 24 EF      BCC   LOOP2  SWITCH 'S0' IS SET TO 1.
00303 C480 C6 FF      LDA  M  #21111111  INDICATE PAUSE BEFORE CYCLING
00304 C482 F7 580C      STA  B   SYSMON  THUR MAIN ROUTINE. (LED TEST)
00305 C485 BD CCE0      JSR   DELAY   WAIT 2 SECONDS.
00306 C488 C6 00      LDA  B  #20000000  INDICATE PAUSE COMPLETE.
00307 C48A F7 580C      STA  B   SYSMON
00308 C48D 44          LSR  A   TEST STATE OF SWITCH 'S1'.
00309 C48E 24 2D      BCC   OPR1   IF SET TO 0, NORMAL OPERATION.
00310 C490 C6 02      LDA  B  #200000010  IF SET TO 1, EXECUTE DIAGNOSTICS.
00311 C492 F7 580C      STA  B   SYSMON  INDICATE DIAGNOSTICS SELECTED.
00312 C495 44          LSR  A   TEST STATE OF SWITCH 'S2'.
00313 C496 24 03      BCC   TST2   IF SET TO 1 EXECUTE
00314 C498 BD C4C6      JSR   TSTLP1  CHANNEL 1 DIAG. TEST LOOP.
00315 C49B 44          LSR  A   TEST STATE OF SWITCH 'S3'.
00316 C49C 24 05      BCC   TST3   IF SET TO 1 EXECUTE
00317 C49E BD C5C9      JSR   TSTLP2  TEST LOOP 2.
00318 C4A1 20 C9      BRA   LOOP1  SAMPLE MENU AFTER TERMINATION OF TSTLP 2.
00319 C4A3 44          LSR  A   TEST STATE OF SWITCH 'S4'.
00320 C4A4 24 03      BCC   TST4   IF SET TO 1 EXECUTE
00321 C4A6 BD C678      JSR   TSTLP3  STATUS RRG DIAGNOSTIC ROUTINE.
00322 C4A9 44          LSR  A   TEST STATE OF SWITCH 'S5'.
00323 C4AA 24 03      BCC   TST5   IF SET TO 1 EXECUTE
00324 C4AC BD C838      JSR   TSTLP4  SELF TEST LOOP.
00325 C4AF 44          LSR  A   TEST STATE OF SWITCH 'S6'.
00326 C4B0 24 03      BCC   TST6   IF SET TO 1 EXECUTE
00327 C4B2 BD C8F9      JSR   TSTLP5  CHANNEL 1 SURV. TEST LOOP.
00328 C4B5 44          LSR  A   TEST STATE OF SWITCH 'S7'.
00329 C4B6 24 B4      BCC   LOOP1  IF SET TO 1 EXECUTE
00330 C4B8 BD C968      JSR   TSTLP6  CHANNEL 2 SURV. TEST LOOP.
00331 C4BB 20 AF      BRA   LOOP1
00332 C4BD 44          LSR  A   TEST STATE OF SWITCH 'S2'.
00333 C4BE 24 03      BCC   OPR2   IF SET TO 1 OPERATE IN THE
00334 C4C0 BD C0DA      JSR   OPR1   BY-PASS MODE.
00335 C4C3 7E C46C OPR2 JMP   LOOP1
00336      *****
00337      ***** SUBROUTINE (TEST LOOP #1) *****
00338      *****
00339      *
00340      * THIS ROUTINE LOADS A TRANSMIT DATA FILE FROM THE TRANSMIT
00341      * DATA TABLE AND STORES THE FILE IN PAR. THE TRANSMIT FILE
00342      * IS IDENTICAL TO TRANSMIT TABLE #1 WITH THE EXCEPTION OF ONE

```

```

00343 * INCORRECT MESSAGE FROM TRANSMIT TABLE #2 REPLACING A
00344 * MESSAGE FROM TABLE #1. THE MESSAGE REPLACEMENT IS SELECTED
00345 * BY SWITCHES S5, S6, AND S7.
00346 *
00347 * SWITCHES \ EXPECTED RESULTS
00348 * S7 S6 S5 \ MESSAGE SELECT \ REFORMATTER \ DIAGNOSTIC
00349 * -----
00350 * 0 0 0 \ WEATHER \ PURGED \ NO ERRORS
00351 * 0 0 1 \ CPME/BAD PARITY \BAD PRY/PURGED\ MESS 1 MISSING
00352 * 0 1 0 \ BCRN TRIG/DIFF TIS\ REFORMATTED \ MESS 2 INCORRECT
00353 * 0 1 1 \ BCRN#1/BAD PARITY \BAD PRY/PURGED\ MESS 3 MISSING
00354 * 1 0 0 \ SCR#1/DIFF. AZ \ REFORMATTED \ MESS 4 INCORRECT
00355 * 1 0 1 \ SYNCH/DIFF TIS \ REFORMATTED \ MESS 5 INCORRECT
00356 * 1 1 0 \ SCR#2/BAD PRY \BAD PRY/PURGED\ MESS 6 MISSING
00357 * 1 1 1 \ BCRN #2/DIF-RG-3/A\ REFORMATTED \ MESS 7 INCORRECT
00358 * \ \
00359 *
00360 ***** INITIALIZATION *****
00361 C4C6 0E TSTLP1 CLI
00362 C4C7 86 00 LDA A #0
00363 C4C9 B7 0199 STA A SCRCH CLEAR MENU.
00364 C4CC B7 021C STA A LOCKUP CLEAR INPUT SYNC FLAG.
00365 C4CF B7 021F STA A TIMFLG CLEAR TIMEOUT FLAG.
00366 C4D2 B7 021E STA A DATFLG CLEAR DATA RECEIVED FLAG.
00367 C4D5 B7 0190 STA A ERRORS CLEAR ALL ERROR FLAGS.
00368 C4D8 B7 0191 STA A ERRORS+1
00369 C4DB B7 0192 STA A ERRORS+2
00370 C4DE B7 021D STA A TIMOUT CLEAR TIMEOUT COUNTER.
00371 C4E1 B7 0221 STA A TXCOMP CLEAR TRANSMISSION COMPLETE FLAG.
00372 C4E4 B7 0224 STA A EOB CLEAR END OF RECV. BUFFER DETECTED FLAG.
00373 C4E7 B7 0229 STA A IDLCNT CLEAR IDLE COUNTER.
00374 C4EA B7 023D STA A RIN
00375 C4ED B7 023F STA A WIN
00376 C4F0 B7 0235 STA A ENDIR
00377 C4F3 86 20 LDA A #BUFC1B SET RECEIVE DATA READ AND WRITE
00378 C4F5 B7 023E STA A RIN+1 POINTERS TO BEGINNING OF CHANNEL #1
00379 C4F8 B7 0240 STA A WIN+1 RECEIVE BUFFER.
00380 C4FB 86 D3 LDA A #BUFC1E SET UP CHANNEL #1 RECEIVE
00381 C4FD B7 0236 STA A ENDIR+1 BUFFER UPPER BOUNDARY.
00382 C500 CE 019C LDX #ITBLB ***** BUILD TRANSMIT FILE *****
00383 C503 FF 0193 STX TEMP MOVE START ADDRESS OF TRANSMIT FILE TO 'TEMP'
00384 C506 CE C000 LDX #ITBLXD MOVE START ADDRESS OF TRANSMIT DATA
00385 C509 FF 0195 STX TEMP+2 TABLE TO 'TEMP+2'
00386 C50C FF 0197 STX TEMP+4 AND TO 'TEMP+4'.
00387 C50F B6 5808 LDA A FIAPA2 GET 'INCORRECT MESSAGE' CODE FROM
00388 C512 44 LSR A SWITCHES S5, S6, AND S7.
00389 C513 44 LSR A
00390 C514 44 LSR A
00391 C515 44 LSR A
00392 C516 44 LSR A
00393 C517 B7 019B STA A SCRCH+2 SAVE 'INCORRECT MESSAGE' CODE.
00394 C51A B6 13 TLP11 PRE TLP11 'INCORRECT MESSAGE' SELECTED?

```

```

00395 C51C B6 0195      LDA A TEMP+2  OFFSET POINTER TO ACCESS SELECTED
00396 C51F F6 0196      LDA B TEMP+3  INCORRECT MESSAGE.
00397 C522 CB 80        ADC B #80
00398 C524 B9 00        ADC A #0
00399 C526 B7 0197      STA A TEMP+4
00400 C529 F7 0198      STA B TEMP+5
00401 C52C FE 0197      LDX TEMP+2
00402 C52F B6 08      TLP12 LDA A #8      SET UP FOR 8 FRAME TRANSFER SEQUENCE.
00403 C531 B7 019A      STA A SCRTOCH+1
00404 C534 A6 00      TLP14 LDA A 0,X    GET DATA FRAME.
00405 C536 E6 01      LDA B 1,X
00406 C538 FE 0193      LDX TEMP      TRANSFER FRAME TO TRANSMIT FILE.
00407 C53B A7 00      STA A 0,X
00408 C53D E7 01      STA B 1,X
00409 C53F B6 0196      LDA A TEMP+3  UPDATE TRANSMIT DATA POINTER.
00410 C542 F6 0195      LDA B TEMP+2
00411 C545 B8 02      ADD A #2
00412 C547 C9 00      ADC B #0
00413 C549 B7 0196      STA A TEMP+3
00414 C54C F7 0195      STA B TEMP+2
00415 C54F B6 0198      LDA A TEMP+5  UPDATE TRANSFER POINTER.
00416 C552 F6 0197      LDA B TEMP+4
00417 C555 B8 02      ADD A #2
00418 C557 C9 00      ADC B #0
00419 C559 B7 0198      STA A TEMP+5
00420 C55C F7 0197      STA B TEMP+4
00421 C55F B6 0194      LDA A TEMP+1  UPDATE TRANSMIT FILE POINTER.
00422 C562 F6 0193      LDA B TEMP
00423 C565 B8 02      ADD A #2
00424 C567 C9 00      ADC B #0
00425 C569 B7 0194      STA A TEMP+1
00426 C56C F7 0193      STA B TEMP
00427 C56F FE 0197      LDX TEMP+4  GET TRANSMIT DATA POINTER.
00428 C572 7A 019A      DEC SCRTOCH+1 DECREMENT FRAME TRANSFER COUNT.
00429 C575 B6 019A      LDA A SCRTOCH+1 WHEN 8 FRAMES ARE TRANSFERED UPDATE
00430 C578 26 BA      BNE TLP14    TO NEXT MESSAGE.
00431 C57A FE 0195      LDX TEMP+2  RESET TRANSFER POINTER.
00432 C57D FF 0197      STX TEMP+2
00433 C580 B6 0196      LDA A TEMP+3  TRANSMIT FILE COMPLETED?
00434 C583 B1 7F      CMP A #17F
00435 C585 22 08      BHI TLP13
00436 C587 7A 019B      DEC SCRTOCH+2 RECALL SAVED "INCORRECT MESSAGE" CODE.
00437 C58A B6 019B      LDA A SCRTOCH+2
00438 C58D 20 8B      BRA TLP11   **** TRANSMIT FILE COMPLETE ****
00439 C58F B6 0188      TLP13 LDA A STATUS CLEAR "CHANNEL #1 FAILURE" FLAG.
00440 C592 94 BF      AND A #10111111
00441 C594 B7 0188      STA A STATUS
00442 C597 B6 09      LDA A #9     SET FRAME COUNT TO ACCEPT 8 FRAMES
00443 C599 B7 0227      STA A FROMI  AFTER TRANSMISSION HAS COMPLETED.
00444 C59C CE 019C      LDX #TXBLR  SET TRANSMIT POINTER TO
00445 C59F FF 0241      STX #0      BEGINNING OF TRANSMIT TABLE.
00446 C5A2 CE 021B      LDX #TXBLR  SET UP TRANSMIT TABLE

```

```

00447 C5A5 FF 0237      STX   ENDDT   UPPER BOUNDARY.
00448 C5A8 CE C100      LDX   #IBLLKP SET LOOKUP POINTER TO
00449 C5AB FF 0243      STX   LKFPTR  BEGINNING OF LOOKUP TABLE.
00450 C5AE CE C16F      LDX   #LKFPND SET UP LOOKUP TABLE
00451 C5B1 FF 0239      STX   ENDDUP  UPPER BOUNDARY.
00452 C5B4 86 78        LDA   A #178  SET UP CONFIGURATION CONTROL
00453 C5B6 87 580A      STA   A #IAFB2 FOR CHANNEL 1 TESTING.
00454 C5B9 86 06        LDA   A #Z00000110 INDICATE THAT TEST
00455 C5BB 87 580C      STA   A SYSMON LOOP 1 IS EXECUTING.
00456 C5BE 86 01        LDA   A #1
00457 C5C0 87 0222      STA   A TXFLAG ENABLE DATA TRANSMISSION.
00458 C5C3 87 0220      STA   A RCVFLB ENABLE DATA RECORDING.
00459                      ***** INITIALIZATION COMPLETED *****
00460 C5C6 7E C9DB      JMP   TLP561
00461                      *****
00462                      ***** SUBROUTINE (TEST LOOP #2) *****
00463                      *****
00464                      *
00465                      * THIS ROUTINE SETS UP THE MODE S SURVEILLANCE LINE
00466                      * SIMULATOR TO CONTINUALLY OUTPUT A MESSAGE TO BOTH
00467                      * SURVEILLANCE CHANNELS, SIMULTANEOUSLY. ADDRESS SWITCHES
00468                      * S5, S6, AND S7 DESIGNATE THE TYPE MESSAGE DISSEMINATED.
00469                      *
00470                      *
00471                      *
00472                      *
00473                      *
00474                      *
00475                      *
00476                      *
00477                      *
00478                      *
00479                      *
00480                      *
00481                      *
00482                      ***** INITIALIZATION *****
00483 C5C7 CE C000      TSTLP2 LDX   #IBLTXD GET START ADDRESS OF TRANSMIT TABLE.
00484 C5CC FF 0238      STX   BTXPTR
00485 C5CF 86 5808      LDA   A #IAFA2 LOOK AT SWITCHES S5, S6, AND S7.
00486 C5D2 44          LSR   A DETERMINE MESSAGE
00487 C5D3 44          LSR   A TO BE DISSEMINATED.
00488 C5D4 44          LSR   A
00489 C5D5 44          LSR   A
00490 C5D6 44          LSR   A
00491 C5D7 27 0B      TLP22 BEQ   TLP21 THIS MESSAGE SELECTED? IF NOT,
00492 C5D9 F4 023C      LDA   B #TXFIR#1 POINT TO ADDRESS OF NEXT MESSAGE.
00493 C5DC CB 10        ADD   B #16
00494 C5DE F7 023C      STA   B #TXFIR#1
00495 C5E1 4A          ORC   B BECKENFIR SELECT MESSAGE CODE.
00496 C5E2 20 F3      BEA   TLP23
00497 C5E4 FE 023B      TLP21 LDA   #TXFTR  LOAD START ADDRESS OF MESSAGE
00498 C5E7 FF 0241      STX   PTR    INTO TRANSMIT TABLE READ POINTER.

```

D-17

```

00499 C5EA F6 023C LDA B BIXPTR+1 DEFINE THE TRANSMIT TABLE
00500 C5EB CB 0D ADD B #13 UPPER BOUNDARY.
00501 C5EF F7 0238 STA B ENBOT+1
00502 C5F2 F6 023B LDA B BIXPTR
00503 C5F5 F7 0237 STA B ENDD1
00504 C5F8 86 00 LDA A #0
00505 C5FA B7 021C STA A LOCKUP CLEAR LOCKUP FLAG.
00506 C5FD B7 021E STA A DATFLG CLEAR DATA FLAG.
00507 C600 B7 021F STA A TIMFLG CLEAR TIMEOUT FLAG.
00508 C603 B7 021D STA A TIMOUT CLEAR TIMEOUT COUNTER.
00509 C606 B7 023F STA A WIR
00510 C609 E7 0235 STA A ENDIN SET RECEIVE DATA WRITE
00511 C60C 86 00 LDA A #BUFSIB POINTER TO BEGINNING OF
00512 C60E B7 0240 STA A WIN+1 SIMU. RECEIVE BUFFER.
00513 C611 86 1F LDA A #BUFSIE SET UP SIMU. RECEIVE
00514 C613 B7 0236 STA A ENDIN+1 BUFFER UPPER BOUNDARY.
00515 C616 86 FF LDA A #FFF SET FRAME COUNT TO MAXIMUM.
00516 C618 B7 0227 STA A FRMCNT
00517 C61B 86 00 LDA A #00 SET CONFIGURATION CONTROL TO OUTPUT
00518 C61D B7 580A STA A PIAPB2 SIMULATED DATA TO BOTH SURV. CHANNELS.
00519 C620 86 0A LDA A #200001010 INDICATE TEST
00520 C622 B7 580C STA A SYSDON LOOP 2 IS RUNNING.
00521 C625 4F CLR A
00522 C626 B7 0221 STA A TXCOMP CLEAR TRANSMISSION COMPLETE FLAG.
00523 C629 86 01 LDA A #1
00524 C62B B7 0222 STA A TXFLAG ENABLE DATA TRANSMISSION.
00525 C62E B7 0220 STA A RCVFLG ENABLE DATA DATA RECORDING.
00526 C631 0E CLI ENABLE INPUT INTERRUPTS.
00527 ***** INITIALIZATION COMPLETED *****
00528 C632 B6 5808 TLP23 LDA A PIAPA2 TEST LOOP 2 WILL LOOP UNTIL SWITCH 'S3'
00529 C635 84 08 AND A #200001000 IS SET TO ITS 0 POSITION.
00530 C637 27 24 BEQ TLP24
00531 C639 B6 0221 LDA A TXCOMP MESSAGE TRANSMISSION COMPLETE?
00532 C63C 27 09 BEQ TLP25
00533 C63E FE 0238 LDX BIXPTR RESET TRANSMISSION READ POINTER.
00534 C641 FF 0241 STX RPT
00535 C644 7F 0221 CLR TXCOMP RESET TRANSMISSION COMPLETE FLAG.
00536 C647 F6 0240 TLP25 LDA A WIN+1
00537 C64A 81 1F CMP A #BUFSIE RESET THE SIMU. RECEIVE DATA WRITE
00538 C64C 23 E4 BLS TLP23 POINTER IF AT THE END OF INPUT
00539 C64E 86 00 LDA A #BUFSIB BUFFER.
00540 C650 B7 023F STA A WIR
00541 C653 7F 021D CLR TIMOUT CLEAR TIMEOUT COUNTER.
00542 C656 86 FF LDA A #FFF
00543 C658 B7 0227 STA A FRMCNT PREVENT SEQUENCE FROM COMPLETING.
00544 C65B 20 D5 BRA TLP23
00545 ***** EXIT ROUTINE *****
00546 C65D B6 5808 TLP24 LDA A PIAPA2 CONTINUE TO DISSEMINATE INLE CHARACTERS
00547 C660 84 03 AND A #03 IF SWITCH 'S2' AND 'S1' REMAIN SET TO 1.
00548 C662 81 07 CMP A #07
00549 C664 27 09 BEQ TLP24
00550 C666 0F SET MISCABLE INPUT INTERRUPTS.

```

```

00551 C667 7F 0222      CLR   TXFLAG   DISABLE DATA TRANSMISSION.
00552 C66A 86 FF        LDA A  #FF     SET CONFIGURATION CONTROL
00553 C66C B7 580A      STA A  PIAPB2  FOR NORMAL OPERATION.
00554 C66F 7F 0220 TLP26 CLR   RCVFLG   DISABLE DATA RECORDING.
00555 C672 86 02        LDA A  #Z00000010  INDICATE TEST LOOP 2
00556 C674 B7 580C      STA A  SYSDON  IS COMPLETE.
00557 C677 39           RTS
00558
00559 *****
00560 ***** SUBROUTINE (TEST LOOP #3) *****
00561 *****
00562 *
00563 * THIS ROUTINE PROVIDES THE RATIO BETWEEN STATUS
00564 * MESSAGES AND REFORMATTED SURVEILLANCE MESSAGES.
00565 * (VERIFIES THE OPERATION OF THE RANDOM NUMBER GENERATOR)
00566 *
00567 *
00568 *
00569 *
00570 *
00571 *
00572 *
00573 *
00574 *
00575 *
00576 *
00577 *
00578 *
00579 *****
00580 C678 86 00 TSTLTP3 LDA A  #0
00581 C67A B7 021C      STA A  LOCKUP  CLEAR LOCKUP FLAG.
00582 C67D B7 021F      STA A  TINFLG  CLEAR TIMEOUT FLAG.
00583 C680 B7 021E      STA A  DATFLG  CLEAR DATA RECV. FLAG.
00584 C683 B7 021D      STA A  TIMOUT  CLEAR TIMEOUT COUNTER.
00585 C686 B7 0221      STA A  TXCOMP  CLEAR TRANSMISSION COMPLETE FLAG.
00586 C689 B7 0223      STA A  SEQFLG  CLEAR SEQUENCE FLAG.
00587 C68C B7 0230      STA A  RIN
00588 C68F B7 023F      STA A  WIH
00589 C692 B7 0235      STA A  ERDIN
00590 C695 B7 0230      STA A  STMSGC  CLEAR STATUS MESSAGE COUNTER.
00591 C698 B7 0231      STA A  STMSGH1
00592 C69B B7 0220      STA A  DATMSG  CLEAR DATA MESSAGE COUNTER.
00593 C69E B7 022E      STA A  DATMSGH1
00594 C6A1 B7 022F      STA A  DATMSGH2
00595 C6A4 B7 0233      STA A  RNGH1  INIT RANDOM NO. GEN.
00596 C6A7 43          COM A
00597 C6AB B7 0230      STA A  EXCLDP
00598 C6AE 94 3F        LDA A  #3F
00599 C6AD B7 0232      STA A  RNR
00600 C6B0 94 00        LDA A  #000000  SET RECEIVE DATA FLAG AND WRITE
00601 C6B2 B7 023E      STA A  RINH1  POINTERS TO BEGINNING OF SINK.
00602 C6B5 B7 0240      STA A  RINH2  RECEIVE BUFFER.

```

D-19

```

00603 C6B8 86 1F          LDA A #RUE31E   SET UP SIMU. RECEIV
00604 C6BA B7 0236       STA A ENDM+1   BUFFER UPPER BOUNDARY.
00605 C6BD CE 019C       LDX #TXPLR    ***** BUILD TRANSMIT FILE *****
00606 C6C0 FF 0193       STX TEMP      STORE START ADDRESS OF TRANSMIT FILE IN 'TEMP'
00607 C6C3 CE C060       LDX #TELTXD+96 STORE START ADDRESS OF
00608 C6C6 FF 0195       STX TEMP+2    TRANSMIT TABLE IN 'TLHP+2'.
00609 C6C9 A6 00         TLP35 LDA A 0+X     MOVE FRAME FROM TRANSMI
00610 C6CB E6 01         LDA B 1+X     TABLE TO TRANSMIT FILE.
00611 C6CD FE 0193       LDX TEMP
00612 C6D0 A7 00         STA A 0+X
00613 C6D2 E7 01         STA B 1+X
00614 C6D4 08           INX           UPDATE TRANSMIT
00615 C6D5 08           INX           FILE POINTER.
00616 C6D6 FF 0193       STX TEMP
00617 C6D9 FE 0195       LDX TEMP+2   UPDATE TRANSMIT
00618 C6DC 08           INX           TABLE POINTER.
00619 C6DD 08           INX
00620 C6DE FF 0195       STX TEMP+2   IDLE CHARACTER TRAIN
00621 C6E1 8C C070       CPX #IBLTXD+112 .TRANSFER COMPLETE?
00622 C6E4 26 E3         BNE TLP36    ***** TRANSMIT FILE COMPLETED *****
00623 C6E6 CE 019C       LDX #TXPLR   SET TRANSMIT POINTER TO
00624 C6E9 FF 0241       STX ROT      BEGINNING OF TRANSMIT FILE.
00625 C6EC FF 0193       STX TEMP     TRANSMIT UPPER BOUNDARY.
00626 C6EF F6 0193       LDA B TEMP
00627 C6F2 B6 0194       LDA A TEMP+1
00628 C6F5 8B 0F         ADD A #0F
00629 C6F7 B7 0194       STA A TEMP+1
00630 C6FA C9 00         ADC B #0
00631 C6FC F7 0193       STA B TEMP
00632 C6FF FE 0193       LDX TEMP
00633 C702 FF 0237       STX ENDM    SET UP UPPER BOUNDARY
00634 C705 B6 0236       LQA A ENDM+1 OF TRANSMIT FILE.
00635 C708 4A           DEC A
00636 C709 4A           DEC A
00637 C70A B7 0198       STA A TEMP+5 SET UP SIMU. RECV. UPPER BOUNDARY FOR THIS
00638 C70B 86 00         LDA A #0      ROUTINE TWO ADDRESSES LESS THAN ENDM.
00639 C70E B7 0193       STA A TEMP
00640 C712 B7 0194       STA A TEMP+1
00641 C715 B7 0195       STA A TEMP+2
00642 C718 43           CO# A        SET FRAME COUNT TO MAXIMUM.
00643 C719 B7 0227       STA A FFRNT
00644 C71C B6 78         LDA A #78
00645 C71E B7 5806       STA A #AFF2  SET UP CONFIGURATION CONTROL
00646 C721 B6 12         LDA A #Y0 010010 FOR CHANNEL 1 MONITORING.
00647 C723 B7 580C       STA A #Y0 010010 INDICATE THAT TEST LOOP 3
00648 C726 B6 01         LDA A #1
00649 C729 B7 0222       STA A #YFLAG ENABLE DATA TRANSMISSION.
00650 C72B B7 0220       STA A #YRFLG ENABLE DATA RECORDING.
00651 C72E 0E           CLJ         ENABLE INPUT INTERRUPTS.
00652 *****          ***** INITIALIZATION COMPLETED *****
00653 C73E B6 0241 TLP31 LDA B #01 MESSAGE TRANSMISSION COMPLETED
00654 C732 B1 0237       CRP A ENDM

```

```

00655 C735 22 0A      BHI     TLP39
00656 C737 26 0E      RNE     TLP310
00657 C739 B6 0242    LDA A  ROT+1
00658 C73C B1 0238    CMP A  END01+1
00659 C73F 23 06      BLS     TLP310      IF YES,
00660 C741 CE 019C    TLP39  LDX     #TX1BLB  SET OUTPUT READ POINTER TO
                                BEGINNING OF TRANSMIT OUTPUT FILE.
00661 C744 FF 0241    STX     ROT
00662 C747 B6 0240    TLP310 LDA A  WIN+1  RESET RECV. BUFFER WRITE POINTER
                                TO BEGINNING OF BUFFER IF IT EXCEEDS
00663 C74A B1 0198    CMP A  TEMP+5  THE UPPER BOUNDARY OF THE BUFFER.
00664 C74D 23 05      BLS     TLP311
00665 C74F 86 00      LDA A  #0
00666 C751 B7 0240    STA A  WIN+1
00667 C754 B6 023E    TLP311 LDA A  RIN+1  DATA AVAILABLE?
00668 C757 B1 0240    CMP A  WIN+1  IF NOT, WAIT!
00669 C75A 27 B3      BEQ     TLP31
00670 C75C F6 0223    LDA B  SEQFLG  SEQUENCE IN PROCESS?
00671 C75F 27 22      BEQ     TLP32
00672 C761 B6 0197    LDA A  TEMP+4  DECREMENT SEQUENCE COUNT.
00673 C764 80 01      SUB A  #1
00674 C766 B7 0197    STA A  TEMP+4  END OF SEQUENCE?
00675 C769 26 03      RNE     TLP33
00676 C76B 7F 0223    CLR     SEQFLG
00677 C76E B6 023E    TLP33  LDA A  RIN+1  UPDATE INPUT READ POINTER.
00678 C771 8B 02      ADD A  #2
00679 C773 B7 023E    STA A  RIN+1
00680 C776 B1 0198    CMP A  TEMP+5  END OF INPUT BUFFER?
00681 C779 23 B4      RLS     TLP31  IF YES, SET INPUT READ
00682 C77B 86 00      LDA A  #0  POINTER TO BEGINNING OF
00683 C77D B7 023E    STA A  RIN+1  INPUT BUFFER.
00684 C780 7E C72F    JMP     TLP31
00685 C783 FE 023D    TLP32  LDX     PIN
00686 C786 A6 00      LDA A  0*X  GET HEADER.
00687 C788 E6 01      LDA B  1*X
00688 C78A 81 00      CMP A  #STAT0  STATUS MESSAGE DETECTED?
00689 C78C 26 21      RNE     TLP34
00690 C78E C1 39      CMP B  #STAT1
00691 C790 26 28      BNE     TLP35
00692 C792 B6 0231    LDA A  STANS0+1  INCREMENT STATUS COUNTER.
00693 C795 F6 0230    LDA B  STANS0
00694 C798 8B 01      AND A  #1
00695 C79A C9 00      ADC B  #0
00696 C79C B7 0231    STA A  STANS0+1
00697 C79F F7 0230    STA B  STANS0
00698 C7A2 E6 04      LDA A  #1  INITIALIZE SEQUENCE COUNTER.
00699 C7A4 B7 0197    STA A  TEMP+1
00700 C7A7 86 01      LDA A  #1  SET FLAG "SEQUENCE IN PROCESS"
00701 C7A9 B7 0223    STA A  SEQFLG
00702 C7AC 7E C902    JMP     TLP310
00703 C7AF 81 1F      TLP34  CMP A  #1  FULL CHARACTER DETECTED?
00704 C7B1 26 07      RNE     #1005
00705 C7B3 C1 F8      CMP B  #1001
00706 C7B5 26 03      RNE     #1005

```

D-21


```

00759          ***** EXIT ROUTINE *****
00760 C824 0F      1LP39 SEI          DISABLE INPUT INTERRUPTS.
00761 C825 7F 0220 CLR          RCVFLG    DISABLE DATA RECORDING.
00762 C828 7F 0222 CLR          TXFLAG    DISABLE DATA TRANSMISSION.
00763 C82B 86 FF   LDA A #1FF     SET CONFIGURATION CONTROL.
00764 C82D B7 580A STA A PIAPB2    BACK TO NORMAL OPERATION.
00765 C830 86 02   LDA A #20000010  INDICATE TEST LOOP 3
00766 C832 B7 580C STA A SYSDON   IS COMPLETE.
00767 C835 86 00   LDA A #0       CLEAR MENU.
00768 C837 39      RTS
00769          *****
00770          ***** SUBROUTINE (TEST LOOP #4) *****
00771          *****
00772          *
00773          *           THIS ROUTINE DETERMINES WHETHER
00774          *           THE SIMULATOR CARD CAN TRANSMIT AND RECEIVE DATA.
00775          *
00776          ***** INITIALIZATION *****
00777 C838 B7 0199 TSTLP4 STA A SCRTCH  SAVE MENU.
00778 C83E 4F      CLR A
00779 C83C B7 021C STA A LOCKUP   CLEAR INPUT SYNCH FLAG.
00780 C83F B7 021F STA A TIMFLG  CLEAR TIMEOUT FLAG
00781 C842 B7 021E STA A DATFLG  CLEAR DATA RECV. FLAG
00782 C845 B7 0190 STA A ERRORS  CLEAR ALL ERROR FLAGS.
00783 C848 B7 021D STA A TIMOUT  CLEAR TIMEOUT COUNTER.
00784 C84B E7 0221 STA A TXCOMP  CLEAR TRANSMISSION COMPLETE FLAG.
00785 C84E B7 023D STA A RIN     SET RECEIVED DATA READ AND WRITE
00786 C851 B7 023F STA A WIN     POINTERS TO BEGINNING OF SIMU.
00787 C854 B7 0235 STA A ENDIN  RECEIVE BUFFER.
00788 C857 B6 0188 LDA A STATUS  CLEAR "SIMULATION CARD ERROR" FLAG.
00789 C85A 84 0F   AND A #21101111
00790 C85C B7 0188 STA A STATUS
00791 C85F 86 05   LDA A #5     SET FRAME COUNT TO ACCEPT 4 FRAMES
00792 C861 B7 0227 STA A FRHNT  AFTER TRANSMISSION HAS COMPLETED.
00793 C864 86 00   LDA A #RUF518
00794 C866 B7 023E STA A RIN+1
00795 C869 B7 0240 STA A WIN+1
00796 C86C 86 1F   LDA A #RUF518 SET UP SIMU. RECEIVE
00797 C86E B7 0236 STA A ENDIN+1 BUFFER UPPER BOUNDARY.
00798 C871 CE C000 LDX #THLTXD  SET TRANSMIT POINTER TO
00799 C874 FF 0241 STX ROT     BEGINNING OF TRANSMIT TABLE.
00800 C877 CE C01F LDX #1PL1XD+31 SET UP TRANSMIT TABLE
00801 C87A FF 0237 STX ENDOT  UPPER BOUNDARY.
00802 C87D CE C010 LDX #1BL1XD+16 SET UP LOOPUP (TRANSMIT)
00803 C880 FF 0243 STX LKPFIP  TABLE READ POINTER.
00804 C883 86 3F   LDA A #1FF   SET UP CONFIGURATION CONTROL
00805 C885 B7 580A STA A PIAPB2  FOR SELF TESTING.
00806 C888 86 22   LDA A #200100010 INDICATE TEST LOOP 4
00807 C88A B7 580C STA A SYSDON  IS EXECUTING.
00808 C88D 86 01   LDA A #1
00809 C88F B7 0222 STA A TXFLAG  ENABLE DATA TRANSMISSION.
00810 C892 B7 0220 STA A RCVFLG  ENABLE DATA RECORDING

```

D-24

```

00811 C895 0E          CLI          ENABLE INPUT INTERRUPTS.
00812                ***** INITIALIZATION COMPLETE *****
00813 C896 B6 021F TLP41 LDA A TIMFLG  TIMEOUT OCCUR?
00814 C899 26 31          BNE TLP42
00815 C89B B6 023E      LDA A RIN+1  DATA AVAILABLE? IF NOT, WAIT.
00816 C89E B1 0240      CMP A WIN+1
00817 C8A1 27 F3          BEQ TLP41
00818 C8A3 FE 023D      LDX RIN      GET RECEIVED FRAME.
00819 C8A6 A6 00          LDA A 0,X
00820 C8A8 E6 01          LDA B 1,X
00821 C8AA FE 0243      LDX LKPFTR  COMPARE TO CORRESPONDING
00822 C8AD A1 00          CMP A 0,X    LOOKUP (TRANSMIT) FRAME.
00823 C8AF 26 23          BNE TLP43
00824 C8B1 E1 01          CMP B 1,X
00825 C8B3 26 1F          BNE TLP43
00826 C8B5 08          INX          UPDATE LOOKUP (TRANSMIT)
00827 C8B6 08          INX          TABLE READ POINTER.
00828 C8B7 FF 0243      STX LKPFTR
00829 C8BA B6 023E      LDA A RIN+1  UPDATE READ POINTER TO
00830 C8BD 8B 02          ADD A #2    SIMU. RECEIVE BUFFER.
00831 C8BF B7 023E      STA A RIN+1
00832 C9C2 B6 0244      LDA A LKPFTR+1 SEARCH COMPLETE?
00833 C8C5 B1 0238      CMP A ENDOT+1
00834 C9C8 22 1A          BHI TLP44   IF YES, RETURN FROM SUBROUTINE.
00835 C8CA 20 CA          BRA TLP41
00836 C8CC B6 0190 TLP42 LDA A ERRORS
00837 C8CF B7 0189      STA A STATUS+1
00838 C9D2 20 08          BRA TLP45
00839 C8D4 B6 0190 TLP43 LDA A ERRORS
00840 C8D7 8A 08          ORA A #200001000 SET 'INCORRECT DATA RECEIVED' ERROR.
00841 C8D9 B7 0189      STA A STATUS+1
00842 C8DC B6 0188 TLP45 LDA A STATUS SET 'DIAGNOSTIC CARD' ERROR.
00843 C8DF 8A 20          ORA A #200100000
00844 C9E1 B7 0189      STA A STATUS
00845                ***** EXIT ROUTINE *****
00846 C8E4 0F          TLP44 SET      DISABLE INPUT INTERRUPTS.
00847 C8E5 7F 0220      CLR RCYFLG  DISABLE DATA RECORDING.
00848 C8E9 7F 0222      CLR TXFLAG  DISABLE DATA TRANSMISSION.
00849 C8EB B6 FF          LDA A #FF   SET CONFIGURATION CONTROL
00850 C8ED B7 580A      STA A PIAPB2 BACK TO NORMAL OPERATION.
00851 C8F0 B6 02          LDA A #200000010 INDICATE TEST LOOP 1
00852 C8F2 B7 580C      STA A SYENON IS COMPLETED.
00853 C8F5 B6 0197      LDA A SCRCH  RECALL SAVED MENU.
00854 C8F8 39          RTS
00855                *****
00856                ***** SURROUTINE (TEST LOOP 1) *****
00857                *****
00858                *
00859                *          THIS ROUTINE DETERMINES THE STATUS
00860                *          OF SURVEILLON CHANNEL #1
00861                *
00862                ***** INITIALIZATION *****

```

```

00863 C8F9 B7 0199 TSTLPS STA A SCRICH SAVE MENU.
00864 C8FC 4F CLR A
00865 C8FD B7 021C STA A LOCKUP CLEAR INFUT SYNCH FLAG.
00866 C900 B7 021F STA A TIMFLG CLEAR TIMEOUT FLAG.
00867 C903 B7 021E STA A DATFLG CLEAR DATA RECEIVED FLAG.
00868 C906 B7 0190 STA A ERRORS CLEAR ALL ERROR FLAGS.
00869 C909 B7 0191 STA A ERRORS+1
00870 C90C B7 0192 STA A ERRORS+2
00871 C90F B7 021D STA A TIMOUT CLEAR TIMEOUT COUNTER.
00872 C912 B7 0221 STA A TXCOMP CLEAR TRANSMISSION COMPLETE FLAG.
00873 C915 B7 0224 STA A EOR CLEAR END OF RECV. BUFFER DETECTED FLAG.
00874 C918 B7 0229 STA A IDLCNT CLEAR IDLE COUNTER.
00875 C91B B7 023D STA A RIN
00876 C91E B7 023F STA A WIN
00877 C921 B7 0235 STA A ENDIN
00878 C924 B6 20 LDA A #BUFC1B SET RECEIVE DATA READ AND WRITE
00879 C926 B7 023E STA A RIN+1 POINTERS TO BEGINNING OF CHANNEL #1
00880 C929 B7 0240 STA A WIN+1 RECEIVE BUFFER.
00881 C92C B6 D3 LDA A #BUFC1E SET UP CHANNEL #1 RECEIVE
00882 C92E B7 0236 STA A ENDIN+1 BUFFER UPPER BOUNDARY.
00883 C931 B6 018B LDA A STATUS CLEAR "CHANNEL #1 FAILURE" FLAG.
00884 C934 B6 BF AND A #210111111
00885 C936 B7 018B STA A STATUS
00886 C939 B6 09 LDA A #9 SET FRAME COUNT TO ACCEPT 8 FRAMES
00887 C93B B7 0227 STA A FRMCNT AFTER TRANSMISSION HAS COMPLETED.
00888 C93E CE C000 LDX #TBLTXD SET TRANSMIT POINTER TO
00889 C941 FF 0241 STX R0T BEGINNING OF TRANSMIT TABLE.
00890 C944 CE C07F LDX #TX1EHD SET UP TRANSMIT TABLE
00891 C947 FF 0237 STX ENDOT UPPER BOUNDARY.
00892 C94A CE C100 LDX #TBLKFP SET LOOKUP POINTER TO
00893 C94D FF 0243 STX LKFPTR BEGINNING OF LOOKUP TABLE.
00894 C950 CE C16F LDX #LKFPND SET UP LOOKUP TABLE
00895 C953 FF 0239 STX ENDUP UPPER BOUNDARY.
00896 C956 B6 78 LDA A #78 SET UP CONFIGURATION CONTROL
00897 C958 B7 580A STA A PIAPB2 FOR CHANNEL 1 TESTING.
00898 C95B B6 42 LDA A #201000010 INDICATE THAT TEST LOOP 5
00899 C95D B7 580C STA A SYSMON IS EXECUTING.
00900 C960 B6 01 LDA A #1
00901 C962 B7 0222 STA A TXFLAG ENABLE DATA TRANSMISSION.
00902 C965 B7 0220 STA A RCVF1G ENABLE DATA RECORDING.
00903 ***** INITIALIZATION COMPLETE *****
00904 C968 7E C9DB JHF TLP561
00905 *****
00906 ***** SUBROUTINE (TEST LOOP #6) *****
00907 *****
00908 *
00909 * THIS ROUTINE DETERMINES THE STATUS
00910 * OF SURVEILLANCE CHANNEL #2
00911 *
00912 ***** INITIALIZATION *****
00913 C96B B7 0199 TSTLPS STA A SCRICH SAVE MENU
00914 C96E 4F CLR A
    
```

D-25

1

```

00915 C96F B7 021C      STA A LOCKUP      CLEAR INPUT SYNCH FLAG.
00916 C972 B7 021F      STA A TIMFLG     CLEAR TIMEOUT FLAG.
00917 C975 B7 021E      STA A DATFLG    CLEAR DATA RECEIVED FLAG.
00918 C978 B7 0190      STA A ERRORS    CLEAR ALL ERROR FLAGS.
00919 C97B B7 0191      STA A ERRORS+1
00920 C97E B7 0192      STA A ERRORS+2
00921 C981 B7 021D      STA A TIMEOUT   CLEAR TIMEOUT COUNTER.
00922 C984 B7 0221      STA A TXCOMP    CLEAR TRANSMISSION COMPLETE FLAG.
00923 C987 B7 0224      STA A EOB       CLEAR END OF RECV. BUFFER DETECTED FLAG.
00924 C98A B7 0229      STA A IDLCNT    CLEAR IDLE COUNTER.
00925 C98D B7 023D      STA A RIN
00926 C990 B7 023F      STA A WIN
00927 C993 96 D4        LDA A #BUFC2B   SET RECEIVE DATA READ AND WRITE
00928 C995 B7 023E      STA A RIN+1     POINTERS TO BEGINNING OF CHANNEL #2
00929 C998 B7 0240      STA A WIN+1     RECEIVE RUFFER.
00930 C99B CE 0187      LDX #BUFC2E    SET UP CHANNEL #2 RECEIVE
00931 C99E FF 0235      STX ENDIN      BUFFER UPPER BOUNDARY.
00932 C9A1 B4 0188      LDA A STATUS   CLEAR 'CHANNEL #2 FAILURE' FLAG.
00933 C9A4 B4 7F        AND A #20111111
00934 C9A6 B7 0188      STA A STATUS
00935 C9A9 B6 09        LDA A #9       SET FRAME COUNT TO ACCEPT 8 FRAMES
00936 C9AB B7 0227      STA A FRMCNT   AFTER TRANSMISSION HAS COMPLETED.
00937 C9AE CE C000      LDX #TBLTXD    SET TRANSMIT POINTER TO
00938 C9B1 FF 0241      STX ROT        BEGINNING OF TRANSMIT TABLE.
00939 C9B4 CE C07F      LDX #TX1END    SET UP TRANSMIT TABLE
00940 C9B7 FF 0237      STX ENDOT      UPPER BOUNDARY.
00941 C9BA CE C100      LDX #TBLCLKP   SET LOOKUP POINTER TO
00942 C9BD FF 0243      STX LKPFTR     BEGINNING OF LOOKUP TABLE.
00943 C9C0 CE C16F      LDX #LKPEND    SET UP LOOKUP TABLE
00944 C9C3 FF 0239      STX ENDUP      UPPER BOUNDARY.
00945 C9C6 B6 87        LDA A #67      SET UP CONFIGURATION CONTROL
00946 C9C8 B7 580A      STA A PIAFR2   FOR CHANNEL 2 TESTING.
00947 C9CB B6 82        LDA A #210000010 INDICATE THAT TEST LOOP 6
00948 C9CD B7 580C      STA A SYSMON   IS EXECUTING.
00949 C9D0 B6 01        LDA A #1
00950 C9D2 B7 0222      STA A TXFLAG   ENABLE DATA TRANSMISSION.
00951 C9D5 B7 0220      STA A RCVFLG   ENABLE DATA RECORDING.
00952 ***** INITIALIZATION COMPLETE *****
00953 C9DB 7E C9DB      JHF TLP561
00954 *****
00955 ***** SURV. CHANNEL DIAGNOSTIC ROUTINE *****
00956 *****
00957 C9DB 0E          TLP561 CLI      ENABLE INPUT INTERRUPTS.
00958 C9DC B6 021F      LDA A TIMFLG   TIMEOUT OCCUR?
00959 C9DF 27 03        BEQ TLP562
00960 C9E1 7E CC1C      JHF EX11
00961 C9E4 B6 023E      TLP562 LDA A RIN+1 DATA AVAILABLE? IF NOT, WAIT.
00962 C9E7 B1 0240      LDF A WIN+1
00963 C9EA 27 EF        BEQ TLP561
00964 C9ED FE 023D      LDX RIN        GET RECEIVE FRAME.
00965 C9EF A6 80        LDA A #A6
00966 C9F1 E6 01        LDA B 1A

```

D-26

```

00967 C9F3 FE 0243      LDX      LKPPTR    DOES THE RECEIVE FRAME
00968 C9F3 A1 00      CMP A    0,X      MATCH THE LOOKUP FRAME?
00969 C9F8 26 2C      BNE      CKSTAT
00970 C9FA E1 01      CMP B    1,X
00971 C9FC 26 28      BNE      CKSTAT
00972 C9FE 7F 0229     CLR      IDLCNT   RESET IDLE COUNTER.
00973 CA01 08          TLP564 INX          UPDATE LOOKUP POINTER.
00974 CA02 08          INX
00975 CA03 FF 0243     STX      LKPPTR
00976 CA06 BD CC79     JSR      UPDATE   UPDATE DATA RECEIVE
00977 CA09 B6 0224     LDA A    EOB      BUFFER READ POINTER.
00978 CA0C 27 03      BEQ      TLP563
00979 CA0E 7E CC1C     JMP      EXIT
00980 CA11 P6 0243     TLP563 LDA A    LKPPTR   SEARCH COMPLETE?
00981 CA14 B1 0239     CMP A    ENDUP    IF YES, JUMP TO EXIT ROUTINE.
00982 CA17 22 0A      BHI      TLP565
00983 CA19 26 C9      BNE      TLP561
00984 CA1B B6 0244     LDA A    LKPPTR+1
00985 CA1E B1 023A     CMP A    ENDUP+1
00986 CA21 23 B8      BLS      TLP561
00987 CA23 7E CC1C     TLP565 JMP      EXIT
00988 ***** STATUS CHECK *****
00989 *
00990 *      THIS ROUTINE DETERMINES IF A STATUS MESSAGE
00991 *      WAS RECEIVED CORRECTLY.
00992 *
00993 *****
00994 CA26 91 0C      CKSTAT CMP A    #STAT0  STATUS HEADER DETECTED?
00995 CA28 27 03      BEQ      CKSTAB
00996 CA2A 7E CAB5     JMP      CKIDLE   IF NOT, TEST FOR IDLE CHARACTER.
00997 CA2D C1 38      CKSTAB CMP B    #STAT1  IF YES, VERIFY THAT THE STATUS
00998 CA2F 27 03      BEQ      CKSTA9  MESSAGE WAS RECEIVED CORRECTLY.
00999 CA31 7E CAB5     JMP      CKIDLE   SET 'FRAME COUNT' TO 4.
01000 CA34 B6 04      CKSTA9 LDA A    #4
01001 CA36 B7 0228     STA A    STACNT
01002 CA39 7C 0229     INC      IDLCNT  INCREMENT IDLE COUNTER.
01003 CA3C B6 0227     LDA A    FRMCNT  DELAY RECIEVER TERMINATION
01004 CA3F 88 05      ADD A    #5      ALLOWING FOR STATUS MESSAGE.
01005 CA41 E7 0227     STA A    FRMCNT
01006 CA44 BD CC79     CKSTA1 JSR      UPDATE   UPDATE RECEIVED DATA
01007 CA47 B6 0224     LDA A    EOB      BUFFER READ POINTER.
01008 CA4A 27 03      BEQ      CKSTA6  EXIT IF AT END OF BUFFER.
01009 CA4C 7E CC1C     JMP      EXIT
01010 CA4F B6 023E     CKSTA6 LDA A    RINH1   NEXT FRAME AVAILABLE:
01011 CA52 B1 0240     CMP A    RINH1
01012 CA55 27 FB      BEQ      CKSTA6
01013 CA57 FE 023D     LDA      RINH    GET FRAME FROM RECV. BUFFER.
01014 CA5A A6 00      LDA A    0
01015 CA5C E6 01      LDA B    1
01016 CA5E 7C 0229     INC      IDLCNT  INCREMENT IDLE COUNTER.
01017 CA61 76 0229     BEQ      STACNT  END OF STATUS MESSAGE?
01018 CA64 27 12      BEQ      CKSTA2  IF YES, SEARCH FOR IDLE CHARACTER.

```

D-27

```

01019 CA66 81 00      CMP A  #00      DATA FIELD SHOULD BE ALL ZEROS.
01020 CA68 26 04      BNE   CKSTA3
01021 CA6A C1 08      CMP B  #08
01022 CA6C 27 D6      BEQ   CKSTA1
01023 CA6E B6 0192    CKSTA3 LDA A  ERRORS+2   IF NOT, SET 'INCORRECT STATUS
01024 CA71 8A 80      ORA A  #Z10000000 MESSAGE' ERROR THEN CONTINUE
01025 CA73 87 0192    STA A  ERRORS+2   VERIFYING STATUS MESSAGE.
01026 CA76 20 CC      BRA   CKSTA1
01027 CA78 81 1F      CKSTA2 CMP A  #IDLE0   VERIFY IDLE CHARACTER
01028 CA7A 26 04      BNE   CKSTA4   AFTER STATUS MESSAGE.
01029 CA7C C1 FB      CMP B  #IDLE1   IF NOT FOUND SET
01030 CA7E 27 27      BEQ   CKSTA5   'INCORRECT IDLE' ERROR.
01031 CA80 B6 0190    CKSTA4 LDA A  ERRORS
01032 CA83 8A 10      ORA A  #Z00010000
01033 CA85 B7 0190    STA A  ERRORS
01034 CA88 FE 023D    LHX   RIN      TEST TO SEE IF IDLE WAS MISSING.
01035 CA8B A6 00      LDA A  0,X
01036 CA8D E6 01      LDA B  1,X
01037 CA8F FE 0243    LDX   LKPPTR   GET RECV. DATA FRAME AND COMPARE
01038 CA92 A1 00      CMP A  0,X     IT TO THE CURRENT LOOKUP FRAME.
01039 CA94 26 11      BNE   CKSTA5   IF BOTH FRAMES MATCH SET ERROR
01040 CA96 E1 01      CMP B  1,X     'MISSING IDLE AFTER STATUS MESSAGE'
01041 CA98 26 0D      BNE   CKSTA5   AND CLEAR ERROR 'INCORRECT IDLE'.
01042 CA9A B6 0190    LDA A  ERRORS  'MISSING IDLE AFTER STATUS MESSAGE'
01043 CA9D 8A 20      ORA A  #Z00100000 ERROR SET AND 'INCORRECT IDLE'
01044 CA9F 84 EF      AND A  #Z11101111 CLEARED.
01045 CAA1 B7 0190    STA A  ERRORS
01046 CAA4 7E C9DB    JMP   TLP561
01047 CAA7 BD CC79    CKSTA5 JSR   UPDATE  UPDATE DATA RECEIVE
01048 CAAA B6 0224    LDA A  EOR     BUFFER READ POINTER.
01049 CAAD 27 03      BEQ   CKSTA7
01050 CAAF 7E CC1C    JMP   EXIT     EXIT IF AT END OF BUFFER.
01051 CAB2 7E C9DB    CKSTA7 JMP   TLP561
01052                ***** IDLE CHECK *****
01053                *
01054                * THIS ROUTINE DETERMINES IF ADDITIONAL IDLES HAVE BEEN
01055                * ADDED TO THE DATA STREAM OR IF A MESSAGE IS MISSING.
01056                *
01057                *****
01058 CAB5 81 1F      CKIDLE CMP A  #IDLE0   IDLE CHARACTER FOUND?
01059 CAB7 27 03      BEQ   CKIDL7
01060 CAB9 7E CB74    JMP   CKDATA
01061 CABD C1 FB      CKIDL7 CMP B  #IDLE1
01062 CABE 27 03      BEQ   CKIDL9
01063 CAC0 7E CB74    JMP   CKDATA
01064 CAC3 BD CCA7    CKIDL9 JSR   MTYPE
01065 CAC6 7C 0229    CKIDL2 INC   IBLCNT   INCREMENT IDLE COUNT.
01066 CAC9 BD CC79    JSR   UPDATE   UPDATE DATA RECEIVE
01067 CACC B6 0224    LDA A  EOR     BUFFER READ POINTER.
01068 CACF 27 03      BEQ   CKID13
01069 CAD1 7E CB2B    JMP   CKID12
01070 CAD4 B6 023E    CKID14 LDA A  RINFI   NEXT FRAME AVAILABLE

```

D-28

```

01071 CAD7 B1 0240      CMP A  WIN+1
01072 CADA 27 FB      BEQ   CKIDL14
01073 CADC FE 023D      LDX   R1N      GET RECV. FRAME.
01074 CADF A5 00      LDA A  0,X
01075 CAE1 E6 01      LDA B  1,X
01076 CAE3 81 1F      CMP A  #IDLE0   IDLE CHARACTER FOUND?
01077 CAE5 26 04      BNE   CKIDL1   IF YES, JUMP TO CKIDL2
01078 CAE7 C1 FB      CMP B  #IDLE1
01079 CAE9 27 BB      BEQ   CKIDL2
01080 CAEB FE 0243 CKIDL1 LDX   LKPFTR   LOOKUP FRAME MATCH THE RECEIVED FRAME?
01081 CAEE A1 00      CMP A  0,X      IF YES, SET THE 'EXTRA IDLES' FLAG.
01082 CAF0 26 0F      BNE   CKIDL3   IF NO, DETERMINE IF MESSAGE IS MISSING.
01083 CAF2 E1 01      CMP B  1,X
01084 CAF4 26 0B      BNE   CKIDL3
01085 CAF6 B6 0190     LDA A  ERRORS   'EXTRA IDLES' FLAG SET.
01086 CAF9 8A 40      ORA A  #201000000
01087 CAFB B7 0190     STA A  ERRORS
01088 CAFE 7E C9DB     JMP   TLP561
01089 CB01 B7 0193 CKIDL3 STA A  TEMP      PEEK AHEAD BY 'IDLCNT' INTO LOOKUP TABLE.
01090 CB04 B6 0229     LDA A  IDLCNT
01091 CB07 0B          CKIDL4 INX
01092 CB08 0B          INX
01093 CB09 4A          DEC A
01094 CBA0 26 FB      BNE   CKIDL4
01095 CB0C B6 0193     LDA A  TEMP      COMPARE LOOKUP FRAME TO RECV. FRAME.
01096 CB0F A1 00      CMP A  0,X
01097 CB11 26 42      BNE   CKIDL5
01098 CB13 E1 01      CMP B  1,X
01099 CB15 26 3E      BNE   CKIDL5
01100 CB17 B6 0229     LDA A  IDLCNT   DOUBLE IDLE COUNT.
01101 CB1A 4B          ASL A
01102 CB1B 0C          CLC
01103 CB1C F6 0244     LDA B  LKPFTR+1  \EX. IDLCNT = 8 / LKPFTR = #C0F6 \
01104 CB1F 1B          ABA          \ UPDATE LKPFTR BY 8 X 2 = 16 = #10 \
01105 CB20 F6 0243     LDA B  LKPFTR    \ LOWER BYTE = #F6 + #10 = #06/C = 1 \
01106 CB23 C9 00      ADC B  #0        \ UPPER BYTE = #C0 + 0 + 1 = #C1 \
01107 CB25 B7 0244     STA A  LKPFTR+1  \ LKPFTR = #C106 \
01108 CB28 F7 0243     STA B  LKPFTR
01109 CB2B CE C170 CKIDL8 LDX   #TBLMSG   UPDATE LOOKUP POINTER BY TWO TIMES IDLE COUNT.
01110 CB2E B6 0225     LDA A  OFFSET   SET APPROPRIATE 'MESSAGE MISSING' ERROR(S).
01111 CB31 27 04      CKIDL10 BEQ   CKIDL6
01112 CB33 0B          INX
01113 CB34 4A          DEC A
01114 CB35 20 FA      BRG   CKIDL10
01115 CB37 B6 0191 CKIDL6 LDA A  ERRORS+1
01116 CB3A AA 00      ORA A  X
01117 CB3C B7 0191     STA A  ERRORS+1
01118 CB3F B6 0229     LDA A  IDLCNT   SUBTRACT 8 FROM THE IDLE COUNT.
01119 CB42 80 08      SUB A  #8
01120 CB44 B7 0229     STA A  IDLCNT   IF STILL POSITIVE, SET THE
01121 CB47 22 03      BHI   CKIDL11  NEXT 'MISSING MESSAGE' ERROR.
01122 CB49 7E C9DB     JMP   TLP561

```

```

01123 CB4C 08      CKID11 INX
01124 CB4D 8C C177 CPX      #TBLMSG+7
01125 CB50 26 E5      BNE      CKIDL6
01126 CB52 7E CC1C      JMP      EXIT
01127 CB55 CE C170 CKID15 LDX      #TBLMSG  SET APPROPRIATE
01128 CB58 B6 0225      LDA A  OFFSET  'MISSING MESSAGE' FLAG.
01129 CB5B 27 04      CKID13 BEQ      CKID12
01130 CB5D 08      INX
01131 CB5E 4A      DEC A
01132 CB5F 20 FA      BRA      CKID13
01133 CB61 B6 0191 CKID12 LDA A  ERRORS+1
01134 CB64 AA 00      ORA A  X
01135 CB66 B7 0191      STA A  ERRORS+1
01136 CB69 B6 0190      LDA A  ERRORS  SET 'PANIC' FLAG.
01137 CB6C BA 80      ORA A  %10000000
01138 CB6E B7 0190      STA A  ERRORS
01139 CB71 7E CC1C      JHF      EXIT
01140
01141                ***** DATA CHECK *****
01142                *
01143                *           THIS ROUTINE IDENTIFIES INCORRECT MESSAGES.
01144                *
01145                *****
01145 CB74 BD CCA7 CKDATA JSR      MTYPE  DETERMINE CURRENT MESSAGE BEING VARIFIED.
01146 CB77 FE 0243      LDX      LKPPTR
01147 CB7A B7 0193      STA A  TEMP
01148 CB7D B6 0225      LDA A  OFFSET  IF THE PROBLEM IS IN VARIFYING THE
01149 CB80 27 4C      BEQ      CKDAT1  FIRST MESSAGE, GO TEST IF IT IS MISSING.
01150 CB82 A6 00      LDA A  0,X      IS THE LOOKUP FRAME AN IDLE CHARACTER?
01151 CB84 B1 C000      CMP A  TBLTXD  IF YES, TEST WHETHER A STATUS MESSAGE
01152 CB87 26 07      BNE      CKDAT2  HAS BEEN INSERTED BETWEEN TWO SEARCH
01153 CB89 E6 01      LDA B  1,X      MESSAGES.
01154 CB8B F1 C001      CMP B  TBLTXD+1 IF NOT, SET APPROPRIATE ERRORS.
01155 CB8E 27 65      BEQ      CKDAT4
01156 CB90 CE C170 CKDAT2 LDX      #TBLMSG
01157 CB93 B6 0225      LDA A  OFFSET
01158 CB96 27 04      CKDAT8 BEQ      CKDAT7
01159 CB98 08      INX      UPDATE INDEX POINTER TO NEXT MESSAGE.
01160 CB99 4A      DEC A
01161 CB9A 20 FA      BRA      CKDAT8
01162 CB9C B6 0192 CKDAT7 LDA A  ERRORS+2  SET APPROPRIATE INCORRECT
01163 CB9F AA 00      ORA A  X      REFORMATTED MESSAGE ERROR.
01164 CBA1 B7 0192      STA A  ERRORS+2
01165 CBA4 B6 023E      LDA A  FIN+1  VERIFY THAT THE NEXT RECEIVED FRAME
01166 CBA7 BB 04      ADD A  #1      IS AVAILABLE BEFORE ATTEMPTING TO
01167 CBA9 B1 0240 CKDAT9 CMP A  MIN+1  COMPARE THE FRAME TO ITS ASSOCIATED
01168 CBAC 22 FE      BHI      CKPAT9  LOOK UP FRAME.
01169 CBAE FE 023D      LDX      FIN      PEER AHEAD AT NEXT RECEIVED FRAME.
01170 CBB1 A6 02      LDA A  2,X
01171 CBB3 E6 03      LDA B  3,X
01172 CBB5 FE 0243      LDX      LKPPTR  COMPARE IT TO NEXT LOOKUP FRAME.
01173 CBB8 A1 02      CMP A  2,X      IF THEY DO NOT MATCH.
01174 CBBA 26 07      BNE      CKDAT3  SET 'PANIC' FLAG.

```

```

01175 CBBC E1 03      CMP B 3,X
01176 CBBE 24 03      BNE CKDAT3
01177 CBC0 7E CA01    JMP TLP564
01178 CBC3 B4 0190    CKDAT3 LDA A ERRORS 'PANIC' FLAG SET TO 1.
01179 CBC6 BA 80      ORA A #Z10000000
01180 CBC8 B7 0190    STA A ERRORS
01181 CBCB 7E CC1C    JMP EXIT EXIT ROUTINE.
01182 CBCE B4 0193    CKDAT1 LDA A TEMP PEEK AHEAD INTO LOOKUP TABLE AT
01183 CBD1 A1 10      CMP A 16,X NEXT MESSAGE HEADER AND COMPARE
01184 CBD3 24 BB      BNE CKDAT2 TO CURRENT RECEIVE FRAME. IF THEY MATCH
01185 CBD5 E1 11      CMP B 17,X SET ERROR 'MESSAGE 1 MISSING'.
01186 CBD7 24 B7      BNE CKDAT2
01187 CBD9 B6 0191    LDA A ERRORS+1 ERROR 'MESSAGE 1 MISSING' SET TO 1.
01188 CBDC BA C170    ORA A TBLMSG
01189 CBDF B7 0191    STA A ERRORS+1
01190 CBE2 B4 0244    LDA A LKFPTR+1 UPDATE LOOKUP POINTER TO NEXT MESSAGE.
01191 CBE5 F4 0243    LDA B LKFPTR
01192 CBE8 8B 10      ADD A #16
01193 CBEA C9 00      ADC B #0
01194 CBEC B7 0244    STA A LKFPTR+1
01195 CBEF F7 0243    STA B LKFPTR
01196 CBF2 7E C9DB    JMP TLP561
01197 CBF5 08        CKDATA4 INX UPDATE LOOKUP POINTER.
01198 CBF6 08        INX
01199 CBF7 FF 0243    STX LKFPTR
01200 CBFA A6 00      LDA A 0,X GET LOOKUP FRAME.
01201 CBFC E4 01      LDA B 1,X IS LOOKUP FRAME AN IDLE CHARACTER?
01202 CBFE B1 C000    CMP A TBLTXD IF YES, UPDATE LOOKUP POINTER AND
01203 CC01 24 05      BNE CKDAT5 CHECK NEXT FRAME FOR IDLE.
01204 CC03 F1 C001    CMP B TBLTXD+1 IF NOT, TEST FOR DATA MATCH.
01205 CC06 27 ED      BEQ CKDAT4
01206 CC08 FE 023D    CKDAT5 LDX RIN
01207 CC0B A1 00      CMP A 0,X
01208 CC0D 24 07      BNE CKDAT6
01209 CC0F E1 01      CMP B 1,X
01210 CC11 24 03      BNE CKDAT6
01211 CC13 7E C9DB    JMP TLP561
01212 CC16 7C 0225    CKDAT6 INC OFFSET
01213 CC19 7E CB90    JMP CKDAT2
01214                ***** EXIT ROUTINE *****
01215 CC1C 0F        EXIT SEI DISABLE INPUT INTERRUPTS.
01216 CC1D B4 0199    LDA A SCRATCH TEST FOR LOOP 1.
01217 CC20 27 04      BEQ TLP5
01218 CC22 B4 580A    LDA A PIAPB2 DETERMINE CURRENT
01219 CC25 48        ASL A DIAG. LOOP IN USE.
01220 CC26 25 21      RCS TLP5
01221 CC28 F4 0190    TLP5 LDA B ERRORS LOAD ERRORS IN STATUS FILE.
01222 CC2B F7 018A    STA B STATUS+2
01223 CC2E 17        TRA
01224 CC2F F4 0191    LDA B ERRORS+1
01225 CC32 F7 018B    STA B STATUS+3
01226 CC35 1B        ABG

```

```

01227 CC36 F6 0192      LDA B  ERRORS+2
01228 CC39 F7 018C      STA B  STATUS+4
01229 CC3C 18           ABA                    UPDATE SYSTEM STATUS
01230 CC3D 27 29       BEQ   EXIT1           IF ERRORS OCCURED.
01231 CC3F B6 0188      LDA A  STATUS        FAILURE IN SURV. CHANNEL #1.
01232 CC42 BA 40       ORA A  %01000000
01233 CC44 B7 0188      STA A  STATUS
01234 CC47 20 1F       BRA   EXIT1
01235 CC49 F6 0190 TLP6 LDA B  ERRORS        LOAD ERRORS IN STATUS FILE.
01236 CC4C F7 018D      STA B  STATUS+5
01237 CC4F 17           TBA
01238 CC50 F6 0191      LDA B  ERRORS+1
01239 CC53 F7 018E      STA B  STATUS+6
01240 CC56 18           ABA
01241 CC57 F6 0192      LDA B  ERRORS+2
01242 CC5A F7 018F      STA B  STATUS+7
01243 CC5D 18           ABA                    UPDATE SYSTEM STATUS
01244 CC5E 27 08       BEQ   EXIT1           IF ERRORS OCCURED.
01245 CC60 B6 0188      LDA A  STATUS        FAILURE IN SURV. CHANNEL #2.
01246 CC63 BA 80       ORA A  %10000000
01247 CC65 B7 0188      STA A  STATUS
01248 CC68 7F 0222 EXIT1 CLR  TXFLAG        DISABLE DATA TRANSMISSION.
01249 CC6B 86 FF       LDA A  %FF          SET CONFIGURATION CONTROL
01250 CC6D B7 580A      STA A  PIAPB2       BACK TO NORMAL OPERATION.
01251 CC70 B6 02       LDA A  %00000010    INDICATE TEST LOOP
01252 CC72 B7 580C      STA A  SYSDON       IS FINISHED.
01253 CC75 B6 0199      LDA A  SCRATCH      RECALL SAVED MENU.
01254 CC78 39           RTS
01255                    *****
01256                    ***** SUBROUTINE (UPDATE) *****
01257                    *****
01258                    *
01259                    * THIS ROUTINE UPDATES THE RECEIVED DATA BUFFER READ POINTER
01260                    * AND COMPARES IT TO THE UPPER ADDRESS OF THE RECEIVE BUFFER.
01261                    * IF THE READ POINTER EXCEEDS THE UPPER ADDRESS AN "INCOMPLETE
01262                    * SEARCH" ERROR IS SET AND THE "END OF BUFFER" FLAG IS
01263                    * RAISED TO INITIATE TERMINATION OF THE TEST LOOP.
01264                    *
01265                    *****
01266 CC79 B7 019A UPDATE STA A  SCRATCH+1    SAVE ACC 'A' DATA.
01267 CC7C FE 023D        LDX   RIN            UPDATE RECV. DATA
01268 CC7F 08           INX                    BUFFER READ POINTER.
01269 CC80 08           INX
01270 CC81 FF 023D        STX   RIN
01271 CC84 B6 023D        LDA A  RIN            END OF RECEIVE DATA BUFFER?
01272 CC87 B1 0235        CMP A  ENDIN         IF NOT; RETURN FROM SUBROUTINE.
01273 CC8A 22 0E        BHI   UPDAT1         IF YES; SET "END OF BUFFER"
01274 CC8C 24 08        RNE   UPDAT2         FLAG AND SET "INCOMPLETE SEARCH"
01275 CC8E B6 023E        LDA A  RIN+1         ERROR.
01276 CC91 B1 0238        CMP A  ENDIN+1
01277 CC94 22 04        BHI   UPDAT1
01278 CC96 B6 019A UPDAT2 LDA A  SCRATCH+1    RECALL SAVED ACC 'A' DATA.

```

```

01279 C099 39          RTS
01280 C09A 86 01  UPDAT1 LDA A  #1          IF YES, SET 'END OF BUFFER'
01281 C09C B7 0224    STA A  E0H          FLAG AND SET 'INCOMPLETE SEARCH'
01282 C09F B6 0190    LDA A  ERRORS      ERROR.
01283 C0A2 8A 08      ORA A  #200001000
01284 C0A4 B7 0190    STA A  ERRORS
01285          *****
01286          ***** SUBROUTINE (MESSAGE TYPE) *****
01287          *****
01288          *
01289          *           THIS ROUTINE DETERMINES WHICH MESSAGE
01290          *           THE LOOKUP POINTER IS SET TO.
01291          *
01292          *****
01293 C0A7 B7 019A  MTYPE STA A  SCRTCH+1    SAVE ACC 'A' DATA.
01294 C0AA F7 0198    STA B  SCRTCH+2    SAVE ACC 'B' DATA.
01295 C0AD CE C100    LDX  #TBLLKP     GET LOOKUP TABLE START ADDRESS
01296 C0B0 FF 0194    STX  TEMP+1     AND STORE IN TEMP 1 AND 2.
01297 C0B3 7F 0225    CLR  OFFSET     SET MESSAGE TYPE PTR TO FIRST MESSAGE.
01298 C0B6 B6 0243    LDA A  LKFPTR   GET CURRENT LOOKUP POINTER VALUE.
01299 C0B9 F6 0244    LDA B  LKFPTR+1
01300 C0BC C0 10    ML3  SUB B  #16    SUBTRACT 16 FROM LOOKUP POINTER.
01301 C0BE 82 00      SEC A  #0
01302 C0C0 B1 0194    CMP A  TEMP+1   COMPARE LOOKUP POINTER TO START ADDRESS.
01303 C0C3 22 10      BHI  ML1        IF GREATER THEN OR EQUAL TO, POINT TO
01304 C0C5 26 07      BNE  ML2        NEXT MESSAGE.
01305 C0C7 F1 0195    CMP B  TEMP+2
01306 C0CA 22 09      BHI  ML1
01307 C0CC 27 07      BEQ  ML1
01308 C0CE B6 019A  ML2  LDA A  SCRTCH+1    RECALL SAVED ACC 'A' DATA
01309 C0D1 F6 0198    LDA B  SCRTCH+2    RECALL SAVED ACC 'B' DATA
01310 C0D4 39          RTS
01311 C0D5 7C 0225  ML1  INC  OFFSET     POINTER TO NEXT MESSAGE.
01312 C0D8 26 E2      BRA  ML3
01313          *****
01314          ***** SUBROUTINE (OPERATIONAL MODE) *****
01315          *****
01316 C0DA 86 09  OPER1  LDA A  #09     SET CONFIGURATION CONTROL
01317 C0DC B7 580A    STA A  PIAPB2    FOR BY-PASS MODE.
01318 C0DF 39          RTS
01319          *****
01320          ***** SUBROUTINE (DELAY) *****
01321          *****
01322          *
01323          *           THIS ROUTINE SETS UP A TWO SECOND PROGRAM FAUSE
01324          *
01325          *****
01326 C0E0 06 00  DELAY  LDA B  #0      INITIALIZE DELAY COUNT
01327 C0E2 F7 022A    STA B  DEL1
01328 C0E5 F7 022B    STA B  DEL2
01329 C0E8 C6 01      LDA B  #1
01330 C0EA F7 022C    STA B  DEL3
    
```

D-33

```

01331 CCED 01      DLYLP3 NOP
01332 CCEE 01      DLYLP2 NOP
01333 CCEF F6 022A DLYLP1 LDA R DEL1
01334 CCF2 CB 01      ADD B #1
01335 CCF4 F7 022A      STA B DEL1
01336 CCF7 24 F6      BCC DLYLP1
01337 CCF9 F6 022B      LDA B DEL2
01338 CCFC CB 01      ADD B #1
01339 CCFE F7 022B      STA B DEL2
01340 CD01 24 EB      BCC DLYLP2
01341 CD03 F6 022C      LDA B DEL3
01342 CD06 C0 01      SUB B #1
01343 CD08 F7 022C      STA B DEL3
01344 CD0B 24 E0      BCC DLYLP3 EXIT WHEN THE CARRY BIT IS SET TO 1.
01345 CD0D 39      RTS
01346
01347 *****
01348 ***** INPUT INTERRUPT ROUTINE *****
01349 CD0E B6 0220 IRQ LDA A RCVFLG DATA RECORDING ENABLED?
01350 CD11 27 12      BEQ A7
01351 CD13 B6 021C      LDA A LOCKUP INTERFACE SYNCHRONIZED TO INPUT
01352 CD16 26 03      BNE A10 DATA STREAM?
01353 CD18 7E CDA0      JMP A1
01354 CD1B 7C 0226 A10 INC BITCNT NEXT FRAME AVAILABLE?
01355 CD1E B6 0226      LDA A BITCNT IF NOT, CLEAR INPUT
01356 CD21 81 0D      CMP A #13 INTERRUPT AND RETURN.
01357 CD23 27 07      BEQ A4
01358 CD25 B6 5800 A7 LDA A PIAPA0 CLEAR INPUT INTERRUPT.
01359 CD28 B6 5804      LDA A PIAPA1
01360 CD2B 3B      RTI
01361 CD2C 7F 0226 A4 CLR BITCNT RESET BIT COUNTER.
01362 CD2F B6 0221      LDA A TXCOMP IF TRANSMISSION IS COMPLETE
01363 CD32 27 0B      BEQ A5 START INHIBIT RECORDING SEQUENCE.
01364 CD34 7A 0227      DEC FRMCNT
01365 CD37 B6 0227      LDA A FRMCNT
01366 CD3A 26 03      BNE A5
01367 CD3C 7F 0220      CLR RCVFLG
01368 CD3F B6 021E A5 LDA A DATFLG DATA FLAG SET?
01369 CD42 26 2C      BNE A8
01370 CD44 B6 5800      LDA A PIAPA0 GET FRAME
01371 CD47 F6 5804      LDA B PIAPA1
01372 CD4A B1 C000      CMP A TBLTXD TEST FRAME FOR IDLE CHARACTER.
01373 CD4D 26 1B      BNE A6
01374 CD4F F1 C001      CMP B TBLTXD1
01375 CD52 26 16      BNE A6
01376 CD54 B6 021D      LDA A TIMOUT INCREMENT TIMEOUT COUNTER.
01377 CD57 8B 01      ADD A #1
01378 CD59 E7 021D      STA A TIMOUT
01379 CD5C 24 71      BCC A3 IF TIMEOUT OCCURS,
01380 CD5E B6 0190      LDA A EPROPS SET 'IDLE CHARACTER LOCKUP ONLY'
01381 CD61 8A 02      ORA A #00000010 FLAG.
01382 CD63 87 0190      STA A EPROPS

```

```

01383 CD66 7C 021F      INC     TIMFLG   SET 'TIMEOUT' FLAG.
01384 CD69 3B          RTI
01385 CD6A 7F 021D A6   CLR     TIMEOUT
01386 CD6D 7C 021E      INC     DATFLG
01387 CD70 FE 023F A8   LDX    WIN      STORE DATA FRAME.
01388 CD73 B6 5800      LDA A  PIAPAO
01389 CD76 F6 5804      LDA B  PIAPAI
01390 CD79 A7 00        STA A  0,X
01391 CD7B E7 01        STA R  1,X
01392 CD7D 08          INX
01393 CD7E 08          JNX
01394 CD7F FF 023F      STX    WIN
01395 CD82 B6 023F      LDA A  WIN      RECEIVE BUFFER FULL?
01396 CD85 B1 0235      CMP A  ENDIN
01397 CD88 22 0A        BHI    A9
01398 CD8A 26 43        BNE    A3
01399 CD8C B6 0240      LDA A  WIN+1
01400 CD8F B1 0236      CMP A  ENDIN+1
01401 CD92 23 3B        BLS    A3
01402 CD94 B6 0190 A9   LDA A  ERRORS   SET 'BUFFER FULL' ERROR.
01403 CD97 8A 04        ORA A  $200000100
01404 CD99 B7 0190      STA A  ERRORS
01405 CD9C 7F 0220      CLR    RCVFLG   STOP ACCEPTING DATA.
01406 CD9F 3B          RTI
01407 CDA0 B6 5800 A1   LDA A  PIAPAO   GET POSSIBLE FRAME. ATTEMPT TO
01408 CDA3 F6 5804      LDA R  PIAPAI   SYNCHRONIZE TO INPUT DATA STREAM
01409 CDA6 B1 C000      CMP A  TBLTXD   BY LOCKING ON AN IDLE CHARACTER.
01410 CDA9 26 0F        BNE    A2
01411 CDAB F1 C001      CMP B  TBLTXD+1
01412 CDAE 26 0A        BNE    A2
01413 CDB0 7C 021C      INC    LOCKUP   WHEN AN IDLE CHARACTER IS DETECTED
01414 CDB3 7F 0226      CLR    BITCNT  SET THE LOCKUP FLAG AND INITIALIZE
01415 CDB6 7F 021D      CLR    TIMEOUT THE FRAME BIT COUNTER AND CLEAR
01416 CDB9 3B          RTI             TIMEOUT COUNTER.
01417 CDBA B6 021D A2   LDA A  TIMEOUT INCREMENT TIMEOUT COUNTER.
01418 CDBD 8B 01        ADD A  #1
01419 CDBF B7 021D      STA A  TIMEOUT
01420 CDC2 24 0B        BCC    A3      IF TIMEOUT OCCURS,
01421 CDC4 B6 0190      LDA A  ERRORS   SET 'NO SYNCHRONIZATION'
01422 CDC7 8A 01        ORA A  $200000001 ERROR FLAG.
01423 CDC9 B7 0190      STA A  ERRORS
01424 CDCC 7C 021F      INC    TIMFLG   SET 'TIMEOUT' FLAG.
01425 CDCF 3B          RTI
01426
01427
01428 *****
***** OUTPUT INTERRUPT *****
*****
01429 CDD0 B6 0222 NMI   LDA A  TXFLAG   TRANSMIT ENABLED?
01430 CDD3 27 37        BEQ    B1
01431 CDD5 B6 0241      LDA A  ROT      TRANSMISSION COMPLETE?
01432 CDD8 B1 0237      CMP A  ENDOT
01433 CDDB 22 1E        BHI    B2
01434 CDDD 26 08        BNE    B3

```

```

01435 CDDF B6 0242      LDA A ROT+1
01436 CDE2 B1 0238      CMF A ENDOT+1
01437 CDE5 22 14        BHI B2
01438 CDE7 FE 0241 B3    LDX ROT
01439 CDEA A6 00        LDA A 0,X      OUTPUT NEXT FRAME.
01440 CDEC B7 5802      STA A PIAPB0
01441 CDEF E6 01        LDA B 1,X
01442 CDF1 F7 5806      STA B PIAPB1
01443 CDF4 08           INX            UPDATE READ POINTER.
01444 CDF5 08           INX
01445 CDF6 FF 0241      STX ROT
01446 CDF9 20 11        BRA B1
01447 CDFB 86 01 B2     LDA A #1      SET *TRANSMISSION COMPLETE* FLAG.
01448 CDFD B7 0221      STA A TXCOMP
01449 CE00 B6 C000      LDA A TBLTXD  OUTPUT IDLE CHARACTER.
01450 CE03 B7 5802      STA A PIAPB0
01451 CE06 B6 C001      LDA A TBLTXD+1
01452 CE09 B7 5806      STA A PIAPB1
01453 CE0C B6 5802 B1   LDA A PIAPB0  CLEAR INTERRUPT FLAG.
01454 CE0F B6 5806      LDA A PIAPB1
01455 CE12 3B          RTI
01456                  *****
01457                  ***** SWI INTERRUPT *****
01458                  *****
01459 CE13 B6 0188 SWI   LDA A STATUS
01460 CE16 8A 40        ORA A #X01000000
01461 CE18 B7 0188      STA A STATUS
01462 CE1B 3B          RTI
01463                  END

```

SYMBOL TABLE

BUFDA	0000	BUFSC1	0020	BUFSC2	00D4	STATUS	0188	ERRORS	0190	TEMP	0193	SCRATCH	0197	IBLTCR	019C	BUFSTR	0000
BUFSIE	001F	BUFC1B	0020	BUFC1E	00D3	BUFC2B	00D4	BUFC2E	0187	TXTRLB	019C	TXTRLE	021B	LOCKUP	021C	THOUT	021D
DATFLG	021E	TINFLG	021F	RCVFLG	0220	TXCOMF	0221	TXFLAG	0222	SFOFLG	0223	ERR	0224	OFFSET	0225	BTOUT	0226
FRMCNT	0227	STACNT	0228	INLCNT	0229	DEL1	022A	DEL2	022B	DEL3	022C	DATHSG	022D	STATHSG	022E	ENG	022F
EXCLOR	0234	ENDIN	0235	ENDOT	0237	ENDUP	0239	BTXPTR	023B	RIN	023D	MIN	023F	PUT	0241	CLPTR	0244
TBLTYD	C000	TX1END	C07F	TLLKP	C100	LKPEND	C13F	TRMSG	C170	STAT0	000C	STAT1	0039	TBLE0	001F	TBLE1	00F9
PIAPA0	5800	PIACA0	5801	PIAFB0	5802	PIACB0	5803	PIAPA1	5804	PIACA1	5805	PIAFB1	5806	PIACB1	5807	PIAPA2	5808
PIACA2	5809	PIAFB2	580A	PIACB2	580B	SYSHON	580C	INIT	C400	INIT1	C454	LOOP1	C460	LOOP2	C44F	OUT	C476
TST1	C495	TST2	C49E	TST3	C4A3	TST4	C4A9	TST5	C4AF	TST6	C4B5	OPR1	C4BD	OPR2	C4C2	TSTLP1	C4C5
TLP11	C51A	TLP12	C52F	TLP14	C534	TLP13	C58F	TSTLP2	C5C9	TLP22	C5D7	TLP21	C5E4	TLP23	C632	TLP25	C647
TLP24	C65D	TLP26	C66F	TSTLP3	C678	TLP36	C6C9	TLP31	C72F	TLP39	C741	TLP310	C747	TLP311	C754	TLP33	C74E
TLP32	C783	TLP34	C7AF	TLP35	C7BA	TLP315	C7C9	RNGA1	C7E3	RNGA2	C7F3	TLP312	C802	TLP316	C813	TLP314	C81A
TLP313	C81D	TLP38	C824	TSTLP4	C838	TLP41	C896	TLP42	C8CC	TLP43	C8D4	TLP45	C8DC	TLP44	C8E4	TSTLP5	C8F9
TSTLP6	C96B	TLP561	C9DB	TLP562	C9E4	TLP564	CA01	TLP563	CA11	TLP565	CA33	CKSTA1	CA26	CKSTA8	CA2D	CKSTA7	CA34
CKSTA1	CA44	CKSTA6	CA4F	CKSTA3	CA6E	CKSTA2	CA78	CKSTA4	CA80	CKSTA5	CAA7	CKSTA7	CAB2	CKIDLE	CAB5	CKID17	CAB6
CKIDL9	CAC3	CKIDL2	CAC6	CKID14	CAD4	CKID11	CAF8	CKID13	CB01	CKIDL4	CB07	CKIDL8	CB28	CKID10	CB31	CKIDL6	CB37
CKID11	CB4C	CKIDL5	CB55	CKID13	CB5B	CKID12	CB61	CKDATA	CB74	CKDAT2	CB90	CKDAT8	CB96	CKDAT7	CB9C	CKDAT9	CB99
CKDAT3	CB03	CKDAT1	CBCE	CKDAT4	CBF5	CKDAT5	CC08	CKDAT6	CC16	EXIT	CC1C	TLP5	CC28	TLP6	CC49	EXL01	CCAB
UPDATE	CC79	UPDAT2	CC96	UPDAT1	CC9A	HTYPE	CCA7	HL3	CCBC	HL2	CCCE	HL1	CCD5	OPER1	CCDA	DELAY	CCED
DLYLP3	CCED	DLYLP2	CCEE	DLYLP1	CCEF	IRQ	CD0E	A10	CD1B	A7	CD25	A4	CD2C	A5	CD3F	A6	CD50
AB	CD70	A9	CD94	A1	CDA0	A2	CDBA	A3	CDCF	NMI	CD00	B3	CDE7	B2	CDFF	B1	CE00
SWI	CE13																

APPENDIX E

EQUIPMENT INSTALLATION
AND OPERATION

EQUIPMENT INSTALLATION.

Four installation cables are provided with the serial data reformatter equipment. All four cables are identical with connectors compatible with the 25-pin cinch connectors used by the Mode S and the modems. These cables are used to install the reformatter between the Mode S surveillance output ports and the modems.

Figure E1 shows the Mode S/terminal automated test facility (TATF) modem configuration prior to and after the installation of the serial data reformatter equipment. The procedure to install the equipment is as follows:


1. Remove the lower back panel on unit 14 of the Mode S sensor.
2. Referring to figure E1 disconnect cable 14W4P1 (14A2A1J1) at the TATF surveillance channel #1 modem.
3. Connect one end of an installation cable to cable 14W4P1.
4. Connect the remaining cable connector to the reformatter's channel #1 Mode S plug.
5. Connect a second installation cable to the reformatter's channel #1 modem plug.
6. Connect the remaining cable connector to plug J1 at the TATF surveillance channel #1 modem.
7. Repeat steps 1 through 6 for cable 14W5P1 (14A4A2J1) to install channel #2 of the reformatter.
8. Plug the power cable into the same AC power phase supplying the modems.

EQUIPMENT OPERATION.


After the serial data reformatter equipment is correctly installed set all the address switches and the address mode control switch to their down position to place the simulation and diagnostic module (SDM) address bus under microprocessor control. Then set the ON/OFF power switch to its ON (up) position and depress the system reset button. Both channel monitors should display a hexadecimal 10 indicating that the channels are not synchronized to the Mode S surveillance data stream and that the SDM monitor should be cleared. The equipment is now in a wait state. The reformatter is placed in this wait state when power is first applied to the equipment or when the system reset button is depressed.

Normal operating mode - To place the reformatter in the normal mode set address switch "O" to its up position. The remaining address switches should remain in their down position. The SDM monitor should respond with all LEDs turned on indicating that the instruction has been read. Once the monitor has indicated that the instruction has been read address switch "O" may be set to its down position. The instruction is executed when the display goes off. The reformatter is now in the normal operating mode. As soon as the instruction has been completed a two second pause will elapse before another instruction can be read. If address switch "O" remains up, the SDM monitor will continue to flash on and off every four seconds. The equipment, however, will remain in the normal mode.

The reformatter, also, may be placed in the normal operating mode by running any of the test programs. At the completion of any of these programs the reformatter is automatically placed in the normal mode of operation.



A. Normal Mode S/TATF MODEM Configuration



B. Mode S/ARTS IIIA Test Configuration

Figure E1. Serial Data Reformatter Equipment Installation

LOC. (HEX)		LOC. (HEX)	
0		0 - 1F	SDM input data buffer
	Random Access Memory	20 - D3	Channel #1 input data buffer
		D4 - 187	Channel #2 input data buffer
		188 - 18F	System status file
/		/19C - 21B	Transmit file
/		/	
3FF			
400			
/	NOT USED	/	
/	USED	/	
57FF			
5800	PIA's	5800-580B	Peripheral Interface addresses
580C		580C	SDM Monitor
580D			
/	NOT USED	/	
/	USED	/	
CBFF			
C000		C000-C07F	Data Transmit Table #1
		C080-C0FF	Data Transmit Table #2
	Read Only Memory	C100-C16F	Data Look Up Table
/		/	
/		/	
CFFF			
D000			
/	NOT USED	/	
/	USED	/	
FFFF			

Figure E2. Overview of SDM Memory Map

Test mode - Before discussing the test mode of operation the functions of the SDM front panel switches and display monitor will be described.

Address Mode Control Switch - The address mode control switch determines whether the microprocessor or the operator has control over the SDM address bus. If this switch is in its down position the microprocessor has control over the address bus. If this switch is in its up position the operator has control over the address bus via the 16 SDM address switches.

SDM Address Switches - The SDM address switches serve two purposes depending on the position of the address mode control switch. If the address mode control switch is in its up position the SDM address switches are used to inspect the content of the SDM's memory. The data at the location selected is displayed on the SDM monitor. Figure E2 shows a brief overview of the SDM memory map. Refer to appendix D for further details on the test programs and data files.

If the address mode control switch is set to its down position the lower 8 address switches are used by the operator to pass instructions to the SDM software. The upper 8 address switches are not used. Table E1 presents the functions of the SDM address switches when the address mode control switch is in its down position. A detailed description of the lower 8 address switches is listed below:

Switch 0 - This switch initiates the reading and execution of an instruction defined by switches 1 through 7 when it is placed in its up position.

Switch 1 - This switch selects the mode of operation. If placed in the down position the normal mode is selected. In this mode switches 2 through 7 are not used. If placed in the up position the test mode is selected.

Switch 2 - If switch 1 is up, this switch selects the verification routine check test when in its up position. Switches 5, 6, and 7 select the fault message for this routine. If switch 1 is down, this switch selects the by-pass mode of operation when in its up position.

Switch 3 - This switch selects the continuous message dissemination routine when it is in the up position. Switches 5, 6, and 7 selects the one message in data transmit table #1 to be transmitted.

Switch 4 - This switch selects the status dissemination check routine when it is in the up position. Switches 5, 6, and 7 select specific information for inspection while this routine is running. Refer to table E1 for more details on what information is displayed.

Switch 5 - This switch selects the SDM verification routine when placed in the up position. Switches 2, 3, and 4 must be in their down position.

Switch 6 - This switch selects the channel#1 verification routine when placed in the up position with switches 2, 3, and 4 remaining in the down position.

TABLE E1. DEFINITION OF SDM ADDRESS SWITCHES

ADDRESS SWITCH	DEFINITION OF INSTRUCTIONS				
0	1 = EXECUTE				
1	0 = Normal Mode	1 = Test Mode			
2	1 = By-Pass Mode	1 = Verification Routine Check SWITCHES FAULT			
		7	6	5	MESSAGE SELECTED
		0	0	0	WEATHER MESSAGE
		0	0	1	CPME/BAD PARITY
		0	1	0	BCN STROBE/DIFF. TIS
		0	1	1	BCN#1/BAD PARITY
		1	0	0	SRCH#1/DIFF. AZIMUTH
		1	0	1	SYNCH/DIFF. TIS
		1	1	0	SRCH#2/BAD HEADER
		1	1	1	BCN#2/DIFF. RG & A CODE
3	CURRENTLY UNUSED	1 = Continuous Message Dissemination SWITCHES			
		7	6	5	MESSAGE SELECTED
		0	0	0	ALL IDLES
		0	0	1	ATCRBS CPME
		0	1	0	BEACON STROBE
		0	1	1	REGULAR BEACON #1
		1	0	0	REGULAR SEARCH #1
		1	0	1	AZIMUTH SYNCH
		1	1	0	REGULAR SEARCH #2
		1	1	1	REGULAR BEACON #2
4	CURRENTLY UNUSED	1 = Status Dissemination Check SWITCHES			
		7	6	5	BYTE DISPLAYED
		0	0	0	UPPER BYTE OF MESSAGE COUNTER
		0	0	1	MIDDLE BYTE OF MESSAGE COUNTER
		0	1	0	LOWER BYTE OF MESSAGE COUNTER
		0	1	1	UPPER BYTE OF STATUS COUNTER
		1	0	0	LOWER BYTE OF STATUS COUNTER
		1	0	1	UPPER BYTE OF SEQUENCE GEN.
		1	1	0	LOWER BYTE OF SEQUENCE GEN.
		1	1	1	EXCLUSIVE OR GATE OUTPUT
5	CURRENTLY UNUSED	1 = SDM Verification Routine			
6	CURRENTLY UNUSED	1 = Channel #1 Verification Routine			
7	CURRENTLY UNUSED	1 = Channel #2 Verification Routine			

Switch 7 - This switch selects the channel#2 verification routine when placed in the up position with switches 2, 3, and 4 remaining in the down position. Note that the serial data reformatter equipment may be completely certified by setting switches 5, 6, and 7 to their up position with switches 2, 3, and 4 remaining in their down position. The three routines will be executed in sequential order. At the completion of all three routines the overall status of the equipment is displayed.

SDM Monitor - The SDM monitor consists of 8 LEDs which provide means to inspect the status of test programs while running or to step through programs and data files resident in memory depending on the position of the address mode control switch. If the address mode control switch is in its down position the SDM monitor provides an account of the equipment on line. While a test program is running the LED corresponding to the switch selecting the program will be on, i.e., if switch 5 is in its up position selecting the SDM verification routine, the LED labeled "D5" will be on. In addition, the LED "D1" will be on indicating that the SDM is in the test mode.

The following procedures are used to certify the serial data reformatter equipment prior to conducting a test. This is accomplished by running the three verification routines.

First preset all the SDM address switches to their down position to prevent accidentally selecting an incorrect test mode. Then set switches 5, 6, and 7 to their up position to select the SVR, CVR-1 and CVR-2 tests, respectively. Now set switch 1 to its up position to select the test mode. Toggle switch "O" to the up position momentarily. The SDM monitor should immediately indicate that the instruction has been read. After a two second pause the three routines will be executed in succeeding order as shown on the monitor. The status of the Reformatter will be displayed on the SDM monitor at the completion of all three verification routines. All indicators of the monitor will be off if the reformatter passes all three routines. The monitor will display the first byte of the system status file if any of the routines fail.

The system status file is presented in table E2. This file contains eight bytes labeled Status+0 through Status+7 as shown. The location and general purpose of each byte is given along with a brief description of the flags contained in each byte. The first byte labeled Status+0 contains the general status of the reformatter and specifies which verification routine failed. Status+1 contains the status of the SDM. The next three bytes consists of specific condition flags on channel #1 and the final three bytes consists of specific condition flags on channel #2. If a problem is detected the file may be inspected by setting the address mode control switch to its up position and selecting the appropriate address via the SDM switches. The error information will be displayed on the SDM monitor.

TABLE E2. SYSTEM STATUS FILE

STATUS+0 (188 Hex.) "CURRENT CARD STATUS"
 D7 - PROBLEM IN SURVEILLANCE REFORMATTER CHANNEL #2!
 D6 - PROBLEM IN SURVEILLANCE REFORMATTER CHANNEL #1!
 D5 - PROBLEM IN DIAGNOSTIC/SIMULATION CARD!
 D4 - NOT USED
 D3 - "
 D2 - "
 D1 - "
 D0 - SOFTWARE ERROR INTERRUPT! (SWI)

STATUS+1 (189 Hex.) "DIAGNOSTIC/SIMULATION CARD"
 D7 - NOT USED
 D6 - "
 D5 - "
 D4 - "
 D3 - INCORRECT DATA RECEIVED!
 D2 - INPUT BUFFER OVERFLOW!
 D1 - IDLE CHARACTER LOCKUP ONLY!
 D0 - IDLE CHARACTER LOCKUP DID NOT OCCUR!

STATUS+2 (18A) {STATUS+5} {18D} "CHANNEL #1" {"CHANNEL #2"}
 D7 - PANIC FLAG!
 D6 - EXTRA IDLE CHARACTERS!
 D5 - MISSING IDLE CHARACTERS!
 D4 - IDLE CHARACTER INCORRECT!
 D3 - TEST TERMINATED BEFORE COMPLETION!
 D2 - INPUT BUFFER OVERFLOW!
 D1 - IDLE CHARACTER LOCKUP ONLY!
 D0 - IDLE CHARACTER LOCKUP DID NOT OCCUR!

STATUS+3 (18B) {STATUS+6} {18E} "MISSING MESSAGES"
 D7 - STATUS MESSAGE (INDICATOR FLAG ONLY)
 D6 - BEACON MESSAGE #2
 D5 - SEARCH MESSAGE #2
 D4 - SEARCH RTQC MESSAGE
 D3 - SEARCH MESSAGE #1
 D2 - BEACON MESSAGE #1
 D1 - BEACON RTQC MESSAGE
 D0 - ATCRBS CPME REGULAR BEACON MESSAGE

STATUS+4 (18C) {STATUS+7} {18F} "INCORRECT MESSAGES"
 D7 - STATUS MESSAGE
 D6 - BEACON MESSAGE #2
 D5 - SEARCH MESSAGE #2
 D4 - SEARCH RTQC MESSAGE
 D3 - SEARCH MESSAGE #1
 D2 - BEACON MESSAGE #1
 D1 - BEACON RTQC MESSAGE
 D0 - ATCRBS CPME REGULAR BEACON MESSAGE