



NOTE:

1. Use straw bales in drainage ditches only for low flow conditions and when specified on the Erosion Control Plans.




ELEVATION




PLAN


INSTALLATION OF A STRAW BALE BARRIER AT TOE OF FILL




Step 1: Excavate trench



Step 3: Tightly pack straw between bales
(plan view of bales)




Step 2: Install bales




Step 4: Backfill soil against bales

PROPERLY STAKED AND ENTRENCHED STRAW BALES



ELEVATION



PLAN

INSTALLATION OF A STRAW BALE BARRIER IN DITCH

See Note 1

NO SCALE

U.S. DEPARTMENT OF TRANSPORTATION FEDERAL HIGHWAY ADMINISTRATION FEDERAL LANDS HIGHWAY	
U.S. CUSTOMARY STANDARD	
STRAW BALES	
STANDARD APPROVED FOR USE 6/2005 REVISED: 6/2007	STANDARD 157-3